DATE: REVISION

## APOLLO/SATURN LAUNCH OPERATIONS

PAGE TEST NO. VEHICLE

CALIBRATION ERROR ELIMINATION TEST

AS-206

Prepared by: Charles V. Belf

APPROVALS:

Manager, Department 958

NASA Systems Engineer

Quality Engineering

# KSC OPERATIONS APOLLO/SATURN TEST CATALOG 1. TEST TITLE CALIBRATION ERROR ELIMINATION TEST AS-206 CALIBRATION TEST AS-206 PAGE 1 OF 2. KSC TEST NO. 958-1-IU 206 3. STAGE, VEHICLE OR GSE IU 206

#### 4. TEST OBJECTIVES

To isolate the causes of excessive noise on the Cal Error Detection Channels and to isolate the causes of the DC level shift between the IU and SIVB Telemetry Systems, when additional equipment is turned on and at power transfer.

#### 5. TEST DESCRIPTION/EQUIPMENT STATUS

Two to three 30-minute runs will be made. Each run will be in a different configuration to gather data under varying conditions. One run will be made to simulate a proposed EO to eliminate the Cal Error.

(CONTINUE ON KSC FORM 23-192 IF REQUIRED)

6. PREPARED BY

8. NASA-KSC APPROVAL

10. APPROVAL DATE

7. ORGANIZATION

9. ORGANIZATION

11. VEHICLE EFFECTIVITY

AS - 206

APOLLO/SATURN TES		PAGE 2 OF					
1, TEST TITLE			2. KSC TEST NO.				
Cal Error Data Collection			11. VEHICLE EFFECTIVITY				
12. WHERE TEST PERFORMED	13. COMPUTER/ACE PROG. IDENT.	UE APPLIC	AS - 206 ABLE) 14. EST. TEST TIME				
12. WHERE TEST PERFORMED	13. COMPOTER/ACE PROG. IDENT.	AFFEIC	A DEE / 14. EST. TEST TIME				
15. TEST CONFIGURATION	15. TEST CONFIGURATION						
16. SUPPORT REQUIREMENTS CHECKLIST (Check appropriate boxes and add any additional)							
GROUND POWER	LCC MEASURING (LVO)	ETR/I	KSC RADAR				
S-IB OR S-IC STAGE PWR	CC MEASURING (INS)	ETR	COMMAND XMITTER				
S-II STAGE POWER	GSE MEASURING (LVO)	LOCA	L COMMAND (C.L.)				
S-IVB STAGE POWER	GSE MEASURING (INS)	ALDS					
IU POWER	CC DATA DISPLAY	LCC	TM STA. (MONITOR)				
LEM POWER	CIF DATA DISPLAY	LCC	TM RECORDING				
SM POWER	DDAS	CIFT	M STA. (MONITOR)				
CM POWER	DDAS TAPE RECORDING	CIF T	M RECORDING				
BACK-UP BATTERIES	SERVICE STRUCTURE MEAS.	CIFC	OMPUTER				
TIMING	RCA-110A COMPUTERS	CIF D	ATA				
COUNTDOWN CLOCK	ACE	TM RE	ECORDS				
ETR SEQUENCER	L/V W-G ECS	REAL	-TIME CIF COMPUT.				
ETR COUNTDOWN CLOCK	CM W-G ECS	POST.	TEST CIF COMPUT.				
ETR S.R.O.	FACILITY ECS (GAS)	KSC T	FRACKING				
ETR R.S.O.	H.P. GAS	RFIM	ONITORING				
ETR PAD SAFETY	CCF	RFRE	EADOUTS (ETR)				
KSC PAD SAFETY	FACILITY TV (OTV)	RFRE	EADOUTS (KSC)				
SECURITY POLICE	FACILITY COMM. (OIS)	WEAT	HER FORECAST				
FIRE FIGHTING	FILM CAMERAS	MCC-C					
MEDICAL	SEARCH LIGHTS	MCC-H	4				
		FOOD	SERVICE				
			×				
OTHERS:							
*NOTE - See SECTION II for the above information.							
		ED)					
17. OTHER APPLICABLE REFERENCE DOCU	(CONTINUE ON KSC FORM 23-192 IF REQUIRED) OTHER APPLICABLE REFERENCE DOCUMENTATION						

.

PAGE TEST NO. VEHICLE

#### I. PURPOSE:

To isolate the causes of excessive noise on the Cal Error Detection Channels and to isolate the causes of the DC level shift between the IU and SIVB Telemetry Systems, when additional equipment is turned on and at power transfer.

#### II. SUPPORT REQUIRED:

- Approximately eight (8) hours of IU/SIVB stage power with no interference.
- 2. IU/SIVB Structure Measuring.
- 3. IU/SIVB Vehicle Networks.
- 4. IU/SIVB Telemetry.
- 5. DDAS
- 6. All G & C for IU:
  - 1) LVDA/LVDC
  - 2) 56 v supply
  - 3) AC supply (inverter)
  - 4) ST-124
  - 5) Control Computer
  - 6) Control Rate Gyros/CSP
- 7. Permission to come up and down with IU/SIVB Telemetry and Telemetry

  Transmitters Open loop frequency clearance required for:

IU:

1) DF1 RF

250.7 MHZ

2) DP1 RF

255.1 MHZ

SIVB:

1) CP1 RF

258.5 MHZ

8. Permission to come up and down with IU Command System - Open loop frequency clearance required for:

PAGE TEST NO. **VEHICLE** 

- 1) Command Decoder/Recorder 450.0 MHZ

- 9. QCI and QCE
- 10. Breakout Boxes and cables for second run:
  - 1) J6 (PT07P 18-32s) 602A3 Dist. (pins  $\underline{a}$ ,  $\underline{b}$ , Z); IU Electrical Schematics, p. 11.
  - 2) J13 (PT07P 24-61s) 602A3 Dist. (pins M, P, S, U, W, Y, <u>a</u>, <u>d</u>); IU Electrical Schematics, pp. 57 and 58.
  - 3) J6 (PT07P-10-6p) DP1 Mux. (602A446), pin E (+) to B (com.); IU Electrical Schematics, p. 40.
  - 4) J18 (PT07P-18-32s) 602A3 Dist. (pins E, N, and P).
- 11. CUNP Power Transfer
- 12. C4NP Power Transfer
- 13. CUIP Power Transfer
- 14. C4IP Power Transfer
- 15. IU OAT Batteries Power Transfer
- 16. SIVB OAT Batteries Power Transfer
- 17. BURF Command System

#### III. PREPARATIONS:

- 1. Breakout Boxes will be required for Run #2 as called out under Run #2.
- 2. IU/SIVB Structure Measuring will be required to strip-out the following measurements in a manner so as to read a change of 5 mv or greater. Also, digital printouts will be required when requested by SUTM.
  - 1) IU Stripouts:

	_	A0-28-10 A0-28-09	5v 0v
NO 200		AO-28-10 AO-28-09	5v 0v
DP	1	AO-04-10	5v

PAGE TEST NO. VEHICLE

2) SIVB Stripouts:

CP 1 BO-28-10 5v CP 1 BO-28-09 0v DP 1 BO-28-10 5v DP 1 BO-28-09 0v

Starting and stopping of strip recorders will be commanded by SUTM.

- 3. IU/SIVB Telemetry will conduct test and monitor in Structure Measuring and DDAS areas.
- 4. DDAS will help visually monitor CALIBRATION ERROR INDICATIONS and the above named measurements as requested.
- 5. All G & C as specified under support required will be required.

  Approximate time on will be 2 to 3, 30-minute runs.
- 6. All IU/SIVB Telemetry and transmitters will be required for 2 to 3, 30-minute runs. (Open loop)
- 7. QCI and QCE will monitor test as required.
- 8. BURF Command System for 2 to 3, 30-minute runs.
- 9. Repeat Steps 1-7 for Run 2.

#### IV. OPERATING STEPS:

- 1. IU/SIVB stage power.
- 2. Start Structure Measuring stripouts, 5mm/per sec., and digital printouts as required.
- 3. Bring up G & C in the following order annotate:
  - 1) RGCC LVDA/LVDC
  - 2) RUPC 56 v power supply
  - 3) RUPC AC supply inverter
  - 4) RUPC ST-124
  - 5) RUFC Control Computer
  - 6) RUFC Control Rate Gyros, CSP

PAGE TEST NO. VEHICLE

4. Bring up the remaining IU/SIVB Telemetry Systems - Annotate:

IU:

1) F1 TM

ON

2) Dummy Load

ON

3) F1 RF

ON

4) P1 RF

ON

SIVB:

1) P1 RF

ON

- 5. Bring up Command System:
  - 1) BURF

Command Carrier ON

2) BURF

Receiver Decoder ON

- 6. Annotate stripouts as equipment is turned on and off.
- 7. SUTM-S4TM will notify CUTC, C4TC, CUNP, and C4NP to prepare for power transfer to Internal and report when ready. (Note: Power Transfer will be repeated as many times as necessary to secure sufficient data.)

### IU Checkpoints:

- 1) Stage Power
- 2) SUOT OAT Batteries Connected; full load capability.
- 3) RGCC Guidance Computer ON and ready for Power Transfer.
- 4) RUPC ST-124 System ON and ready for Power Transfer.
- 5) RUFC Flight Control ON and ready for Power Transfer.

#### SIVB Checkpoints:

- 1) Stage Power
- 2) Batteries connected in full load capability.
- 3) Recirculation Pumps Safe.
- 8. IU Power Transfer to INTERNAL on mark from CUNP or CUTC.
- 9. SIVB Power Transfer to INTERNAL on mark from C4NP or C4TC.
- 10. SUTM-S4TM will notify CUTC, C4TC, CUNP, and C4NP to prepare for

PAGE TEST NO. VEHICLE

power transfer to EXTERNAL power.

- 11. IU/SIVB Power Transfer to EXTERNAL on mark from CUNP and C4NP.
- 12. Bring Down Command System:
  - 1) BURF

Recorder Decoder

OFF

2) BURF

Command Carrier

OFF

13. Turn OFF IU/SIVB TM Systems:

IU:

1) P1 RF

OFF

2) F1 RF and F1 TM

OFF

3) Dummy Load

OFF

SIVB:

1) P1 RF

OFF

- 14. Turn OFF G & C in the following order annotate:
  - 1) RUFC

Control Rate Gyros/CSP.

2) RUFC

Control Computer

3) RUPC

ST-124

4) RUPC

56 v Power Supply

5) RUPC

AC Power Supply (Inverter)

6) RGCC

LVDA/LVDC

- 15. Bring down IU/SIVB Stage Power.
- 16. Reconfigure for Run #2.
- 17. Bring Up IU/SIVB Stage Power.
- 18. Breakout Boxes in for Run #2 Verify.
- 19. Install Jumpers and Remove Shorting Bars:

#### Jumpers:

- 1) J6 (602A3 Dist.) Dist. side to skin a, b, Z.
- 2) J6 (DP1 Mux. 602A446) pins E (+), B (com.) to Digital Voltmeter.
- 3) J18 (602A3 Dist.) Jumper pins E to N to P.

PAGE TEST NO. **VEHICLE** 

#### Shorting Bars OUT:

- 1) J6 (602A3 Dist.) pins  $\underline{a}$ ,  $\underline{b}$ , Z.
- 2) J13 (602A3 Dist.) pins M, P, S, U, W, Y,  $\underline{a}$ , and  $\underline{d}$ . 3) J18 (602A3 Dist.) pins E, N, and P.

- Adjust IU 5v Supply for 5v into DP 1 Mux. pins E (+), B (com.). 20.
- 21. Repeat Operating Steps 2 through 13.

#### V. SECURING STEPS:

- 1. Secure Stage Power (IU/SIVB).
- 2. Remove all breakout boxes and test equipment.
- 3. Return IU/SIVB to Flight Configuration.
- 4. Release all personnel.

#### VI. SPECIAL NOTES:

- 1. DAC needs 45 minutes notice prior to power down.
- 2. STEPS OF THIS PROCEDURE MAY BE OMITTED, REPEATED, OR INTERCHANGED UPON NOTICE FROM SUTM AND CONCURRENCE FROM CUTC AND/OR C4TC.

T17		The second secon	2. REV.	3. NUMBER	
TITLE			Z. REV.	3. NUMBER	2
			4. EFF.	5. DATE	6. NUMBER
PAGE	8. STEP	9.	CHANGE		
		-	4		
			7		
					9
			-	_	
			,		
		-0	1 6	3	
			_ 1		
4					
***************************************					
O. REA	SON FOR	CHANGE:			
1. PRE	PARED B	Y	12. NASA SYSTEM ENGR.	13. L/V TEST CONDUC	TOR

DATE: REVISION

#### PREPARATIONS - SIVB VEHICLE NETWORKS

- 1. Disconnect the following (Ref. 1B62349):
  - A. Aft. No. 1 Simulator (4D11) (Al or A2).

```
406W1P1 From 404A2A1J4
406W3P1 From 404 W15P13 (Cal.)
406W4P1 From 404W208P72 (TM)
404W15P14 From J1 (4D10)
```

B. Aft. No. 2 Simulator (4D41) (Al or A2).

```
406W1P1 From 404A45A1J4

406W3P1 From 404W15P10 (Cal.)

406W4P1 From 404W208P74 (TM)

404W15P9 From J2
```

C. Fwd Simulator (4D21 + 4D31) (A3).

```
406W2P1 From 411A99A10A1J4

406W3P1 From 411W17P11 (Cal)

406W4P1 From 411W205P17 (TM) (4D31)

406W5P1 From 411W17P12 (4D20)

406W6P1 From 411W17P13 (Cal.)

406W7P1 From 411W205P18 (TM) (4D20)

411W17P8 From J1
```

- 2. Install or verify installed shunt boxes (Ref. 1B62355-New):
  - A. +4D10 Shunt Box (1615)

404W15P14 to J1 404W208P72 to J2 404W15P13 to J3 173A3W8P2 to J5 1579W3P2 to J6

B. +4D20 Shunt Box (1577)

411W17P12 to J1 411W205P18 to J2 411W17P13 to J3 173A4W3P2 to J5 1577W1P1 to J6

C. +4D30 Shunt Box (1616)

411W17P8 to J1 411W205P16 to J2 411W17P9 to J3 173A4W4P2 to J5 1577W1P2 to J6 411W3P1 to J7 1616W1P1 to J8

```
D. +4D40 Shunt Box (1579)
```

404W15P9 to J1 404W208P74 to J2 404W15P10 to J3 173A3W9P2 to J5 1579W3P1 to J6

- 3. Connect or Verify Connected:
  - A. Fwd J-Box (1587)

173A4W1P2 to J1 1587W1P1 to J2 1587W2P1 to J3 1587W4P1 to J6 DM2 (Diode Mod.) to J7

B. Aft. J-Box (1493)

173A3W1P2 to J1 173A3W3P2 to J2 173A3W4P2 to J3 1493W9P1 to J7 1493W3P1 to J8 1493W6P1 to J9 1493W4P1 to J11 1493W8P1 to J15 DM1 (Diode Mod.) to J16

- 4. Disconnect or Verify Disconnected:
  - A. AFT

404W7P9 from 404A74A2J1 (LH Recir. INV Input) 404W7P10 from 404A74A1J1 (Lox Recirc. INV Input) 403W3P2 from 403B1J1 (Hyd. Pump)

- 5. Connect or Verify Connected:
  - A. Silo Plates
    - 1) Fwd (173A4)

173A4W1P1 to J25 173A4W5P1 to J26 173A4W3P1 to J27 173A4W4P1 to J28

2) Aft (173A3)

173A3W1P1 to J3 173A3W10P1 to J10 173A3W8P1 to J11 173A3W9P1 to J12 173A3W3P1 to J27 173A3W4P1 to J28

6. Cable to Cable (Connect or verify connected):

1587W4P2 to 1494W15P1 1493W4P2 to 1494W12P1 1579W3P3 to 173A3W10P2 1577W1P3 to 173A4W5P2 1494W12P2 to 404W203P27 1494W12P3 to 404W7J9 1494W12P4 to 404A2J3 404W7J2 to 416W2P1 404W7J4 to 417W2P1 404W7J6 to 418W2P1 1494W19P2 to 411W3P2 1494W19P1 to 411W17P10 1493W8P2 to 404A2J19 1493W8P3 to 404W7P4 1493W3P2 to 404A45J3 1587W2P2 to 411A99A1053 1616W1P2 to 411W205P17

- 7. SIVB Power Application
  - A. C4ES obtain clearance from C4TC, then apply SIVB power per DAC procedure, I-21042-SIVB6 1B62242. Report when complete.
- 8. SIVB OAT Room (152' level)

S40T (Switch Module Panel)

- A. Verify all switches are in the down position except S-43 in up position.
- B. S40T verify circuit breakers on:

1270A1A4-1 1270A1A4-6 1270A2A6-2 1270A1A4-4

- C. Switch 1465S2 (+23D213) ON 1465S1 (+4D114) ON
- D. Verify knife switches in OAT Battery Room are set. Observe battery voltage indications on battery monitor panels.
- E. Verify event and E & I recorders in operating condition.
- F. Event and E & I recorders AC, DC and chart drive switches ON.
- G. R4HY Inflt. Mode SW to auto.

PAGE TEST NO. VEHICLE

H. S40T turn +4D10, +4D20, +4D30, +4D40 battery power on.

#### POST TEST OPERATIONS SIVB

1. Disconnect the following & Verify when complete:

(C4TC S4CE)

A. +4D10 Shunt Box (1615)

404W15P14 to J1 404W208P72 to J2 404W15P13 to J3 173A3W8P2 to J5 1579W3P2 to J6

B. +4D20 Shunt Box (1577)

411W17P12 to J1 411W205P18 to J2 411W17P13 to J3 173A4W3P2 to J5 1577W1P1 to J6

C. +4D30 Shunt Box (1616)

411W17P8 to J1 411W205P16 to J2 411W17P9 to J3 173A4W4P2 to J5 1577W1P2 to J6 411W3P1 to J7 1616W1P1 to J8

D. +4D40 Shunt Box (1579)

404W15P9 to J1 404W208P74 to J2 404W15P10 to J3 173A3W9P2 to J5 1579W3P1 to J6

- E. Cable to Cable disconnect 1616W1P2 from 411W205P17.
- F. Remove shunt Boxes (Ref. 1B62355)
- 2. Install or Verify installed battery simulator boxes (Ref. 1B62349)
  Note: Aft Unit Al may be temporarily suspended. (C4TC S4CE)
- 3. Connect the following & Verify when complete:

(C4TC S4CE)

A. Aft No. 1 simulator (4D11) (Al or A2)

406W1P1 to 404A2A1J4 406W3P1 to 404W15P13 (Cal)

PAGE TEST NO. VEHICLE

406W4P1 to 404W208P72 (TM) 404W15P14 to J1 (4D10)

B. Aft No. 2 simulator (4D41) (Al or A2)

406W1P1 to 404A45A1J4 406W3P1 to 404W15P10 (Ca1) 406W4P1 to 404W208P74 (TM) 404W15P9 to J2

C. Fwd simulator (4D21 & 4D31) (A3)

406W2P1 to 411A99A10A1J4 406W3P1 to 411W17P11 (CAL) 406W4P1 to 411W205P17 (TM) (4D31) 406W5P1 to 411W17P12 (4D20) 406W6P1 to 411W17P13 (CAL) 406W7P1 to 411W205P18 (TM) (4D20) 411W17P8 to J1