

(b) *Foundation requirements.* You must provide information to show that site-specific soil and oceanographic conditions are capable of supporting the proposed drilling unit. If you provided sufficient site-specific information in your EP, DPP, or DOCD, you may reference that information. The District Supervisor may require you to conduct additional surveys and soil borings before approving the APD if additional information is needed to make a determination that the conditions are capable of supporting the drilling unit.

(c) *Frontier areas.* (1) If the design of the drilling unit you plan to use in a frontier area is unique or has not been proven for use in the proposed environment, the District Supervisor may require you to submit a third-party review of the unit's design. If required, you must obtain the third-party review according to § 250.903. You may submit this information before submitting an APD.

(2) If you plan to drill in a frontier area, you must have a contingency plan that addresses design and operating limitations of the drilling unit. Your plan must identify the actions necessary to maintain safety and prevent damage to the environment. Actions must include the suspension, curtailment, or modification of drilling or rig operations to remedy various operational or environmental situations (e.g. vessel motion, riser offset, anchor tensions, wind speed, wave height, currents, icing or ice-loading, settling, tilt or lateral movement, resupply capability).

(d) *U.S. Coast Guard (USCG) Documentation.* You must provide the current Certificate of Inspection or Letter of Compliance from the USCG. You must also provide current documentation of any operational limitations imposed by an appropriate classification society.

(e) *Floating drilling unit.* If you use a floating drilling unit, you must indicate that you have a contingency plan for moving off location in an emergency situation.

(f) *Inspection of unit.* The drilling unit must be available for inspection by the District Supervisor before commencing operations.

(g) Once the District Supervisor has approved a MODU for use, you do not need to re-submit the information required by this section for another APD to use the same MODU unless changes in equipment affect its rated capacity to operate in the District.

§ 250.418 What additional information must I submit with my APD?

You must include the following with the APD:

(a) Rated capacities of the drilling rig and major drilling equipment, if not already on file with the appropriate District office;

(b) A drilling fluids program that includes the minimum quantities of drilling fluids and drilling fluid materials, including weight materials, to be kept at the site;

(c) A proposed directional plot if the well is to be directionally drilled;

(d) A Hydrogen Sulfide Contingency Plan (see § 250.490), if applicable, and not previously submitted;

(e) A welding plan (see §§ 250.109 to 250.113) if not previously submitted;

(f) In areas subject to subfreezing conditions, evidence that the drilling equipment, BOP systems and components, diverter systems, and other associated equipment and materials are suitable for operating under such conditions;

(g) A request for approval if you plan to wash out or displace some cement to facilitate casing removal upon well abandonment; and

(h) Such other information as the District Supervisor may require.

Casing and Cementing Requirements

§ 250.420 What well casing and cementing requirements must I meet?

You must case and cement all wells. Your casing and cementing programs must meet the requirements of this section and of §§ 250.421 through 250.428.

(a) *Casing and cementing program requirements.* Your casing and cementing programs must:

(1) Properly control formation pressures and fluids;

(2) Prevent the direct or indirect release of fluids from any stratum through the wellbore into offshore waters;

(3) Prevent communication between separate hydrocarbon-bearing strata;

(4) Protect freshwater aquifers from contamination; and

(5) Support unconsolidated sediments.

(b) *Casing requirements.* (1) You must design casing (including liners) to withstand the anticipated stresses imposed by tensile, compressive, and buckling loads; burst and collapse pressures; thermal effects; and combinations thereof.

(2) The casing design must include safety measures that ensure well control during drilling and safe operations during the life of the well.

(c) *Cementing requirements.* You must design and conduct your cementing jobs so that cement composition, placement techniques, and waiting times ensure that the cement placed behind the bottom 500 feet of casing attains a minimum compressive strength of 500 psi before drilling out of the casing or before commencing completion operations.

§ 250.421 What are the casing and cementing requirements by type of casing string?

The table in this section identifies specific design, setting, and cementing requirements for casing strings and liners. For the purposes of subpart D, the casing strings in order of normal installation are as follows: drive or structural, conductor, surface, intermediate, and production casings (including liners). The District Supervisor may approve or prescribe other casing and cementing requirements where appropriate.

Casing type	Casing requirements	Cementing requirements
(a) Drive or Structural	Set by driving, jetting, or drilling to the minimum depth as approved or prescribed by the District Supervisor.	If you drilled a portion of this hole, you must use enough cement to fill the annular space back to the mudline.
(b) Conductor	Design casing and select setting depths based on relevant engineering and geologic factors. These factors include the presence or absence of hydrocarbons, potential hazards, and water depths. Set casing immediately before drilling into formations known to contain oil or gas. If you encounter oil or gas or unexpected formation pressure before the planned casing point, you must set casing immediately	Use enough cement to fill the calculated annular space back to the mudline. Verify annular fill by observing cement returns. If you cannot observe cement returns, use additional cement to ensure fill-back to the mudline. For drilling on an artificial island or when using a glory hole, you must discuss the cement fill level with the District Supervisor.