
















73





HEATER POWER, ENGINE 101
(TYPICAL ENGINES 1-5)




IGNITER CIRCUIT




IGNITER CIRCUIT




SEE PAGE 2





*THESE TIMES ARE NOMINAL TIMES ONLY.
REFER TO SK60B57201, PAGE 68.



START SEQUENCE




LAUNCH COMMIT





LIFTOFF

THRUST OK PRESSURE SWITCH C/O SYSTEM




FUEL DEPLETION SENSORS C/O






LOX LEVEL CUTOFF SENSORS




ENGINE CUTOFF LOGIC



(B) TO OTHER 4 ENGINES C/O RELAYS

SEE PAGE 6



SEE PAGE 8

CLUTCH

