

APOLLO GUIDANCE COMPUTER

FIXED MEMORY BANK REGISTER

F11-F16 BANK	EXT	F. BANK	F11-F16 BANK	EXT	F. BANK
00	X	00	22	X	22
01	X	01	23	X	23
02	X	02	24	X	24
03	X	03	25	X	25
04	X	04	26	X	26
05	X	05	27	X	27
06	X	06	30	0	30
07	X	07	31	0	31
10	X	10	32	0	32
11	X	11	33	0	33
12	X	12	34	0	34
13	X	13	35	0	35
14	X	14	36	0	36
15	X	15	37	0	37
16	X	16	40	4	30
17	X	17	41	4	31
20	X	20	42	4	32
21	X	21	43	4	33

TO BE USED WITH TABLE ON REVERSE SIDE

APOLLO GUIDANCE COMPUTER

FIXED MEMORY STRAND SELECT SIGNALS

ROPE T		ROPE S		ROPE R		STR	STR	
HIMOD	LOMOD	HIMOD	LOMOD	HIMOD	LOMOD			
36,2000-2777	30,2000-2777	22,2000-2777	14,2000-2777	06,2000-2777	00,2000-2777	01	19	STR 14
36,3000-3777	30,3000-3777	22,3000-3777	14,3000-3777	06,3000-3777	00,3000-3777	02	210	
37,2000-2777	31,2000-2777	23,2000-2777	15,2000-2777	07,2000-2777	01,2000-2777	03	311	
37,3000-3777	31,3000-3777	23,3000-3777	15,3000-3777	07,3000-3777	01,3000-3777	04	412	
40,2000-2777	32,2000-2777	24,2000-2777	16,2000-2777	10,2000-2777	4000-4777 02,2000-2777	05	19	STR 58
40,3000-3777	32,3000-3777	24,3000-3777	16,3000-3777	10,3000-3777	5000-5777 02,3000-3777	06	210	
41,2000-2777	33,2000-2777	25,2000-2777	17,2000-2777	11,2000-2777	6000-6777 03,2000-2777	07	311	
41,3000-3777	33,3000-3777	25,3000-3777	17,3000-3777	11,3000-3777	7000-7777 03,3000-3777	08	412	
42,2000-2777	34,2000-2777	26,2000-2777	20,2000-2777	12,2000-2777	04,2000-2777	09	19	STR 912
42,3000-3777	34,3000-3777	26,3000-3777	20,3000-3777	12,3000-3777	04,3000-3777	10	210	
43,2000-2777	35,2000-2777	27,2000-2777	21,2000-2777	13,2000-2777	05,2000-2777	11	311	
43,3000-3777	35,3000-3777	27,3000-3777	21,3000-3777	13,3000-3777	05,3000-3777	12	412	

BANK SHOWN IN TABLE IS VALUE OF
F11 - F16. CONTENTS OF F BANK AND
TEXT GIVEN ON REVERSE SIDE

NOTE: S = 4000-4777 ⇒ 02,2000-2777
5000-5777 ⇒ 02,3000-3777
6000-6777 ⇒ 03,2000-2777
7000-7777 ⇒ 03,3000-3777

RAYTHEON COMPANY
SPACE AND INFORMATION SYSTEMS DIVISION
SYSTEMS SUPPORT TRAINING

RAYTHEON