



NATIONAL AERONAUTICS AND SPACE ADMINISTRATION

APOLLO 17  
MISSION J-3


FINAL

**CSM  
RENDEZVOUS  
PROCEDURES**

PREPARED BY

CSM RENDEZVOUS PROCEDURES GROUP  
MCDONNELL DOUGLAS ASTRONAUTICS COMPANY  
HOUSTON OPERATIONS

MANNED SPACECRAFT CENTER  
HOUSTON, TEXAS



6 NOV 1972

---

PROJECT APOLLO  
CSM RENDEZVOUS PROCEDURES  
MISSION J-3, APOLLO 17, CSM 114

---

6 November 1972

PREPARED FOR  
CREW PROCEDURES DIVISION  
NATIONAL AERONAUTICS AND SPACE ADMINISTRATION  
MANNED SPACECRAFT CENTER  
HOUSTON, TEXAS

APPROVED: Donald W. Lewis  
Donald W. Lewis  
NASA Technical Manager

APPROVED: J. W. BiTodeau  
J. W. BiTodeau  
Chief, Crew Procedures Division

APPROVED: D. K. Slayton  
Donald K. Slayton  
Chairman, Crew Procedures Control Board

TABLE OF CONTENTS

1.0	INTRODUCTION . . . . .	1
2.0	CMP NOMINAL RENDEZVOUS PROCEDURES . . . . .	2
2.1	MISSION PLAN . . . . .	2
2.2	NOMINAL PROCEDURES RATIONALE . . . . .	6
2.3	DETAILED PROCEDURES . . . . .	13
3.0	CMP ABORT RENDEZVOUS PROCEDURES . . . . .	42
3.1	ABORT PLAN . . . . .	42
3.1.1	RENDEZVOUS TECHNIQUES . . . . .	42
3.1.2	ABORT POINTS . . . . .	44
3.2	ABORT PROCEDURES RATIONALE . . . . .	48
3.3	DETAILED PROCEDURES . . . . .	50
3.3.1	TWO REV SEQUENCE . . . . .	50
3.3.2	ONE REV SEQUENCE . . . . .	61
3.3.3	COMMON COELLIPTIC SEQUENCE . . . . .	66
4.0	CMP SUPPLEMENTARY PROCEDURES . . . . .	98
4.1	PLANE CHANGE BURNS . . . . .	98
4.1.1	RCS PLANE CHANGE . . . . .	98
4.1.2	SPS PLANE CHANGE . . . . .	101
4.2	CSM ACTIVE BURNS . . . . .	109
4.2.1	TPI BURN . . . . .	109
4.2.2	MCC BURN . . . . .	115
4.2.3	PRE-BRAKING SPS BURN . . . . .	117
4.2.4	BRAKING . . . . .	128
5.0	ACRONYMS AND ABBREVIATIONS . . . . .	133
6.0	REFERENCES . . . . .	139
APPENDIX A - CMP RENDEZVOUS NAVIGATION SCHEDULES		
APPENDIX B - CSM ATTITUDE REQUIREMENT FOR THE NOMINAL APOLLO 17 RENDEZVOUS		
APPENDIX C - CMP INTERFACE REQUIREMENTS FOR THE NOMINAL APOLLO 17 RENDEZVOUS		
APPENDIX D - FLIGHT DATA FILE NOMINAL RENDEZVOUS PROCEDURES		
APPENDIX E - FLIGHT DATA FILE ABORT AND RESCUE RENDEZVOUS PROCEDURES		

## 1.0 INTRODUCTION

The purpose of the CSM Rendezvous Procedures Document is to provide a single source of CSM Guidance and Navigation procedures information to be used in flight planning, crew training, and in preparing onboard data for the nominal and abort CSM/LM Apollo 17 rendezvous.

The procedures presented in this document are for the third J mission which will be flown with the CSM 114 spacecraft. Trajectory dependent information contained in this document is based on the prime launch date of 7 December 1972 (GMT) and a LM lunar lift-off GET of 188:03:14.6.

Five appendices are contained in this document. They contain information which is of special interest for purposes of training, analysis or CSM interface discussion. Also included are the CSM onboard data as used during the nominal rendezvous and in case of LM abort.

This is a control document, subject to review by all elements of the Apollo Program and approval by the Crew Procedures Control Board. All comments, suggestions or questions concerning this document should be directed to D. C. Wammack, CSM Rendezvous Procedures Group, McDonnell Douglas Astronautics Company, phone 483-3433.

## 2.0 CMP NOMINAL RENDEZVOUS PROCEDURES

The G&N procedures employed by the Command Module Pilot during the Apollo 17 nominal rendezvous are presented in this section. These procedures are divided into groups of congruous operations called Steps.

The mission plan is discussed in subsection 2.1; the rendezvous Steps are listed and the purpose of each Step is discussed in subsection 2.2; and the detailed procedures for performing each Step are presented in subsection 2.3.

### 2.1 MISSION PLAN

The Command Module Pilot is scheduled to begin preparations for rendezvous approximately two hours prior to LM lift-off when he maneuvers the CSM to the COAS calibration attitude. The rendezvous is completed approximately two hours after lift-off when all docking activities are completed. The nominal GET for each major event during this period is listed below:

BEGIN RNDZ PREPARATION	186:10:00
LM LIFT-OFF	188:03:14.6
LM INSERTION	188:10:32.3
LM TPI	188:57:32.3
LM TPF	189:40:28.1
DOCKING	190:05:00

The Apollo 17 nominal rendezvous will utilize the Direct Ascent rendezvous technique which was first employed by Apollo 14. This two-impulse technique requires 90 minutes from LM insertion to LM/CSM station-keeping. The LM is scheduled to apply the TPI burn 47 minutes after insertion and to apply the graduated braking burns approximately 130° of orbital travel after TPI. Two nominally zero DV midcourse corrections are scheduled at

15-minute intervals after TPI. These burns adjust the relative trajectory between the two vehicles in case post-TPI trajectory dispersions exist. All post-insertion burns will be applied by the CSM if the LM is unable to apply them. The CSM will perform the rendezvous with a roll of 180°.

Although Apollo 17 will utilize the same rendezvous technique as used for Apollo 16, several procedural changes have been made. The major changes affecting the CMP are listed below:

- A. The CMP will not attempt to take sextant marks prior to the darkness interval following LM insertion.
- B. An uplink of the CMC LM state vector after insertion is scheduled to be performed. This uplink will be over an OMNI antenna instead of the high gain antenna.
- C. A TPI recycle will be performed.
- D. A one-half degree deadband will be used for tracking.

Orbital motion and relative motion plots for the nominal Apollo 17 rendezvous are contained in Figures (1) and (2). The orbital motion plot presents the CSM and LM inertial positions at each burn during the rendezvous. The relative motion plot presents the CSM position at each burn and major CSM event in a curvilinear coordinate system referenced to the LM.




FIGURE 1. POST-INSERTION ORBITAL MOTION PLOT FOR  
THE DIRECT ASCENT RENDEZVOUS




FIGURE 2. POST-INSERTION RELATIVE MOTION PLOT FOR THE DIRECT ASCENT RENDEZVOUS

## 2.2 NOMINAL PROCEDURES RATIONALE

This subsection presents the purpose and any constraints considered for each rendezvous Step. Only the CMC procedures for the nominal rendezvous are considered.

- STEP 1     Reconfigure DAP. The DAP is reconfigured to provide a faster rate for DAP attitude maneuvers. The DAP is assumed to be configured for narrow deadband at this time.
- STEP 2     Maneuver to COAS Calibration Attitude. The maneuver to this attitude will center a star in the COAS in preparation for COAS alignment calibration. This attitude will allow HGA coverage and also position the CSM for the IMU alignment option of P52.
- STEP 3     Acquire STDN with HGA. The HGA is necessary to establish communication with the STDN in order to receive an uplink of state vectors and a rendezvous information update.
- STEP 4     Accept STDN Uplink and Copy Update. A predicted CSM state vector at lift-off based on ground tracking is uplinked to improve the CMC knowledge of the CSM state vector. The predicted LM state vector at insertion +5 minutes is uplinked to furnish the CMC with a LM state vector valid after insertion. The Surface Flag Reset command is uplinked to allow CMC use of the LM state vector while the LM is still on the surface.

The pads for both the Direct Ascent and Coelliptic rendezvous are supplied by MCC-H so that the CMC pre-thrust program(s) may be initialized. The CSM weight is supplied so that the DAP's estimate of

the weight may be updated to include expended RCS propellant.

The ground supplies the predicted CSM and LM state vector at insertion +1 minute in case the CMC's knowledge of the state vectors is degraded and there is no communication between the CSM and MCC-H.

The CSM consumables status is also relayed to the CMP. If required, the consumables pad will be updated.

- STEP 5     Realign IMU. The IMU must be periodically fine-aligned in order to provide an accurate attitude reference for navigation computations and burn maneuvers.
- STEP 6     Calibrate COAS. The COAS alignment must be calibrated in case COAS marking is required due to a sextant failure.
- STEP 7     Align GDC. The GDC is aligned as a standard procedure after P52 completion to provide a backup attitude reference.
- STEP 8     Verify DSE Tape Motion. The data storage equipment operation should be checked to assure the acquisition of systems data while the CSM is behind the moon. The S-Band relay is activated at this time.
- STEP 9     Acquire STDN with HGA. HGA coverage is necessary to downlink the DSE record at a high bit rate.
- STEP 10    Load CSM and LM Weights. The DAP's knowledge of the CSM weight is updated to include expended RCS propellant. The DAP's knowledge of the LM weight is updated to the predicted LM weight at docking.

- STEP 11 Maneuver to Post-Insertion Track Attitude. The CSM maneuvers to this attitude in order to be prepared for LM tracking after insertion. This attitude does not allow HGA coverage, therefore the post-insertion uplink will be performed using an OMNI.
- STEP 12 Configure VHF and EMS for Ranging. The VHF system and EMS should be configured for ranging during the rendezvous. They should be in this configuration prior to lift-off.
- STEP 13 Configure Rendezvous Lights. The CSM exterior rendezvous lights should be activated so that the CDR may boresight the CSM in the AOT during darkness if the RR fails. The CSM running lights should be activated prior to TPF so that the CDR may visually determine the CSM attitude during docking.
- STEP 14 Align GDC. The GDC is aligned to the IMU prior to lift-off to provide an accurate backup attitude reference during rendezvous.
- STEP 15 Initiate VHF Ranging. VHF ranging is necessary after LM insertion to monitor range between the CSM and LM and to allow ranging navigation marks to be taken.
- STEP 16 Accept STDN Uplink. The LM state vector must be uplinked to the CSM to furnish the CMC with a better estimate of LM state after insertion.
- STEP 17 Initiate P34 and Rendezvous Navigation. The TPI pre-thrust program is entered in order to accomplish the following:
- A. Initiate P20

- B. Initiate the automatic rendezvous program sequence (MINKEY).
- C. Initialize the program for the recycle.
- D. Display the time until TPI.
- E. Initiate VHF marking.
- F. Display the number of sextant and VHF marks taken.

The CSM attitude is within  $10^{\circ}$  of the preferred track attitude so that only a trim maneuver is required to start rate tracking.

Sextant marking is started when the LM enters darkness.

- STEP 18    Compute P34 Recycle. The TPI burn components are computed to verify the convergence of the solution and for comparison with the LGC solution.
- STEP 19    Compute TPI Solution and Terminate Nav. The TPI burn components are computed and supplied to the CDR to be biased and compared with the LGC solution. The burn solution is also used by P40 for a possible CSM active TPI burn. The final comp terminates rendezvous navigation until after TPI.
- STEP 20    Backup LM TPI Burn. The CSM is maneuvered to the TPI burn attitude and is configured to perform the TPI burn in the event the LM cannot apply it.  
  
The data storage equipment operation should be checked during this period to assure the acquisition of systems data while the CSM is behind the moon.

- STEP 21 Update LM S.V. in the CMC. The CMC's knowledge of the LM state vector should be updated to include the LM TPI burn in order to minimize excessive updates during the next navigation period.
- STEP 22 Initiate P35 and Rendezvous Navigation. The MCC pre-thrust program is entered at this time in order to:
- A. Initiate LM tracking
  - B. Initiate VHF and sextant marking on the LM
  - C. Display the time since TPI
  - D. Display the number of sextant and VHF marks taken
- STEP 23 Compute MCC-1 Solution and Terminate Navigation. The computed MCC solution is supplied to the CDR for a CMC and LGC solution comparison. The solution is also necessary in order for the CMP to back up the burn. MCC-1 is scheduled for TPI+15 minutes, so final comp initiation should be at TPI+12 minutes. The final comp terminates rendezvous navigation until after MCC-1.
- STEP 24 Backup LM MCC-1 Burn. In the event the LM cannot apply the MCC-1 burn, it should be applied by the CSM to refine the intercept trajectory.
- STEP 25 Update LM S.V. in the CMC. If the LM applies MCC-1, the CMC's knowledge of the LM state vector should be updated to include the burn in order to minimize excessive updates during the next navigation period.
- STEP 26 Initiate P35 and Rendezvous Navigation. The MCC pre-thrust program is entered at this time in order to:

- A. Initiate LM tracking
  - B. Initiate VHF and sextant marking on the LM
  - C. Display the time since MCC-1
  - D. Display the number of sextant and VHF marks taken
- STEP 27 Compute MCC-2 Solution and Terminate Navigation. The computed MCC solution is supplied to the CDR for a CMC and LGC solution comparison. The solution is also necessary in order for the CMP to backup the burn. MCC-2 is scheduled for TPI+30 minutes so final comp initiation should be at TPI+27 minutes. The final comp terminates rendezvous navigation.
- STEP 28 Backup LM MCC-2 Burn. In the event the LM cannot apply the MCC-2 burn, it should be applied by the CSM to refine the intercept trajectory.
- STEP 29 Update LM S.V. in the CMC. If the LM applies MCC-2, the CMC's knowledge of the LM state vector should be updated to include the burn to provide accurate CMC range and range rate information.
- STEP 30 Maneuver to COAS Track Attitude. The CMP must monitor line-of-sight rate in order to backup the LM during braking. P79 is terminated; V49 uses the attitude calculated by P79.
- STEP 31 Perform Docking Preparation Activities. These operations include configuring switches for docking and initiating LM photography.
- STEP 32 Acquire STDN with HGA. Ground communication is necessary to arm the pyros, for television transmission, and for the ground to monitor the docking.

- STEP 33    Perform TPF Activities and Photograph LM. These activities include configuring switches for post-TPF conditions and photographing the LM.
- STEP 34    Maneuver for CSM Inspection. A maneuver is scheduled so that the CDR may observe the condition of the CSM SIM Bay. CMP communication with MCC-H is temporarily suspended.
- STEP 35    Maneuver to Docking Attitude. The CSM must maneuver to an attitude favorable for docking. HGA coverage is reacquired.
- STEP 36    Arm Pyros. The pyros must be armed in order to retract the docking probe. The status of the SECS LOGIC and SECS PYRO ARM switches must be obtained from the ground since there is no onboard indication of their positions.
- STEP 37    Perform Docking Activities. These operations are necessary in order to capture the LM latch and achieve hard docking. After docking is confirmed, the docking checklist is performed.
- STEP 38    Reconfigure DAP. The DAP is reloaded to specify the docked CSM/LM configuration.
- STEP 39    Configure Switches for Post-Docking. Spacecraft control is returned to the CMC after docking.

### 2.3 DETAILED PROCEDURES

The detailed procedures for the LM active nominal rendezvous are contained in this subsection. If the CSM is required to become active during the rendezvous, the supplementary detailed procedures presented in section 4.0 will be used.

These detailed procedures basically consider only the G&N requirements, although some non-G&N procedures are included for purposes of information and continuity.

Detailed procedures specify each change in the switch settings and the sequential changes in the DSKY displays.

The format of the detailed procedures is tabular. The GET column specifies the time associated with each Step and each time-critical event. Approximate times are indicated by an entry to the nearest minute (e.g., 186:10:XX) or by reference to the nearest minute to a time-critical event (e.g., TPI-10 MIN). Exact times are specified to the nearest second (e.g., 186:27:53). The LTNG column indicates the CSM in daylight (blank) or darkness (black), and the STDN column indicates the CSM has STDN coverage (dashed) or no STDN coverage (blank).

The OPERATIONS column lists the Step and substep headings, which are underlined, and the set of operations necessary to complete each Step. The DSKY keystroke operations are left-justified and the switch-setting operations are indented. When a switch position is not specifically labeled on the panel, the position is specified as (CTR), (UP), or (DOWN). The panel on which each switch is located is shown in the STA/PANEL column.

The PROG, V-N DISPLAY and REGISTER DISPLAYS columns specify the status of the DSKY display. Entries into these columns are made for all changes of the Verbs, Nouns, or Programs

and the associated values in the three registers. Blanks in any individual digits are indicated by the letter "B". If a complete register is blank, it is omitted and only the remaining non-blank registers are shown. If the contents of any register display are known, the nominal design data are shown with the proper decimal place; if the contents are unknown, X's with the proper decimal place are shown.

The COMMENTS column contains supplemental information in order to clarify the procedures or indicate contingency options. All register display contents and information passed by the STDN updates are defined. Additional STDN or LM operations which involve the CMP and some internal computer routines (e.g., average-G) are noted. Information concerning marking schedules, AOS, LOS, and other events are provided for completeness.

The nominal detailed procedures begin 186 hours 10 minutes into the mission and continue through the post-docking switch configuration at 190 hours 08 minutes.

These procedures are presented in pages 15 through 41, with the first three and one-half pages containing assumed initial switch settings.

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<u>ASSUMED SWITCH SETTINGS:</u> THC-LOCKED RHC 1-LOCKED RHC 2-LOCKED  EMS FUNCTION-OFF MODE-STBY CMC ATT-IMU FDAI SCALE-5/1 SELECT-1/2 SOURCE-ATT SET ATT SET-GDC MANUAL ATTITUDE(3)-RATE CMD LIMIT CYCLE-OFF ATT DEADBAND-MAX RATE-LOW TRANS CONTR PWR-OFF ROT CONTR PWR NORMAL 1-OFF 2-AC/DC DIRECT(BOTH)-OFF  SC CONT-CMC CMC MODE-AUTO BMAG MODE(3)-RATE 2 SPS THRUST DIRECT-NORMAL DV THRUST(2)-OFF SCS TVC(2)-RATE CMD SPS GIMBAL MOTORS(4)-OFF DV CG-CSM IMU CAGE-OFF ENTRY EMS ROLL-OFF ENTRY .05G-OFF LV/SPS IND -PC LV/SPS IND SII/SIVB-GPI TVC GMBL DRIVE(BOTH)-AUTO					



GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p>G/N PWR-AC1          MAIN BUS TIE(2)-OFF          NONESS BUS-OFF          CB GUIDANCE/NAVIGATION(10)-CLOSED</p> <p>SCS TVC SERVO POWER(BOTH)-OFF          FDAI/GPI POWER-BOTH          LOGIC POWER 2/3-ON(UP)          SCS ELECTRONICS POWER-GDC/ECA          SIG CONDR/DRIVER BIAS PWR(BOTH)-AC1          BMAG POWER(BOTH)-ON</p> <p>AUTO RCS SELECT(16)-MNA/MNB          EXCEPT: ROLL(4)-OFF          SEQ EVENTS CONT SYSTEM LOGIC(BOTH)-OFF          PYRO ARM(BOTH)-SAFE</p> <p>ALL CB-CLOSED          EXCEPT:          DIRECT ULL(2)-OPEN          REACTION CONTROL SYSTEM RCS          LOGIC(2)-OPEN          DOCK PROBE(2)-OPEN          SPS PITCH 1 AND YAW 1-OPEN          FLOAT BAG(3)-OPEN          SEQ EVENTS CONT SYS (4)-OPEN          ELS/CM-SM SEP(2)-OPEN          PL VENT FLT/PL-OPEN</p> <p>VHF AM T/R-RCV          VHF RNG-NORM</p> <p>FDAI 1-INRTL          FDAI 2-INRTL          EARTH/LUNAR-LUNAR          ALT SET-60 NM          MODE-OPR/SLOW</p> <p>COAS POWER-ON(UP)          UTILITY POWER-ON(UP)</p>				5 5 5 5 7 7 7 7 7 7 8 8 8 8 8 8 8 8 8 8 9 9 13 13 13 13 13 15 15	

GET H:M:S	L G	S T N D G	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					G/N POWER(2)-ON(UP) RNDZ XPNDR-HEATER  OPTICS ZERO-ZERO TEL TRUN-SLAVE TO SXT COUPLING-RSLV MODE-CMC SPEED-LO CONDITION LAMPS-ON UP TELEMETRY-ACCEPT  CB HI GAIN ANT(BOTH)-CLOSED  ALL CB-CLOSED EXCEPT: MAIN RELEASE(2)-OPEN				100 100  122 122 122 122 122 122 122 122  225  229 229	

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
186:10:XX	[REDACTED]	01	POO		<u>RECONFIGURE DAP</u> V48E	F 04 46	11101 X1111		R1-DAP CONFIGURATION R2-DAP CONFIGURATION
					V21E 11102E  PRO  PRO  PRO	F 04 46  F 06 47  F 06 48	11102 X1111  +36844 +XXXXXX.  +000.43 +001.02		R1-CSM WEIGHT (LBS) R2-LM WEIGHT (LBS)  R1-GIMBAL PITCH TRIM(DEG) R2-GIMBAL YAW TRIM(DEG)
186:12:XX	[REDACTED]	02	POO		<u>MANEUVER TO COAS CALIB ATTITUDE</u> V49E	F 06 22	+XXX.XX +XXX.XX +XXX.XX		R1-DESIRED ICDU ANG; ROLL(DEG) R2-DESIRED ICDU ANG; PITCH(DEG) R3-DESIRED ICDU ANG; YAW(DEG)
					V25E +18000E +24400E +34100E  PRO  PRO	F 06 22  F 50 18  06 18	+180.00 +244.00 +341.00  +180.00 +244.00 +341.00  +180.00 +244.00 +341.00		R1-AUTO ATT MNVR; ROLL(DEG) R2-AUTO ATT MNVR; PITCH(DEG) R3-AUTO ATT MNVR; YAW(DEG)
					MONITOR MANEUVER	F 50 18	+180.00 +244.00 +341.00		
					ENTER	BB BB			

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
186:18:XX			03	P00	ACQUIRE STDN WITH HGA V64E	F 06 51	-058.XX +052.XX		R1-HGA ANG; RHO(DEG) R2-HGA ANG; GAMMA(DEG)
					HIGH GAIN ANTENNA TRACK-MAN HGA PITCH POSITION-SET PITCH POSITION HGA YAW POSITION-SET YAW POSITION S BAND ANTENNA-HI GAIN HIGH GAIN ANTENNA TRACK-AUTO	BB BB		2 2 2 3 2	RHO=-58 GAMMA=+52
186:21:XX			04	P00	ACCEPT STDN UPLINK AND COPY UPDATE				
				P27	UP TLM CM-ACCEPT VERIFY UPLINK ACTIVITY LT-ON	XX XX	XXXXX XXXXX XXXXX	2	UPLINK ACT LT-ON
					MONITOR UPLINK				LM S.V.(INS+5) CSM S.V.(L/O) RESET SURFACE FLAG CONSUMABLES(IF REQ'D) CSM S.V. (L/O) ASCENT PADS CSM WEIGHT
				P00	COPY UPDATE	BB BB		2	UPLINK ACT LT-OFF
					VERIFY UPLINK ACTIVITY LT-OFF				
					UP TLM CM-BLOCK				
186:27:53			05	P00	REALIGN IMU V37E 52E	F 04 06	00001 00003		R1-IMU ORIENTATION OPTION R2-REFSMMAT
186:28:XX				P52	PRO	F 50 25	00015		R1-CELESTIAL BODY ACQUISITION

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					PRO  OPTICS ZERO-OFF CHECK FIRST STAR CODE	F 01 70	00022	122	R1-CELESTIAL BODY CODE (BEFORE MARK)
					PRO  OPTICS MODE-MAN	06 92	+007.XX +020.XXX	122	R1-NEW OCDU ANG; SHAFT (DEG) R2-NEW OCDU ANG; TRUNNION (DEG)
					OHC-CENTER STAR IN SXT MARK BUTTON-DEPRESS	F 51 BB		122	PLEASE MARK
					PRO  PRO	F 50 25	00016	122	R1-TERMINATE MARK SEQUENCE
						F 01 71	00022	122	R1-CELESTIAL BODY CODE (AFTER MARK)
						F 01 70	00024	122	R1-CELESTIAL BODY CODE (BEFORE MARK)
					CHECK SECOND STAR CODE OPTICS MODE-CMC	06 92	+104.XX +36.XXX	122	R1-NEW OCDU ANG; SHAFT(DEG) R2-NEW OCDU ANG; TRUNNION(DEG)
					PRO  OPTICS MODE-MAN	F 51 BB		122	PLEASE MARK
					OHC-CENTER STAR IN SXT MARK BUTTON-DEPRESS	F 50 25	00016	122	R1-TERMINATE MARK SEQUENCE
					PRO  PRO	F 01 71	00024	122	R1-CELESTIAL BODY CODE(AFTER MARK)
					RECORD DATA	F 06 05	+000.XX	122	R1-ANG ERROR DIFFERENCE(DEG)

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
186:34:XX					<p>PRO</p> <p>RECORD DATA CMC MODE-FREE</p> <p>PRO</p> <p>PRO</p> <p>ENTER</p> <p>V21E 21E</p> <p>OPTICS MODE-CMC</p> <p>PRO</p> <p>VERIFY STAR CENTERED IN SXT OPTICS MODE-MAN</p> <p>OPTICS SPEED-HI OHC-DRIVE TRUNNION TO LESS THAN 10 DEG</p> <p>OPTICS ZERO-ZERO</p> <p>OPTICS SPEED-LO</p> <p>OPTICS MODE-CMC</p> <p><u>CALIBRATE COAS</u></p> <p>V37E 52E</p> <p>PRO</p> <p>ENTER</p>	F 06 93  F 50 25  F 50 25  F 01 70  F 01 70  06 92  F 51 BB	+00.XXX +00.XXX +00.XXX  00014  00015  00022  00021  +035.XX +036.XX	1  122  122  122  122  122  122  122  122  122  122  122  122  122  122  122	-22-	R1-DELTA GYRO ANG; X(DEG) R2-DELTA GYRO ANG; Y(DEG) R3-DELTA GYRO ANG; Z(DEG)  R1-FINE ALIGNMENT  R1-CELESTIAL BODY ACQUISITION  R1-CELESTIAL BODY CODE (BEFORE MARK)  R1-NEW OCDU ANG; SHAFT(DEG) R2-NEW OCDU ANG; TRUNNION(DEG)

GET H:M:S	L N G	S T D	S T E	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					V21E 16E OPTICS ZERO-OFF	F 01 70	00016	122		
					PRO	06 92	+357.XX +57.XXX		R1-NEW OCDU ANG; SHAFT(DEG) R2-NEW OCDU ANG; TRUNNION(DEG)	
					RHC 2-ARMED RHC 2-CENTER STAR IN COAS KEY VERB	BB 92	+XXX.XX +XX.XXX	1 122	FREEZE DKSY DISPLAY KEY RELEASE LIGHT-ON	
					RECORD SHAFT AND TRUNNION RHC 2-LOCKED CMC MODE-AUTO OPTICS ZERO-ZERO 37E 00E	BB BB				
186:40:XX		07	P00		<u>ALIGN GDC</u>				KEY RELEASE LIGHT-OFF	
					ATT SET TW-SET TO IMU ANGLES ON FDAI 1 FDIAI SELECT-1 FDIAI SOURCE-ATT SET(VERIFY) ATT SET-IMU ATT SET TW-NULL FDAI 1 ERROR NEEDLES ATT SET-GDC GDC ALIGN PB-PUSH UNTIL NEEDLES NULLED FDIAI SELECT-1/2			1 1 1 1 1 1 1 1		
186:54:XX		08	P00		<u>VERIFY DSE TAPE MOTION</u>					
					HIGH GAIN ANTENNA TRACK-MAN HGA PITCH POSITION-SET PITCH POSITION HGA YAW POSITION-SET YAW POSITION HIGH GAIN ANTENNA TRACK-AUTO			2 2 2 2	STDN ENABLES S-BAND RELAY  RHO=-58 GAMMA=+52	
186:54:30									LOSS OF SIGNAL	
187:14:13									CSM LEAVES MOON SHADOW	

GET H:M:S	L T N G	S T D N	P R O G	OPERATIONS	V-M DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
187:38:45		09	P00	ACQUIRE STDN WITH HGA				ACQUISITION OF SIGNAL
187:41:XX		10	P00	LOAD CSM AND LM WT V48E	F 04 46	11102 X1111		R1-DAP CONFIGURATION R2-DAP CONFIGURATION
				PRO	F 06 47	+36844. +XXXXXX.		R1-CSM WEIGHT(LBS) R2-LM WEIGHT(LBS)
				V24E +XXXXXE +5935E	F 06 47	+XXXXXX. +05935.		
				PRO	F 06 48	+000.43 +001.02		R1-GIMBAL PITCH TRIM(DEG) R2-GIMBAL YAW TRIM(DEG)
				PRO	BB BB			
187:42:XX		11	P00	MANEUVER TO POST INSERTION TRACK ATTITUDE V49E	F 06 22	+180.00 +244.00 +341.00		R1-DESIRED ICDU ANG; ROLL(DEG) R2-DESIRED ICDU ANG; PITCH(DEG) R3-DESIRED ICDU ANG; YAW(DEG)
				V25E +18000E +2600E +E	F 06 22	+180.00 +026.00 +000.00		
				PRO	F 50 18	+180.00 +026.00 +000.00		R1-AUTO ATT MNVR; ROLL(DEG) R2-AUTO ATT MNVR; PITCH(DEG) R3-AUTO ATT MNVR; YAW(DEG)
				PRO	06 18	+180.00 +026.00 +000.00		
				MONITOR MANEUVER	F 50 18	+180.00 +026.00 +000.00		

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
187:49:XX	[REDACTED]	12	POO	ENTER		BB BB			
					<u>CONFIGURE VHF AND EMS FOR RANGING</u>				
					VHF AM T/R-OFF			9	
					VHF AM B-DUPLEX			3	
					A-OFF(VERIFY)			3	
					VHF RANGING-ON(UP)			3	
					VHF ANT-RIGHT(VERIFY)			3	
					EMS FUNCTION-DV SET/VHF RNG			1	
					EMS MODE-BACKUP/VHF RNG			1	
					RNDZ XPNDR-PWR			100	
187:52:XX	[REDACTED]	13	POO	<u>CONFIGURE RNDZ LIGHTS</u>				2	
					EXTERIOR LIGHTS(2)-ON(UP)				
187:57:XX	[REDACTED]	14	POO	<u>ALIGN GDC</u>				1	
					ATT SET TW-SET TO IMU ANGLES ON FDAI 1			1	
					FDAI SELECT-1			1	
					FDAI SOURCE-ATT SET(VERIFY)			1	
					ATT SET-IMU			1	
					ATT SET TW-NULL FDAI 1 ERROR NEEDLES			1	
					ATT SET-GDC			1	
					GDC ALIGN PB-PUSH UNTIL NEEDLES NULLED			1	
					FDAI SELECT-1/2			1	
188:03:15	[REDACTED]								<b>LM LIFT-OFF</b>
188:09:XX	[REDACTED]	15	POO	<u>INITIATE VHF RANGING</u>				9	
					VHF RNG-RESET				
188:10:32	[REDACTED]								<b>LM INSERTION</b>
188:13:XX	[REDACTED]				<u>VHF VOICE CHECK</u>			9	
					VHF AM T/R-T/R				
					VERIFY VHF VOICE				
					VHF AM T/R-OFF			9	

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
188:19:32	[REDACTED]	16	P00	ACCEPT STDN UPLINK UP TLM CM-ACCEPT				2	UPLINK ACT LT-ON LM S.V.(INS+5) CSM S.V.(L/0)
	[REDACTED]		P27	VERIFY UPLINK ACTIVITY LT-ON MONITOR UPLINK		XX XX	XXXXX XXXXX XXXXX	2	UPLINK ACT LT-OFF
	[REDACTED]		P00	VERIFY UPLINK ACTIVITY LT-OFF UP TLM CM-BLOCK		BB BB			
188:23:32	[REDACTED]	17	P00	INITIATE P34 AND RNDZ NAVIGATION V37E 34E		F 50 25	00017		R1-MINKEY SELECTION OPTION
	[REDACTED]		P20 P34	PRO  MONITOR TRIM MANEUVER		F 06 37	+00XXX. +000XX. +0XX.XX		R1-GETI TPI(HRS) R2- (MIN) R3- (SEC)
	[REDACTED]			V25E +188E +57E +3230E		F 06 37	+00188. +00057. +032.30		
	[REDACTED]			PRO		F 06 55	+00000. +000.00 +130.00		R1-PRECISION OFFSETS R2-ELEVATION ANG(DEG) R3-TPI/TPF TRANSFER ANG(DEG)
TPI-33	[REDACTED]			<u>BEGIN VHF MARKING</u>		F 16 45	+XXB00 -33BXX -00001		R1-MARKS(VHF/OPTICS) R2-TFI(MIN/SEC) R3-NO FINAL COMP CODE
	[REDACTED]			SET MDC DET COUNTING UP TO TPI				1	
	[REDACTED]			SET LEB DET COUNTING UP TO TPI				306	

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
188:26:48					BEGIN SEXTANT MARKING OPTICS ZERO-OFF OPTICS MODE-MAN OHC-CENTER LM IN SXT TAKE ONE SXT MARK PER MIN			122 122 122	CSM ENTERS MOON SHADOW
TPI-20MIN		18	P34		COMPUTE P34 RECYCLE  OPTICS MODE-CMC  V32E  RECORD DATA  PRO  RECORD DATA  PRO  RECORD DATA  PRO OPTICS MODE-MAN CONTINUE RNDZ NAVIGATION	F 06 55	+00000 +208.30 +130.00	122	R1-PRECISION OFFSETS R2-ELEVATION ANG(DEG) R3-TPI/TPF TRANSFER ANG(DEG)
						F 06 58	+0008.3 +0077.1 +0033.6		R1-PERILUNE ALT(POST-TPI)(NM) R2-DELTA V(TPI)(FPS) R3-DELTA V(TPF)(FPS)
						F 06 81	-0076.1 +0000.5 -0012.1		R1-DELTA VX(LV)(FPS) R2-DELTA VY(LV)(FPS) R3-DELTA VZ(LV)(FPS)
						F 16 45	+XXBXX -19BXX -00001	122	R1-MARKS(VHF/OPTICS) R2-TFI(MIN/SEC) R3-NO FINAL COMP CODE

GET H:M:S	L S T N D G N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI-10MIN	19	P34		COMPUTE TPI SOLUTION AND TERMINATE NAV OPTICS SPEED-HI OHC-DRIVE TRUNNION TO LESS THAN 10 DEG OPTICS ZERO-ZERO OPTICS SPEED-LO OPTICS MODE-CMC			122 122 122 122 122	
			PRO		F 06 55	+00000. +208.30 +130.00		R1-PRECISION OFFSETS R2-ELEVATION ANG(DEG) R3-TPI/TPF TRANSFER ANG(DEG)
			PRO	RECORD DATA	F 06 58	+0008.3 +0077.1 +0033.6		R1-PERILUNE ALT(POST TPI)(NM) R2-DELTA V (TPI)(FPS) R3-DELTA V (TPF)(FPS)
			PRO	RECORD DATA	F 06 81	-0076.1 +0000.5 -0012.1		R1-DELTA VX (LV)(FPS) R2-DELTA VY (LV)(FPS) R3-DELTA VZ (LV)(FPS)
			PRO	RECORD DATA	F 16 45	+26B23 -08BXX +000.XX		R1-MARKS (VHF/OPTICS) R2-TFI (MIN/SEC) R3-MGA(DEG)
TPI-08MIN	20	P34		BACKUP LM TPI BURN				IF THE LM CAN NOT APPLY THE TPI BURN, SEE SECTION 4.2.1 DISCUSSION
		P40	PRO		F 50 18	+180.XX +279.XX +000.XX		R1-AUTO ATT MNVR; ROLL(DEG) R2-AUTO ATT MNVR; PITCH(DEG) R3-AUTO ATT MNVR; YAW(DEG)
			PRO		06 18	+180.XX +279.XX +000.XX		ATTITUDE INCLUDES SPS GIMBAL OFFSET AND TRIM

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					MONITOR MANEUVER	F 50 18	+180.XX +279.XX +000.XX	1 1 1 1 1 1 1 1 1 1	
188:51:XX					ALIGN GDC ATT SET TW-SET TO IMU ANGLES ON FDAI 1 FDIAI SELECT-1 FDIAI SOURCE-ATT SET (VERIFY) ATT SET-IMU ATT SET TW-NULL FDAI 1 ERROR NEEDLES ATT SET-GDC GDC ALIGN PB-PUSH UNTIL NEEDLES NULLLED FDIAI SELECT-1/2				
					<u>RECORD P76 DATA</u>				OBTAINTPI P76 FROM CDR
188:52:59					<u>VERIFY DSE TAPE MOTION</u> VHF AM T/R-T/R			9	USE VHF COMM LOSS OF SIGNAL
					CONFIGURE EMS EMS MODE-STBY EMS FUNCTION-OFF EMS FUNCTION-DV SET/VHF RNG LOAD 66.1 INTO EMS EMS FUNCTION-DV			1 1 1 1 1 1	TPI DV MINUS TAIL OFF
					<u>CONFIGURE SCS</u> CB STAB CONT SYS(ALL)-CLOSE CB SPS (12)-CLOSE MANUAL ATTITUDE(3)-RATE CMD(VERIFY) RATE-LOW(VERIFY) DV CG-CSM(VERIFY) SPS HE VLVS(BOTH)-AUTO(VERIFY) CHECK N2 A AND N2 B			8 8 1 1 1 3 3	

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					PRO				
					MONITOR TRIM MANEUVER	06 18	+180.XX +279.XX +000.XX		R1-AUTO ATT MNVR; ROLL(DEG) R2-AUTO ATT MNVR; PITCH(DEG) R3-AUTO ATT MNVR; YAW(DEG)
					ENTER	F 50 18	+180.XX +279.XX +000.XX		
					ENTER	F 50 25	00204		R1-SPS GIMBAL TEST OPTION
					FDAI SCALE-5/1 (VERIFY) VERIFY MDC DET SET	06 40	-XXBXX +0077.1 +0000.0	1	R1-TFI(MIN/SEC) R2-VG (FPS) R3-DELTA V ACCUMULATED(FPS)
TPI-35SEC					MONITOR DSKY BLANK	BB BB			
TPI-30SEC					CHECK PIPA BIAS LESS THAN 2 FPS FOR 5 SEC	06 40	-00B29 +0077.1 +0000.0	1	AVE G ON
TPI-05SEC						F 99 40	-00B05 +0077.1 +0000.0		ENGINE ON ENABLE REQUEST
188:57:32					CONFIRM LM BURN COMPLETE				LM TPI
									IF THE LM DID NOT APPLY THE TPI BURN, SEE SECTION 4.2.1

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					ENTER  EMS FUNCTION-OFF CB SPS PITCH 1 AND YAW 1-OPEN	F 16 85	+XXXX.X +XXXX.X +XXXX.X	1 8	R1-BODY VGX(FPS) R2-BODY VGY(FPS) R3-BODY VGZ(FPS)
TPI+01MIN	21	P40			UPDATE LM S.V. IN THE CMC PRO	F 06 33	+00188. +00057. +032.30		R1-GETI TPI(HRS) R1- (MIN) R3 (SEC)
		P76			PRO	F 06 84	+0075.1 -0000.5 +0014.1		R1-LM DELTA VX(LV)(FPS) R2-LM DELTA VY(LV)(FPS) R3-LM DELTA VZ(LV)(FPS)
TPI+03MIN	22	P76			INITIATE P35 AND RNDZ NAVIGATION  CONFIGURE EMS FOR RANGING EMS FUNCTION-DV SET/VHF RNG EMS MODE-BACKUP/VHF RNG VHF RNG-RESET PRO			1 1 9	
				P35	F 16 45	+26B23 +03BXX -00001		R1-MARKS(VHF/OPTICS) R2-TFI(MIN/SEC) R3-NO FINAL COMP CODE	
					START SEXTANT MARKING OPTICS ZERO-OFF OPTICS MODE-MAN OHC-CENTER LM IN SXT TAKE ONE SXT MARK PER MINUTE OPTICS MODE-CMC			122 122 122 122	

GET H:M:S	L T N G	S T D E	S T E	P R O	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI+12MIN		23	P35		<u>COMPUTE MCC1 SOLUTION AND TERMINATE NAV</u>				
				PRO		F 06 81	+XXXXX.X +XXXXX.X +XXXXX.X 		R1-DELTA VX(LV)(FPS) R2-DELTA VY(LV)(FPS) R3-DELTA VZ(LV)(FPS)
				RECORD DATA		F 16 45	+09B09 -03BX <sub>X</sub> +XXX.XX		R1-MARKS(VHF/OPTICS) R2-TFI(MIN/SEC) R3-MGA(DEG)
				PRO					
TPI+13MIN		24	P35		<u>BACKUP LM MCC1 BURN</u>				
			P41	PRO		F 50 18	+XXX.XX +XXX.XX +XXX.XX		R1-AUTO ATT MNVR; ROLL(DEG) R2-AUTO ATT MNVR; PITCH(DEG) R3-AUTO ATT MNVR; YAW(DEG)
				ENTER		06 85	+XXXXX.X +XXXXX.X +XXXXX.X 		R1-BODY VGX(FPS) R2-BODY VGY(FPS) R3-BODY VGZ(FPS)
MCC-35SEC				MONITOR DSKY BLANK		BB BB			
MCC-30SEC						16 85	+XXXXX.X +XXXXX.X +XXXXX.X 		AVE G ON
189:12:32						F 16 85	-0000.8 -0000.0 +0000.6		<b>LM MCC1</b>
189:13:06				VERIFY LM BURN COMPLETE					IF THE LM CANNOT APPLY THE MCC1 BURN, SEE SECTION 4.2.2  CSM LEAVES MOON SHADOW

GET H:M:S	L T N G	S T D P	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI+16MIN		25	P41		<u>UPDATE LM S.V. IN THE CMC</u>				
			P76		PRO	F 06 33	+00189. +00012. +032.XX		R1-GETI MCC1(HRS) R2- (MIN) R3- (SEC)
					PRO	F 06 84	+XXXXX.X +XXXXX.X +XXXXX.X		R1-LM DELTA VX(LV)(FPS) R1-LM DELTA VY(LV)(FPS) R3-LM DELTA VZ(LV)(FPS)
TPI+17MIN		26	P76		<u>INITIATE P35 AND RNDZ NAVIGATION</u>				IF CSM ACTIVE AND TPF DELTA V > 55 FPS, SEE SECTION 4.2.3.
			P35		PRO	F 16 45	+09B09 +03BXX -00001	122 122	R1-MARKS(VHF/OPTICS) R2-TFI(MIN/SEC) R3-NO FINAL COMP CODE
					START SEXTANT MARKING OPTICS MODE-MAN OHC-CENTER LM IN SXT TAKE ONE SXT MARK PER MINUTE				
TPI+27MIN		27	P35		<u>COMPUTE MCC2 SOLUTION AND TERMINATE NAV</u>				
			P35		PRO	F 06 81	-0000.0 -0000.0 +0003.3	122 122 122 122 122	R1-DELTA VX(LV)(FPS) R2-DELTA VY(LV)(FPS) R3-DELTA VZ(LV)(FPS)
					OPTICS SPEED-HI OHC-DRIVE TRUNNION TO LESS THAN 10 DEG OPTICS ZERO-ZERO OPTICS SPEED-LO OPTICS MODE-CMC				

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI+28MIN					RECORD DATA PRO	F 16 45	+09B09 -03BXX +XXX.XX		R1-MARKS(VHF/OPTICS) R2-TFI(MIN/SEC) R3-MGA(DEG)
	28	P35			<u>BACKUP LM MCC2 BURN</u> PRO	F 50 18	+XXX.XX +XXX.XX +XXX.XX		R1-AUTO ATT MNVR; ROLL(DEG) R2-AUTO ATT MNVR; PITCH(DEG) R3-AUTO ATT MNVR; YAW(DEG)
		P41			ENTER	06 85	+XXXX.X +XXXX.X +XXXX.X		R1-BODY VGX(FPS) R2-BODY VGY(FPS) R3-BODY VGZ(FPS)
MCC-35SEC					MONITOR DSKY BLANK	BB BB			
MCC-30SEC						16 85	+XXXX.X +XXXX.X +XXXX.X		AVE G ON
189:27:32						F 16 85	+XXXX.X +XXXX.X +XXXX.X		LM MCC2
					VERIFY LM BURN COMPLETE				IF THE LM CANNOT APPLY THE MCC2 BURN, SEE SECTION 4.2.2
TPI+31MIN		29	P41		<u>UPDATE LM S.V. IN THE CMC</u> PRO	F 06 33	+00189. +00027. +032.XX		R1-GETI MCC2(HRS) R2- (MIN) R3- (SEC)
			P76		PRO	F 06 84	+XXXX.X +XXXX.X +XXXX.X		R1-LM DELTA VX(LV)(FPS) R2-LM DELTA VY(LV)(FPS) R3-LM DELTA VZ(LV)(FPS)

GET H:M:S	L T N D G	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI+32MIN		30	P76	MANEUVER TO COAS TRACK ATTITUDE				

-35-

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
189:30:XX		31	P00		<u>PERFORM DOCKING PREPARATION ACTIVITIES</u>  PERFORM PRE-DOCK CHECKLIST MANUAL ATTITUDE (3)-RATE CMD (VERIFY) LIMIT CYCLE-OFF (VERIFY) ATT DEADBAND-MIN RATE-LOW(VERIFY) TRANS CONTR PWR-ON ROT CONTR PWR DIRECT (BOTH)-MNA/MNB SC CONT-CMC (VERIFY) AUTO RCS SELECT (16)-MNA/MNB CB DOCK PROBE(2)-CLOSE DOCKING PROBE RETRACT(BOTH)-OFF(CTR) (VERIFY) DOCKING PROBE-RETRACT DOCKING PROBE EXTD/REL TB(2)-GRAY (VERIFY) CB SEQ EVENTS CONT SYS(4)-CLOSE COAS POWER-ON(UP)(VERIFY) EXTERIOR LIGHTS RUN/EVA-ON(UP)(VERIFY)				1 1 1 1 1 1 1 8 8 2 2 2 2 2 8 15 2	
189:37:13									IF CSM ACTIVE BRAKING, SEE SECTION 4.2.4	
189:37:XX		32	P00		<u>ACQUIRE STDN WITH HGA</u> HIGH GAIN ANTENNA TRACK-MAN HGA PITCH POSITION-SET PITCH POSITION HGA YAW POSITION-SET YAW POSITION S BAND ANTENNA-HI GAIN HIGH GAIN ANTENNA TRACK-AUTO			2 2 2 3 2	ACQUISITION OF SIGNAL  RHO=-35 GAMMA=+37	

GET H:M:S	L N G	S T D P	S T E O G	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
189:38:XX		33		P00	<u>PERFORM TPF ACTIVITIES AND PHOTOGRAPH LM</u>  <u>PHOTOGRAPH LM</u> <u>UTILITY POWER-ON(UP)(VERIFY)</u> <u>TV-ON</u> <u>DAC-ON</u> <u>BEGIN PHOTOS WITH DAC AND TV</u>			15	
189:40:28					<u>CONFIGURE SWITCHES FOR POST TPF</u> <u>EMS MODE-STBY</u> <u>EMS FUNCTION-OFF</u> <u>EXTERIOR LIGHTS RNDZ-OFF(CTR)</u>			1 1 2	<b>TPF</b>
189:44:XX				PRO	<u>TERMINATE LM PHOTOS</u>  <u>DAC-OFF</u> <u>TV-OFF</u>	BB BB			
189:46:XX		34		P00	<u>MANEUVER FOR CSM INSPECTION</u>  V49E  V25E +31900E +25400E +E  PRO	F 06 22  F 06 22  F 50 18	+180.XX +282.XX +000.XX  +319.00 +254.00 +000.00  +319.00 +254.00 +000.00		R1-DESIRED ICDU ANG; ROLL(DEG) R2-DESIRED ICDU ANG; PITCH(DEG) R3-DESIRED ICDU ANG; YAW(DEG)  R1-AUTO ATT MNVR; ROLL(DEG) R2-AUTO ATT MNVR; PITCH(DEG) R3-AUTO ATT MNVR; YAW(DEG)

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
189:55:XX					PRO  MONITOR MANEUVER  ENTER  <u>MANEUVER TO DOCKING ATTITUDE</u> V49E  V25E +18000E +28200E +E  PRO  PRO  MONITOR MANEUVER  ENTER  REACQUIRE STDN HGA	06 18  F 50 18  BB BB  F 06 22  F 06 22  F 50 18  06 18  F 50 18  BB BB	+319.00 +254.00 +000.00  +319.00 +254.00 +000.00    +319.00 +254.00 +000.00  +180.00 +282.00 +000.00  +180.00 +282.00 +000.00  +180.00 +282.00 +000.00  +180.00 +282.00 +000.00		R1-DESIRED ICDU ANG; ROLL(DEG) R2-DESIRED ICDU ANG; PITCH(DEG) R3-DESIRED ICDU ANG; YAW(DEG)

GET H:M:S	L T N G	S T D P	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
189:57:XX		36	P00		<u>ARM PYROS</u>  CUE STDN FOR LOGIC ARM SEQ EVENTS CONT SYSTEM LOGIC(BOTH)- ON(UP)  SEQ EVENTS CONT SYSTEM PYRO ARM(BOTH)- ON(UP)			8	STDN GO FOR PYRO ARM
190:00:XX		37	P00		<u>PERFORM DOCKING ACTIVITIES</u> V37E 47E  <u>INITIATE LM PHOTOGRAPHY</u> DAC-ON TV-ON PHOTOGRAPH LM MNVR  <u>TRANSLATE TO CAPTURE LATCH</u> THC-ARMED THC-MINIMUM THRUST FORWARD  THC-LOCKED	F 16 83	+0000.0 +0000.0 +0000.0	8	R1-DELTA VX(FPS) R2-DELTA VY(FPS) R3-DELTA VZ(FPS)
190:05:XX			P47		<u>PERFORM AT CAPTURE</u>  DOCKING PROBE EXT/REL TB(2)-BP(VERIFY) REPORT CAPTURE TO LM SC CONT-CMC(VERIFY) CMC MODE-FREE ALLOW PROBE TO DAMP S/C MOTION (10 SEC) DOCKING PROBE RETRACT SEC-1 PRIM-2 (IF REQ'D)	F 16 83	+XXXX.X +XXXX.X +XXXX.X	2 1 1 2 2	<b>DOCKING</b>  WHEN WITHIN $\pm 3^\circ$ OF DOCKING ATTITUDE

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
190:06:XX					<p><u>PERFORM AT DOCK LATCH</u>  <u>DOCKING PROBE EXTD/REL TB(2)-GRAY</u>  <u>(VERIFY)</u></p> <p><u>PERFORM AT HARD DOCK</u></p> <p>SEQ EVENT CONT SYS PYRO ARM(BOTH)-SAFE  LOGIC(BOTH)-OFF</p> <p>CB SEQ EVENTS CONT SYS(4)-OPEN</p> <p>THC-LOCKED(VERIFY)</p> <p>RHC 2-LOCKED(VERIFY)</p> <p>BMAG MODE(3)-RATE 2(VERIFY)</p> <p>DOCKING PROBE-OFF</p> <p>DOCKING PROBE RETRACT(BOTH)-OFF(CTR)</p> <p>EXTERIOR LIGHTS RUN/EVA-OFF</p> <p>COAS POWER-OFF</p> <p>AUTO RCS SELECT ROLL(4)-OFF</p> <p>TRANS CONTR PWR-OFF</p> <p>ROT CONTR PWR DIRECT (BOTH)-OFF</p> <p>VHF RANGING-OFF</p> <p><u>TERMINATE LM PHOTOGRAPHY AND P47</u></p> <p>DAC-OFF</p> <p>TV-OFF</p> <p>PRO</p> <p>OOE</p>	F 37 BB BB BB		2 8 8 8 1 2 2 2 15 8 1 1 3	-40-	

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
190:07:XX	[REDACTED]	38	P00		<u>RECONFIGURE DAP</u> V48E	F 04 46	11102 X1111		R1-DAP CONFIGURATION R2-DAP CONFIGURATION
					V21E 61111E	F 04 46	61111 X1111		
					PRO	F 06 47	+XXXXXX. +05935.		R1-CSM WEIGHT(LBS) R2-LM WEIGHT(LBS)
					PRO	F 06 48	+000.43 +001.02		R1-GIMBAL PITCH TRIM(DEG) R2-GIMBAL YAW TRIM(DEG)
					PRO	BB BB		1 100	
190:08:XX	[REDACTED]	39	P00		<u>CONFIGURE SWITCHES FOR POST DOCKING</u> CMC MODE-AUTO RNDZ XPNDR-OFF				

### 3.0 CMP ABORT RENDEZVOUS PROCEDURES

During the period of CSM and LM separation, an abort may be initiated at a pre-determined time and the rendezvous completed by using one of several techniques. The LM active Direct Ascent, One Rev, or Two Rev technique will be used to complete the rendezvous if the LM obtains the desired insertion conditions or if the LM makes an accurate abort initiation maneuver.

The procedures for the Direct Ascent rendezvous are similar to those presented in the previous section. This section discusses the CMP procedures necessary to support the other two LM active rendezvous techniques.

#### 3.1 ABORT PLAN

The abort plan defines pre-determined abort points and regions during CSM and LM separation and the rendezvous technique to be used after the abort. The two basic rendezvous techniques of the abort plan are discussed in subsection 3.1.1 and the abort points and regions are discussed in subsection 3.1.2. Detailed discussion of the abort plan may be found in Reference 9.

##### 3.1.1 RENDEZVOUS TECHNIQUES

One Rev Rendezvous. The One Rev rendezvous consists of four LM burns with station-keeping occurring approximately 3.5 hours after the abort. The CMP will backup all maneuvers in case the LM is unable to apply them.

The first maneuver, CSI, is applied one-half rev after insertion at approximately LM apolune and establishes the desired catch-up or fall-back rate between the CSM and LM. Also, the out-of-plane velocity will be nulled at CSI, establishing a node

approximately 30 minutes before CDH. The second maneuver, CDH, is applied one-half rev after the CSI burn and establishes a constant LM catch-up rate by establishing a constant 15 nm differential altitude between the orbits of the two vehicles. The third maneuver, TPI, is applied approximately 42 minutes after CDH at a LM elevation angle of 26.6° (the CSM elevation angle is 208.3°). This should occur anywhere from 22 to 16 minutes prior to sunrise. The TPI maneuver establishes a trajectory which intercepts the target 130° after the TPI burn. Nominally zero DV midcourse corrections are scheduled at 15 and 30 minutes after TPI to refine the intercept trajectory. The fourth maneuver, TPF, is actually divided into five braking gates which establish desired relative velocities at specified ranges. These braking gates are defined as follows:

at 1.50 nm 45 fps,  
at 1.00 nm 30 fps (nominally the first braking gate),  
at 0.50 nm 20 fps,  
at 0.25 nm 10 fps,  
at 0.08 nm 5 fps.

A plane change burn will be applied 30 minutes prior to CDH if the magnitude of the burn is greater than five feet per second. This burn, and the out-of-plane burn at CSI, remove most of the out-of-plane dispersions.

A generalized orbital motion plot is contained in Appendix E, page two. A family of relative motion curves is defined by the various abort insertion points. These curves are contained in Appendix E, page three.

Two Rev Rendezvous. The Two Rev rendezvous consists of six LM burns with station-keeping occurring approximately 5.5 hours after insertion. The CMP will backup all maneuvers except the LM boost burn.

The LM applies the boost burn one-half rev after insertion. It is

a 10.0 feet per second burn which raises the LM perilune altitude. One rev after insertion a HAM burn is applied by the LM so that the post-CDH DH will be 15 nm. The coelliptic sequence (CSI, CDH, TPI, TPF) is then initiated one and one-half revs after insertion.

A generalized orbital motion plot is contained in Appendix E, page six and the family of relative motion plots defined by the time of abort is contained in Appendix E, page seven. As shown in the third figure, a large range at insertion necessitates adding an additional rev between the boost burn and HAM for the T2-1 case.

### 3.1.2 ABORT POINTS

Separation to Circularization. In case of a "NO-GO" decision for the CSM circularization burn the LM will achieve station-keeping by applying a chart computed maneuver. There is no discrete abort point during this period.

Circularization to PDI. If a "NO-GO" decision is made for PDI, the LM applies an abort initiation maneuver 12 minutes after the scheduled PDI time. If the abort burn is applied after the first PDI opportunity, the One Rev technique is used for rendezvous. If the abort burn is made after the second PDI opportunity, the Two Rev technique is used.

PDI to T1 Time. The CDR may initiate an abort at any time between Powered Descent Initiation and T1 (T1 being the time when a LM abort would result in the minimum LM apolune of 30 nm). T1 time for the first PDI opportunity is approximately  $PDI_1 + 17$  minutes and T1 for the second opportunity is approximately  $PDI_2 + 16$  minutes.

An abort during this region is classified as either a "PDI early abort" or an "PDI late abort". The crossover point between the early and

late aborts is determined by the phase angle between the LM and CSM. The approximate crossover times are  $PDI_1 + 10$  minutes and  $PDI_2 + 6$  minutes.

The One Rev rendezvous technique is used for a  $PDI_1$  early abort and a  $PDI_2$  late abort. The Two Rev technique is used for a  $PDI_1$  late abort and a  $PDI_2$  early abort.

T1 to T2. If a failure requiring an abort is found after T1, the abort will be initiated at a discrete time designated T2. (T2 being the first time after T1 when the LM apolune would be 30 nm). The approximate T2 times for the first two powered descent opportunities are  $PDI_1 + 25$  minutes and  $PDI_2 + 22$  minutes.

The Two Rev rendezvous technique will be used for an abort at the T2 time. In the event of a T2 abort from the first PDI opportunity, an additional rev is required between the boost and the HAM burns.

T2 to Nominal Lift-Off -10 Minutes. For each CSM rev that the LM is on the surface, MCC-H computes an abort lift-off time which will result in either a Direct Ascent rendezvous or a One Rev rendezvous. This time is designated as "T3".

If the CDR initiates an abort at a T3 time, the Direct Ascent rendezvous will be used whenever possible. If, however, trajectory or systems limitations prevent using the Direct Ascent technique, then the rendezvous will be performed using the One Rev technique with lift-off time delayed approximately two and one-half minutes.

Nominal Lift-Off Time -10 Minutes to Nominal Lift-Off Time. An APS leak during APS pressurization is cause for an immediate LM lift-off. This may occur as early as 10 minutes prior to nominal lift-off time and is designated as the "early coelliptic abort region". The Two Rev technique is used for rendezvous for aborts prior to eight minutes before

lift-off and the One Rev technique is used for aborts after eight minutes.

LM or CSM system failures may make the One Rev technique more desirable than the Direct Ascent technique for rendezvous. If these failures are determined before lift-off, then the lift-off is delayed approximately two and one-half minutes and the One Rev rendezvous is then performed. The abort is designated as a "coelliptic abort".

Nominal Lift-Off Time to Docking. If the LM inserts with an unacceptable trajectory dispersion which cannot be adjusted with a LM tweak maneuver, the rendezvous technique to be used is changed from the Direct Ascent to the One Rev technique. This is accomplished at five minutes after insertion when the LM applies a bailout burn which adjusts LM phasing to be compatible with the One Rev rendezvous requirements. The CMP backs up the bailout burn but would apply it at insertion +12 minutes.

Separation to Docking. A summary of the LM abort points and rendezvous techniques is contained in Figure 3.

PERIOD	ABORT NAME	RENDEZVOUS TECHNIQUE
FIRST POWERED DESCENT OPPORTUNITY	NO PDI+12 ABORT PDI, EARLY ABORT PDI, LATE ABORT T2 ABORT	ONE REV RENDEZVOUS ONE REV RENDEZVOUS TWO REV RENDEZVOUS MODIFIED TWO REV RENDEZVOUS
SECOND POWERED DESCENT OPPORTUNITY	NO PDI+12 ABORT PDI, EARLY ABORT PDI, LATE ABORT T2 ABORT	TWO REV RENDEZVOUS TWO REV RENDEZVOUS ONE REV RENDEZVOUS TWO REV RENDEZVOUS
POST-LANDING	T3 ABORT  COELLIPTIC ABORT (8-10 MIN EARLY) COELLIPTIC ABORT (2-8 MIN EARLY) COELLIPTIC ABORT (NOM L/O +2.5 MIN)	DIRECT ASCENT RENDEZVOUS (ALTERNATE-ONE REV RENDEZVOUS) TWO REV RENDEZVOUS ONE REV RENDEZVOUS ONE REV RENDEZVOUS
POST-LIFT-OFF	LM BAILOUT	ONE REV RENDEZVOUS

FIGURE 3. APOLLO 17 ABORT POINT AND RENDEZVOUS TECHNIQUE SUMMARY

### 3.2 ABORT PROCEDURES RATIONALE

Rationale for the Coelliptic rendezvous procedures after the TPI final comp is the same as for the Direct Ascent rendezvous. Rationale for additional procedures prior to the final comp necessary for performing a coelliptic rendezvous are contained in this section.

Reconfigure DAP. The DAP is reconfigured to change the vehicle's attitude maneuver rate and deadband.

A .5 degree/second attitude maneuver rate is used for rendezvous. This rate gives acceptable maneuver times without excessive fuel expenditures.

The R03 deadband is set to 0.5 degrees for rendezvous because:

- A. P40/P41 will select the R03 deadband if P20 is running when P40/P41 is selected.
- B. Line-of-sight monitoring after MCC-2 will be done with the R03 narrow deadband.

If a tracking deadband larger than .5 degrees is desired, it should be loaded via N79.

Manually narrowing the deadband in R03 does not change the attitude reference; therefore, when switching to the minimum deadband, the mode switch should be cycled to FREE and back to AUTO to re-establish the attitude hold reference.

Accept STDN Uplink. The One Rev and Two Rev detailed procedures were developed assuming that the LM aborted after PDI. The STDN uplink supplies the CMC with an initial LM state vector. If, however, the LM aborts without initiating PDI, P76 would be used to update the CMC LM state vector with the LM abort burn.

An additional STDN uplink is scheduled prior to the HAM in the Two Rev rendezvous. This uplink will improve the CMC's knowledge of the CSM and LM state vectors and will give the CMC the capability to compute an accurate HAM if there has been no navigation prior to the HAM.

Update LM State Vector in the CMC. P76 is used to update the CMC's knowledge of the LM state vector to include any burn that the LM may apply to accomplish rendezvous.

Configure VHF and EMS for Ranging. The VHF and EMS are configured for ranging so that VHF marks may be taken.

Initiate Pre-Thrust Program and Rendezvous Navigation. The pre-thrust program is entered in order to:

- A. Initiate P20 and LM tracking
- B. Initiate VHF marking on the LM
- C. Display the time to the burn
- D. Display the number of sextant and VHF marks taken
- E. Initialize the program for the upcoming recycle and final comp
- F. To initiate the MINKEY sequence if this is the first pre-thrust program

Start Recycle Sequence. The burn components are computed for comparison with the LGC solution.

Compute Burn Solution and Terminate Navigation. The burn solution is used in the CMC for a possible CSM active burn. The final comp terminates rendezvous navigation until the next marking period.

Backup LM Burn. The CMP backs up the LM HAM, CSI, PC and CDH burns. If the LM fails to apply any of these burns, the CSM would become the active vehicle and perform the CMC computed burn.

A. Backup LM RCS Burn

The MINKEY logic specifies an RCS burn if the computed DV is less than seven feet per second. The CMP configures the CSM for an RCS burn but does not actually apply the burn. If the LM fails to apply the burn, the CMP would apply the burn by zeroing the burn components in the CMC P41 N85 display with the THC.

B. Backup LM SPS Burn

The MINKEY logic specifies an SPS burn if the computed DV is greater than or equal to seven feet per second. Except for arming the SPS engine and applying ullage, the CMP configures the CSM for an SPS burn. In the event the LM cannot apply the burn, the CMP would burn the CMC solution by:

- (1) Arming the SPS engine
- (2) Applying ullage for 11 seconds
- (3) Proceeding on the flashing V99 N40 display

### 3.3 DETAILED PROCEDURES

The CSM detailed procedures for the LM active abort rendezvous are contained in subsection 3.3.1, 3.3.2, and 3.3.3. These detailed procedures consider primarily the G&N requirements, although some non-G&N procedures are included for purposes of information and continuity. The format for presenting the abort procedures is the same as the format used for presenting the nominal direct ascent rendezvous procedures (subsection 2.3). However, since the procedures cover generalized cases, no trajectory dependent data such as GET and DSKY register displays are shown.

#### 3.3.1 TWO REV SEQUENCE

The Two Rev procedures begin five minutes before insertion and assume an abort after PDI. In the event of a no PDI abort, the procedures would contain a P76 velocity update rather than a STDN state vector

uplink. The procedures continue through the CSI final comp which is the starting point for the common Coelliptic sequence (subsection 3.3.3).

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
INS-05MIN			1		* * * * * * * * * * TWO REV SEQUENCE * * * * * * * * * *				
				POO	<u>RECONFIGURE DAP</u> <u>V37E OOE</u>  CYCLE CMC MODE-FREE/AUTO <u>V48E</u>  <u>V21E 11102E</u>  PRO  PRO  PRO	BB BB  F 04 46 F 04 46 F 06 47 F 06 48 BB BB	11111 01111 11102 01111 +XXXXX. +XXXXX. +XXX.XX +XXX.XX	1	
INS+05MIN			2	POO	<u>ACCEPT STDN UPLINK</u> <u>UP TLM CM-ACCEPT</u> VERIFY UPLINK ACTIVITY LT-ON MONITOR UPLINK:				INSERTION OR AIM
				P27		XX XX	XXXXX XXXXX XXXXX	2	UPLINK ACT LT-ON
				POO	VERIFY UPLINK ACTIVITY LT-OFF <u>UP TLM CM-BLOCK</u>	BB BB		2	UPLINK ACT LT-OFF

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
HAM-60MIN									OBTAİN LM BOOST TIG & DV FROM LM
HAM-59MIN	3	P00	<u>UPDATE LM STATE VECTORS</u>						LM BOOST
		P76	V37E 76E			F 06 33	+00XXX. +000XX. +0XX.XX		
			V25E +XXE +XXE +XXXXE			F 06 33	+00XXX. +000XX. +0XX.XX		LOAD BOOST TIG
			PRO			F 06 84	+XXXX.X +XXXX.X +XXXX.X		
			V25E +100E +E +E			F 06 84	+0010.0 +0000.0 +0000.0		
	4	P76	<u>CONFIGURE VHF AND EMS FOR RANGING</u>			F 37 BB		9 3 1 1	
			VHF AM T/R-T/R						
			VHF ANTENNA-RIGHT						
			EMS FUNCTION - DV SET/VHF RNG						
			EMS MODE - BACKUP/VHF RNG						

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS		
HAM-40MIN	5	P76	<u>ACCEPT STDN UPLINK</u>			BB BB	XXXXXX XXXXXX XXXXXX	2	UPLINK ACT LT-ON		
			OOE								
		P27	UP TLM CM-ACCEPT VERIFY UPLINK ACTIVITY LT-ON MONITOR UPLINK			XX XX					
			POO			BB BB					
			VERIFY UPLINK ACTIVITY LT-OFF UP TLM CM-BLOCK			BB BB					
	6	POO	<u>INITIATE P31 AND RNDZ NAVIGATION</u>			F 50 25	00017	2	UPLINK ACT LT-OFF OBTAIN CSI,TPI,AND HAM TIG'S FROM LM		
			V37E 31E								
		P20 P31	PRO			F 50 18	+XXX.XX +XXX.XX +XXX.XX				
			PRO			06 18	+XXX.XX +XXX.XX +XXX.XX				
			MONITOR AUTO MNVR VHF RNG-RESET			F 06 11	+00XXX. +000XX. +0XX.XX	9	LOAD CSI TIG		
		V25E +XXXE +XXE +XXXXE			F 06 11		+00XXX. +000XX. +0XX.XX				

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
HAM-20MIN				7 P31	PRO PRO V25E +XXXE +XXE +XXXXE PRO V25E +XXXE +XXE +XXXXE PRO START RECYCLE SEQUENCE V32E RECORD DATA	F 06 55 F 06 37 F 06 37 F 06 33 F 06 33 F 16 45 F 06 90	+00001 +208.30 +130.00 +00XXX. +000XX. +0XX.XX +00XXX. +000XX. +0XX.XX +00XXX. +000XX. +0XX.XX +00XXX. +000XX. +0XX.XX +0XB00 -XXBXX -00001 +XXX.XX +XXXX.X +XXXX.X		LOAD TPI TIG LOAD HAM TIG

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
HAM-12MIN		8	P31		PRO  RECORD DATA PRO  <u>COMPUTE HAM SOLUTION AND TERMINATE NAV</u> PRO  RECORD DATA PRO  RECORD DATA V22E +E  PRO	F 06 81  F 16 45  F 06 90  F 06 81  F 06 81  F 16 45	+XXXX.X +XXXX.X +0000.0  +XXB00 -19BXX -00001  +XXX.XX +XXXX.X +XXXX.X  +XXXX.X +XXXX.X +0000.0  +XXXX.X +0000.0 +0000.0  +XXB00 -11BXX +XXX.XX		-95-

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
HAM-11MIN		9	P31		BACKUP LM HAM BURN <u>PRO</u>	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
			P41		ENTER	06 85	+XXXX.X +XXXX.X +XXXX.X		
HAM-35SEC					MONITOR DSKY BLANK	BB BB			
HAM-30SEC						16 85	+XXXX.X +XXXX.X +XXXX.X		AVE G ON
HAM TIG						F 16 85	+XXXX.X +XXXX.X +XXXX.X		LM HAM
					VERIFY LM HAM BURN COMPLETE				
HAM+01MIN	10	P41			UPDATE LM STATE VECTOR IN THE CMC <u>PRO</u>	F 06 33	+00XXX. +000XX. +0XX.XX		
		P76			PRO	F 06 84	+XXXX.X +0000.0 +0000.0		

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
HAM+02MIN		11	P76	P32	<u>INITIATE P32 AND RNDZ NAVIGATION</u> PRO  PRO  MONITOR AUTO MNVR  PRO  PRO  PRO  <u>START SEXTANT MARKING</u> OPTICS ZERO-OFF OPTICS MODE-MAN OHC-CENTER LM IN SXT TAKE ONE SXT MARK PER MIN	F 50 18 06 18 F 06 11 F 06 55 F 06 37 F 16 45	+XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX +00XXX. +000XX. +0XX.XX +00001 +208.30 +130.00 +00XXX. +000XX. +0XX.XX +XXB00 -XXBXX -00001		122 122 122	-58-

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
CSI-20MIN			12	P32	<u>START RECYCLE SEQUENCE</u> OPTICS MODE-CMC V32E  <u>RECORD DATA</u> PRO  <u>RECORD DATA</u> PRO  <u>CONTINUE SEXTANT MARKING</u> OPTICS MODE-MAN OHC-CENTER LM IN SXT TAKE ONE SXT MARK PER MIN	F 06 90	+XXX.XX +XXXX.X +XXXX.X		122	
CSI-12MIN			13	P32	<u>COMPUTE CSI SOLUTION AND TERMINATE NAV</u>  OPTICS SPEED-HI OHC-DRIVE TRUNNION TO LESS THAN 10 DEG OPTICS ZERO-ZERO OPTICS SPEED-LO OPTICS MODE-CMC	F 06 81  F 16 45	+XXXX.X +XXXX.X +0000.0  +XXBXX -19BXX -00001	122 122		

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					PRO  RECORD DATA PRO  RECORD DATA PRO  ***** CONTINUE WITH STEP 1 OF THE COMMON COELLIPTIC SEQUENCE, SECTION 3.3.3 *****	F 06 90  F 06 81  F 16 45	+XXX.XX +XXXX.X +XXXX.X  +XXXX.X +XXXX.X +0000.0  +XXBXX -1OBXX +XXX.XX		

### 3.3.2 ONE REV SEQUENCE

The One Rev procedures begin five minutes before insertion and assume an abort after PDI. In the event of a no-PDI abort, the procedures would contain a P76 velocity update rather than a STDN state vector uplink. The procedures continue through CSI final comp where the common Coelliptic sequence (subsection 3.3.3) is initiated.

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
INS-01MIN					<p>*****          ONE REV SEQUENCE          *****</p> <p>RECONFIGURE DAP</p> <p><u>V37E 00E</u></p> <p>V48E</p> <p>V21E 11102E</p> <p>PRO</p> <p>PRO</p>	<p>BB BB</p> <p>F 04 46</p> <p>F 04 46</p> <p>F 06 47</p> <p>F 06 48</p>	<p>11111          01111</p> <p>11102          01111</p> <p>+XXXXX.          +XXXXX.</p> <p>±XXX.XX          ±XXX.XX</p>		
	1	POO			<p>CONFIGURE VHF ANF EMS FOR RANGING</p> <p><u>VHF AM T/R-T/R</u></p> <p>VHF ANTENNA-RIGHT</p> <p>EMS FUNCTION-DV SET/VHF RNG</p> <p>EMS MODE-BACKUP/VHF RNG</p>			9311	INSERTION OR AIM
	2	POO							-62-

GET H:M:S	L T N G	S T D E	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
INS+05MIN		3	P00	ACCEPT STDN UPLINK UP TLM CM-ACCEPT VERIFY UPLINK ACTIVITY LT-ON MONITOR UPLINK		XX XX	XXXXX XXXXX XXXXX	2	UPLINK ACT LT-ON
			P27			BB BB		2	UPLINK ACT LT-OFF OBTAIN CSI&TPI TIG FROM LM
CSI-40MIN		4	P00	INITIATE P32 AND RNDZ NAVIGATION V37E 32E		F 50 25	00017		
			P20	PRO		F 50 18	+XXX.XX +XXX.XX +XXX.XX		
			P32	PRO		06 18	+XXX.XX +XXX.XX +XXX.XX		
				MONITOR AUTO MNVR VHF RNG-RESET		F 06 11	+00XXX. +000XX. +0XX.XX	9	
				V25E +XXXE +XXE +XXXXE		F 06 11	+00XXX. +000XX. +0XX.XX		LOAD CSI TIG
				PRO		F 06 55	+00001 +208.30 +130.00		

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
CSI-20MIN	5	P32			PRO  V25E +XXXE +XXE +XXXXE  PRO  <u>START SEXTANT MARKING</u> OPTICS ZERO-OFF OPTICS MODE-MAN OHC-CENTER LM IN SXT TAKE ONE SXT MARK PER MIN  <u>START RECYCLE SEQUENCE</u> OPTICS MODE-CMC V32E  RECORD DATA PRO  RECORD DATA PRO	F 06 37  F 06 37  F 16 45  F 06 90  F 06 81  F 16 45	+00XXX. +000XX. +0XX.XX  +00XXX. +000XX. +0XX.XX  +XXB00 -XXBXX -00001  +XXX.XX +XXXX.X +XXXX.X  +XXXX.X +XXXX.X +0000.0  +XXBXX -19BXX -00001	122 122 122 122 122	LOAD TPI TIG

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
CSI-12MIN				6 P32	<p><u>CONTINUE SEXTANT MARKING</u></p> <p>OPTICS MODE-MAN</p> <p>OHC-CENTER LM IN SXT</p> <p>TAKE ONE SXT MARK PER MIN</p> <p><u>COMPUTE CSI SOLUTION AND TERMINATE NAV</u></p> <p>OPTICS SPEED-HI</p> <p>OHC-DRIVE TRUNNION TO LESS THAN 10 DEG</p> <p>OPTICS ZERO-ZERO</p> <p>OPTICS SPEED-LO</p> <p>OPTICS MODE-CMC</p> <p>PRO</p> <p>RECORD DATA</p> <p>PRO</p> <p>RECORD DATA</p> <p>PRO</p> <p>*****</p> <p>CONTINUE WITH STEP 1 OF THE COMMON COELLIPTIC SEQUENCE, SECTION 3.3.3</p> <p>*****</p>	F 06 90	+XXXX.XX +XXXX.X +XXXX.X	122 122		

### 3.3.3 COMMON COELLIPTIC SEQUENCE

The common Coelliptic sequence begins immediately after the CSI final comp and continues through the post-docking switch configuration. This sequence is common to both the One Rev and Two Rev rendezvous techniques.

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
CSI-10MIN			1	P32	<pre>***** COMMON COELLIPTIC SEQUENCE *****</pre> <u>BACKUP LM CSI BURN</u> PRO PRO MONITOR AUTO MNVR ALIGN GDC TO IMU ATT SET TW-SET TO IMU ANGLES ON FDAI 1 FDAI SELECT-1 FDAI SOURCE-ATT SET (VERIFY) ATT SET-IMU ATT SET TW-NULL FDAI 1 ERROR NEEDLES ATT SET-GDC GDC ALIGN PB-PUSH UNTIL NEEDLES NULLED FDAI SELECT-1/2 RECORD P76 DATA	F 16 45	+XXBXX -10BXX +XXX.XX			1 1 1 1 1 1 1 1 1 1

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p><u>CONFIGURE EMS FOR BURN</u></p> <p>EMS MODE-STBY</p> <p>EMS FUNCTION-OFF</p> <p>-DV SET/VHF RNG</p> <p>LOAD DV MINUS 11 FPS IN EMS</p> <p>EMS FUNCTION-DV</p> <p><u>CONFIGURE SCS</u></p> <p>CB STAB CONT SYS(ALL)-CLOSE</p> <p>CB SPS(12)-CLOSE</p> <p>MANUAL ATTITUDE(3)-RATE CMD(VERIFY)</p> <p>RATE-LOW(VERIFY)</p> <p>DV CG-CSM(VERIFY)</p> <p>SPS HE VLVS(BOTH)-AUTO(VERIFY)</p> <p>CHECK N2 A AND N2 B</p> <p><u>TVC PREPARATION</u></p> <p>SCS TVC(BOTH)-RATE CMD(VERIFY)</p> <p>TVC GIMBAL DRIVE(BOTH)-AUTO(VERIFY)</p> <p>MAIN BUS TIE(2)-ON</p> <p>TVC SERVO POWER 1-AC1/MNA</p> <p>TVC SERVO POWER 2-AC2/MNB</p> <p>ROT CONTR PWR NORMAL 2-AC</p> <p>ROT CONTR PWR DIRECT 2-OFF(VERIFY)</p> <p>ATT DEADBAND-MIN</p> <p>BMAG MODE(3)-ATT 1/RATE 2</p> <p>SC CONT-SCS</p> <p>RHC 2-ARMED</p>			1 1 1 1 1	8 8 1 1 1 3 3	

GET H:M:S	L N D G	S T E P	S T R O	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p><u>PRIMARY TVC CHECK</u></p> <p>SPS GIMBAL MOTORS PITCH 1-START/ON YAW 1-START/ON</p> <p>VERIFY TRIM CONTROL AND SET</p> <p>VERIFY MTVC</p> <p>SC CONT-CMC</p> <p>THC-CLOCKWISE</p> <p>VERIFY NO MTVC</p> <p><u>SECONDARY TVC CHECK:</u></p> <p>SPS GIMBAL MOTORS PITCH 2-START/ON YAW 2-START/ON</p> <p>SET GPI TRIM</p> <p>VERIFY MTVC</p> <p>THC-NEUTRAL</p> <p>VERIFY NO MTVC</p> <p>VERIFY GPI RETURNS TO 0,0</p> <p>ROT CONTR PWR NORMAL(BOTH)-AC/DC DIRECT(BOTH)-MNA/MNB</p> <p>BMAG MODE(3)-RATE 2</p> <p>PRO</p> <p>MONITOR TRIM MANEUVER</p> <p>BMAG MODE(3)-ATT 1/RATE 2</p>	06 18	+XXX.XX +XXX.XX +XXX.XX		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	

GET H:M:S	L G	S T N	S T D	P R O G	OPERATIONS	V-M DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					ENTER PRO MONITOR GPI RESPONSE:  FDAI SCALE-5/1(VERIFY) VERIFY DET SET RATE-HIGH EMS MODE-NORMAL TRANS CONTR PWR-ON	F 50 25  BB BB 06 40	00204  -XXBXX +XXXX.X +0000.0	1 1 1 1 1	
CSI-01MIN					MONITOR DSKY BLANK	BB BB  06 40	-00B29 +XXXX.X +0000.0		AVE G ON
CSI-35SEC					CHECK PIPA BIAS LESS THAN 2 FPS FOR 5 SEC	F 99 40	-00B05 +XXXX.X +0000.0		'ENGINE ON ENABLE REQUEST
CSI-30SEC						F 16 85	+XXXX.X +XXXX.X +XXXX.X		LM CSI
CSI-05SEC									
CSI TIG					VERIFY LM BURN COMPLETE ENTER				

GET H:M:S	L N G	S T D	S T E	P R O	P G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
CSI+02MIN						<p>SPS GIMBAL MOTORS(4)-OFF SEQUENTIALLY      TVC SERVO POWER(BOTH)-OFF      RHC 2-LOCKED      TRANS CONTR PWR-OFF      ROT CONTR PWR DIRECT(BOTH)-OFF      CB DIRECT ULLAGE(BOTH)-OPEN      CB SPS PITCH 1 AND YAW 1-OPEN      RECORD DV COUNTER AND RESIDUALS      EMS FUNCTION-OFF      EMS MODE-STBY</p> <p><u>P40 UPDATE LM S.V. IN THE CMC</u>  <u>PRO</u></p> <p>ATT DEADBAND-MAX      RATE-LOW      BMAG MODE(3)-RATE 2      MAIN BUS TIE(2)-OFF</p> <p><u>P76 PRO</u></p>	F 06 33	+00XXX. +000XX. +0XX.XX	1 7  1 1 8 8  1 1	

GET H:M:S	L T N G	S T D N	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
CSI+03MIN		2	P76	<u>INITIATE P36 AND RNDZ NAVIGATION</u> <u>PRO</u> <u>P36</u> <u>PRO</u>  <u>MONITOR AUTO MNVR</u>  <u>RECONFIGURE EMS FOR RANGING</u> <u>EMS FUNCTION-DV SET/VHF RNG</u> <u>EMS MODE-BACKUP/VHF RNG</u> <u>VHF RNG-RESET</u>  <u>V25E +XXE +XXE +XXXXE</u>  <u>PRO</u>	F 50 18  06 18  F 06 33  F 06 33  F 16 45	+XXX.XX +XXX.XX +XXX.XX  +XXX.XX +XXX.XX +XXX.XX  +00XXX. +00XXX. +0XX.XX  +00XXX. +00XXX. +0XX.XX  +XXBXX -XXBXX -00001	1 1 9	OVERWRITE WITH LM PC TIG

GET H:M:S	L T N G	S T D N	S E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
PC-09MIN					<u>START SEXTANT MARKING</u> OPTICS ZERO-OFF OPTICS MODE-MAN OHC-CENTER LM IN SXT TAKE ONE SXT MARK PER MIN <u>COMPUTE PC SOLUTION AND TERMINATE NAV</u> <u>OPTICS SPEED-HI</u> <u>OHC-DRIVE TRUNNION TO LESS THAN 10 DEG</u> <u>OPTICS ZERO-ZERO</u> <u>OPTICS SPEED-LO</u> <u>OPTICS MODE-CMC</u> PRO <u>RECORD DATA</u> PRO <u>RECORD DATA</u>			122 122 122		
	3	P36				F 06 90	+XXX.XX +XXXX.X +XXXX.X	122 122 122 122 122		
	4	P36			<u>BYPASS PC MANEUVER</u> <u>V22E +E</u>	F 06 81	+0000.0 +XXXX.X +0000.0		IF DVY GREATER THAN 5 FPS, BUT LESS THAN 7 FPS, SEE SECTION 4.1.1. IF DVY GREATER THAN OR EQUAL TO 7 FPS, SEE SECTION 4.1.2.	

GET H:M:S	L G	S N	S D	P E	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
						PRO  P76 PRO  PRO  5 P33 PRO <u>INITIATE P33 AND RNDZ NAVIGATION</u>  V25E +XXXE +XXE +XXXXE  PRO	F 16 45  F 06 33  F 06 84  F 06 13  F 06 13  F 16 45	+XXBXX -08BXX +XXX.XX  +00XXX. +000XX. +0XX.XX  +0000.0 +0000.0 +0000.0  +00XXX. +000XX. +0XX.XX  +00XXX. +000XX. +0XX.XX  +XXBXX -XXBXX -00001			

GET H:M:S	L N G	S T D	S T E	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
CDH-20MIN		6	P33		<p><u>START SEXTANT MARKING</u></p> <p>OPTICS ZERO-OFF</p> <p>OPTICS MODE-MAN</p> <p>OHC-CENTER LM IN SXT</p> <p>TAKE ONE SXT MARK PER MIN</p> <p><u>START RECYCLE SEQUENCE</u></p> <p>OPTICS MODE-CMC</p> <p>V32E</p> <p>RECORD DATA</p> <p>PRO</p> <p>RECORD DATA</p> <p>PRO</p> <p><u>CONTINUE SEXTANT MARKING</u></p> <p>OPTICS MODE-MAN</p> <p>OHC-CENTER LM IN SXT</p> <p>TAKE ONE SXT MARK PER MIN</p>	F 06 90  F 06 81  F 16 45	+XXXX.XX +XXXXX.X +XXXXX.X  +XXXXX.X ±XXXXX.X ±XXXXX.X  +XXBXX -19BXX -00001	122 122 122  122  122		

GET H:M:S	L G	S T N	S T D	P R O	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
CDH-12MIN		7	P33		<p><u>COMPUTE CDH SOLUTION AND TERMINATE NAV</u></p> <p>OPTICS SPEED-HI            OHC-DRIVE TRUNNION TO LESS THAN 10 DEG            OPTICS ZERO-ZERO            OPTICS SPEED-LO            OPTICS MODE-CMC</p> <p>PRO</p> <p>RECORD DATA</p> <p>PRO</p> <p>RECORD DATA</p> <p>PRO</p>			122 122 122 122 122	

GET H:M:S	L N G	S T D	S T E	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
CDH-10MIN		8	P33		BACKUP LM CDH BURN	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
			P40		PRO	06 18	+XXX.XX +XXX.XX +XXX.XX		
					PRO	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
					MONITOR AUTO MNVR				
					ALIGN GDC TO IMU			1	
					ATT SET TW-SET TO IMU ANGLES ON FDAI 1			1	
					FDAI SELECT-1			1	
					FDAI SOURCE-ATT SET			1	
					ATT SET-IMU			1	
					ATT SET TW-NULL FDAI 1 ERROR NEEDLES			1	
					ATT SET-GDC			1	
					GDC ALIGN PB-PUSH UNTIL NEEDLES NULLED			1	
					FDAI SELECT-1/2			1	
					RECORD P76 DATA				OBTAINT CDH P76 FROM CDR
					CONFIGURE EMS FOR BURN			1	
					EMS MODE-STBY			1	
					EMS FUNCTION-OFF			1	
					EMS FUNCTION-DV SET/VHF RNG			1	
					LOAD DV MINUS 11 FPS IN EMS			1	
					EMS FUNCTION-DV			1	

GET H:M:S	L N G	S D N	S E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p><u>CONFIGURE SCS</u></p> <p>CB STAB CONT SYS(ALL)-CLOSE      CB SPS(12)-CLOSE      MANUAL ATTITUDE(3)-RATE CMD(VERIFY)      RATE-LOW(VERIFY)      DV CG-CSM(VERIFY)      SPS HE VLVS(BOTH)-AUTO(VERIFY)      CHECK N2 A AND N2 B</p> <p><u>TVC PREPARATION</u></p> <p>SCS TVC(BOTH)-RATE CMD(VERIFY)      TVC GIMBAL DRIVE(BOTH)-AUTO(VERIFY)      MAIN BUS TIE(2)-ON      TVC SERVO POWER 1-AC1/MNA      TVC SERVO POWFR 2-AC2/MNB      ROT CONTR PWR NORMAL 2-AC      ROT CONTR PWR DIRECT 2-OFF(VERIFY)      ATT DEADBAND-MIN      BMAG MODE(3)-ATT 1/RATE 2      SC CONT-SCS      RHC 2-ARMED</p> <p><u>PRIMARY TVC CHECK</u></p> <p>SPS GIMBAL MOTORS PITCH 1-START/ON                                        YAW 1-START/ON      VERIFY TRIM CONTROL AND SET      VERIFY MTVC      SC CONT-CMC      THC-CLOCKWISE      VERIFY NO MTVC</p>				8 8 1 1 1 3 3	

GET H:M:S	L N G	S T D	S T E	P R O	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p>SECONDARY TVC CHECK:            SPS GIMBAL MOTORS PITCH 2-START/ON            YAW 2-START/ON</p> <p>SET GPI TRIM            VERIFY MTVC            THC-NEUTRAL            VERIFY NO MTVC            VERIFY GPI RETURNS TO 0,0            ROT CONTR PWR NORMAL(BOTH)-AC/DC            ROT CONTR PWR DIRECT(BOTH)-MNA/MNB            BMAG MODE(3)-RATE 2</p> <p>PRO</p> <p>MONITOR TRIM MANEUVER</p> <p>BMAG MODE(3)-ATT 1/RATE 2</p>	06 18  F 50 18	+XXX.XX +XXX.XX +XXX.XX  +XXX.XX +XXX.XX +XXX.XX	1  1  1  1  1		

GET H:M:S	L T N G	S T D N	P R O P	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
				ENTER PRO MONITOR GPI RESPONSE:	F 50 25  BB BB 06 40	00204  -XXBXX +XXXX.X +0000.0		
CDH-01MIN				FDAI SCALE-5/1 (VERIFY) VERIFY DET SET RATE-HIGH EMS MODE-NORMAL TRANS CONTR PWR-ON			1 1 1 1	
CDH-35SEC CDH-30SEC				MONITOR DSKY BLANK	BB BB  06 40	-00B29  +XXXX.X +0000.0		AVE G ON  1
				CHECK PIPA BIAS LESS THAN 2 FPS FOR 5 SEC	F 99 40	-00B05  +XXXX.X +0000.0		ENGINE ON ENABLE REQUEST
CDH-05SEC				VERIFY LM BURN COMPLETE ENTER	F 16 85	+XXXX.X  +XXXX.X +XXXX.X		LM CDH
CDH TIG								

GET H:M:S	L N G	S T D	S T E	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
CDH+01MIN		9	P40		SPS GIMBAL MOTORS(4)-OFF SEQUENTIALLY TVC SERVO POWER(BOTH)-OFF RHC 2-LOCKED TRANS CONTR PWR-OFF ROT CONTR PWR DIRECT(BOTH)-OFF CB DIRECT ULLAGE(BOTH)-OPEN CB SPS PITCH 1 AND YAW 1-OPEN RECORD DV COUNTER AND RESIDUALS EMS FUNCTION-OFF EMS MODE-STBY UPDATE LM S.V. IN THE CMC PRO	F 06 33	+00XXX. +000XX. +0XX.XX	1 7 1 1 8 8 1 1		
			P76		ATT DEADBAND-MAX RATE-LOW BMAG MODE(3)-RATE 2 MAIN BUS TIE(2)-OFF PRO	F 06 84	+XXXXX.X +XXXXX.X +XXXXX.X	1 1 1 5		

GET H:M:S	L G	S T	S D	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
CDH+03MIN		10	P76	PRO	<u>INITIATE P34 AND RNDZ NAVIGATION</u>	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
			P34	PRO		06 18	+XXX.XX +XXX.XX +XXX.XX		
				MONITOR AUTO MNVR					
				RECONFIGURE EMS FOR RANGING					
				EMS FUNCTION-DV SET/VHF RNG					
				EMS MODE-BACKUP/VHF RNG					
				VHF RNG-RESET					
				PRO	F 06 37	+00XXX. +000XX. +0XX.XX		1	
				V22E +20830E	F 06 55	+00000 +000.00 +130.00		1	
				PRO	F 06 55	+00000 +208.30 +130.00		9	
					F 16 45	+XXBXX -XXBXX -00001			SPECIFY ELEV ANG OPTION

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI-20MIN			11	P34	<p><u>START SEXTANT MARKING</u></p> <p>OPTICS ZERO-OFF</p> <p>OPTICS MODE-MAN</p> <p>OHC-CENTER LM IN SXT</p> <p>TAKE ONE SXT MARK PER MIN</p> <p><u>START RECYCLE SEQUENCE</u></p> <p>OPTICS MODE-CMC</p> <p>V32E</p> <p>RECORD DATA</p> <p>PRO</p> <p>RECORD DATA</p> <p>PRO</p> <p>RECORD DATA</p> <p>PRO</p> <p><u>CONTINUE SEXTANT MARKING</u></p> <p>OPTICS MODE-MAN</p> <p>OHC-CENTER LM IN SXT</p> <p>TAKE ONE SXT MARK PER MIN</p>	F 06 37	+00XXX. +000XX. +0XX.XX	122	

GET H:M:S	L G	S T N G	S T D E N	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI-12MIN		12	P34		<u>COMPUTE TPI SOLUTION AND TERMINATE NAV</u> OPTICS SPEED-HI OHC-DRIVE TRUNNION TO LESS THAN 10 DEG OPTICS ZERO-ZERO OPTICS SPEED-LO OPTICS MODE-CMC PRO V25E +XXXXE +XXE +XXXXE PRO RECORD DATA PRO RECORD DATA PRO RECORD DATA			122 122 122 122 122	OBTAİN TPI TIG FROM LM  OVERWRITE WITH LM TPI TIG

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
TPI-10MIN					PRO <u>BACKUP LM TPI BURN</u> PRO PRO MONITOR TRIM MANEUVER <u>ALIGN GDC</u> ATT SET TW-SET TO IMU ANGLES ON FDAI 1 FDAI SELECT-1 FDAI SOURCE-ATT SET(VERIFY) ATT SET-IMU ATT SET TW-NULL FDAI 1 ERROR NEEDLES ATT SET-GDC GDC ALIGN PB-PUSH UNTIL NEEDLES NULLED FDAI SELECT-1/2 <u>RECORD P76 DATA</u>	F 16 45 F 50 18 06 18 F 50 18	+XXBXX -10BXX +XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX	1 1 1 1 1 1 1 1		OBTAINTPI P76 FROM CDR

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					CONFIGURE EMS EMS MODE-STBY EMS FUNCTION-OFF -DV SET/VHF RNG LOAD DV MINUS 11 FPS IN EMS EMS FUNCTION-DV			1 1 1 1 1 1	
					CONFIGURE SCS CB STAB CONT SYS(ALL)-CLOSE CB SPS(12)-CLOSE MANUAL ATTITUDE(3)-RATE CMD(VERIFY) RATE-LOW(VERIFY) DV CG-CSM(VERIFY) SPS HE VLVS(BOTH)-AUTO(VERIFY) CHECK N2 A AND N2 B			8 8 1 1 1 3 3	
				PRO		06 18	+XXX.XX +XXX.XX +XXX.XX		
					MONITOR TRIM MANEUVER	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
					ENTER	F 50 25	00204		
					ENTER	06 40	-XXBXX +XXXX.X +0000.0		
					FDAI SCALE-5/1(VERIFY) VERIFY DET SET			1 1	

GET H:M:S	L N G	S T D	S T E	P R O	P G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI-35SEC TPI-30SEC						MONITOR DSKY BLANK  CHECK PIPA BIAS LESS THAN 2 FPS FOR 5 SEC	BB BB  06 40	-00B29 +XXXX.X +0000.0		AVE G ON
TPI-05SEC							F 99 40	-00B05 +XXXX.X +0000.0		ENGINE ON ENABLE REQUEST
TPI TIG						CONFIRM LM BURN COMPLETE  ENTER	F 16 85	+XXXX.X +XXXX.X +XXXX.X	1 8	LM TPI  IF THE LM CANNOT APPLY THE TPI BURN, SEE SECTION 4.2.1.
TPI+01MIN	14	P40	PRO	PRO	PRO	EMS FUNCTION-OFF CB SPS PITCH 1 AND YAW 1-OPEN  UPDATE LM S.V. IN THE CMC	F 06 33	+00XXX. +000XX. +0XX.XX		
		P76					F 06 84	+XXXX.X +XXXX.X +XXXX.X		

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI+03MIN		15	P76	PRO	<u>INITIATE P35 AND RNDZ NAVIGATION</u> <u>CONFIGURE EMS FOR RANGING</u> <u>EMS FUNCTION-DV SET/VHF RNG</u> <u>EMS MODE-BACKUP/VHF RNG</u> <u>VHF RNG-RESET</u>			1 1 9	
			P35	PRO	<u>START SEXTANT MARKING</u> <u>OPTICS ZERO-OFF</u> <u>OPTICS MODE-MAN</u> <u>OHC-CENTER LM IN SXT</u> <u>TAKE ONE SXT MARK PER MIN</u>	F 16 45	+XXBXX +03BXX -00001	122 122 122	-88
TPI+12MIN		16	P35	PRO	<u>COMPUTE MCC1 SOLUTION AND TERMINATE NAV</u> <u>OPTICS MODE-CMC</u>	F 06 81	+XXXX.X +XXXX.X +XXXX.X	122	
				PRO	<u>RECORD DATA</u>	F 16 45	+09B09 -02BXX +XXX.XX		

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI+13MIN		17	P35	<u>BACKUP LM MCC1 BURN</u> PRO		F 50 18	+XXX.XX +XXX.XX +XXX.XX		
MCC-35SEC MCC-30SEC			P41	ENTER		06 85	+XXXX.X +XXXX.X +XXXX.X		AVE G ON
				MONITOR DSKY BLANK		BB BB			
TPI+15MIN				VERIFY LM BURN COMPLETE		16 85	+XXXX.X +XXXX.X +XXXX.X		LM MCC1
TPI+16MIN		18	P41	<u>UPDATE LM S.V. IN THE CMC</u> PRO		F 16 85	+XXXX.X +XXXX.X +XXXX.X		IF THE LM CANNOT APPLY THE MCC1 BURN, SEE SECTION 4.2.2
			P76	PRO		F 06 33	+00XXX. +00XXX. +0XX.XX		
						F 06 84	+XXXX.X +XXXX.X +XXXX.X		

GET H:M:S	L T N D G	S T E P	S T R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI+18MIN		19	P76	<u>INITIATE P35 AND RNDZ NAVIGATION</u>  PRO  P35	F 16 45	+09B09 +03BXX -00001	122 122	IF THE CSM IS ACTIVE AND TPF DELTA V > 55 FPS, SEE SECTION 4.2.3
TPI+27MIN		20	P35	<u>COMPUTE MCC2 SOLUTION AND TERMINATE NAV</u> PRO  OPTICS MODE-MAN OHC-CENTER LM IN SXT TAKE ONE SXT MARK PER MIN  OPTICS SPEED-HI OHC-DRIVE TRUNNION TO LESS THAN 10 DEG OPTICS ZERO-ZERO OPTICS SPEED-LO OPTICS MODE-CMC  RECORD DATA PRO	F 06 81	+XXXX.X +XXXX.X +XXXX.X	122 122 122 122 122 122	-06

GET H:M:S	L T N D G	S T D E N	P R O P G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI+28MIN		21	P35	BACKUP LM MCC2 BURN PRO	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
			P41	ENTER	06 85	+XXXX.X +XXXX.X +XXXX.X		
MCC-35SEC				MONITOR DSKY BLANK	BB BB			AVE G ON
MCC-30SEC					16 85	+XXXX.X +XXXX.X +XXXX.X		
TPI+30MIN					F 16 85	+XXXX.X +XXXX.X +XXXX.X		LM MCC2
				VERIFY LM BURN COMPLETE				IF THE LM CANNOT APPLY THE MCC2 BURN, SEE SECTION 4.2.2.
TPI+31MIN	22	P41	PRO	UPDATE LM S.V. IN THE CMC	F 06 33	+00XXX. +000XX. +0XX.XX		
		P76	PRO		F 06 84	+XXXX.X +XXXX.X +XXXX.X		
TPI+32MIN	23	P76	PRO	MANEUVER TO COAS TRACK ATTITUDE	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
		P79						

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI+35MIN				POO	V37E 00E V49E PRO PRO MONITOR MANEUVER ENTER V83E	BB BB F 06 22 F 50 18 06 18 F 50 18 BB BB F 16 54	+XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX +XXX.XX	1 1 1 1	

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
TPI+40MIN					TRANS CONTR PWR-ON ROT CONTR PWR DIRECT(BOTH)-MNA/MNB SC CONT-CMC(VERIFY) AUTO RCS SELECT(16)-MNA/MNB CB DOCK PROBE(2)-CLOSE DOCKING PROBE RETRACT(BOTH)-OFF(CTR) (VERIFY) DOCKING PROBE-RETRACT DOCKING PROBE EXTD/REL TB (2) - GRAY (VERIFY) CB SEQ EVENTS CONT SYS(4)-CLOSE COAS POWER-ON(UP)(VERIFY) EXTERIOR LIGHTS RUN/EVA-ON(UP)(VERIFY)			1 1 8 8 2 2 2 8 15 2		IF CSM ACTIVE BRAKING, SEE SECTION 4.2.4.
TPI+42MIN					<u>PHOTOGRAPH LM</u> UTILITY POWER-ON(UP)(VERIFY) TV-ON DAC-ON BEGIN PHOTOS WITH DAC AND TV			15	TPF	

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI+49MIN		25	P00		MANEUVER FOR CSM INSPECTION V49E	F 06 22	+XXX.XX +XXX.XX +XXX.XX		LOAD DESIRED ATTITUDE
					V25E +XXXXXE +XXXXXE +XXXXXE	F 06 22	+XXX.XX +XXX.XX +XXX.XX		
					PRO	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
					PRO	06 18	+XXX.XX +XXX.XX +XXX.XX		
					MONITOR MANEUVER	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
					ENTER	BB BB			
TPI+60MIN		26	P00		MANEUVER TO DOCKING ATTITUDE V49E	F 06 22	+XXX.XX +XXX.XX +XXX.XX		LOAD DOCKING ATTITUDE
					V25E +XXXXXE +XXXXXE +XXXXXE	F 06 22	+XXX.XX +XXX.XX +XXX.XX		

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					PRO	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
					PRO	06 18	+XXX.XX +XXX.XX +XXX.XX		
					MONITOR MANEUVER	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
					ENTER	BB BB			
					REACQUIRE STDN HGA				
27	POO	ARM PYROS			CUE STDN FOR LOGIC ARM SEQ EVENTS CONT SYSTEM LOGIC(BOTH)- ON(UP)			8	STDN GO FOR PYRO ARM
					SEQ EVENTS CONT SYSTEM PYRO ARM(BOTH)- ON(UP)			8	
TPI+64MIN	28	POO			<u>PERFORM DOCKING ACTIVITIES</u> V37E 47E	F 16 83	+0000.0 +0000.0 +0000.0		
		P47			INITIATE LM PHOTOGRAPHY DAC-ON TV-ON PHOTOGRAPH LM MNVR				

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
TPI+68MIN					<p><u>TRANSLATE TO CAPTURE LATCH</u>  THC-ARMED  THC-MINIMUM THRUST FORWARD</p> <p>THC-LOCKED</p> <p><u>PERFORM AT CAPTURE</u>  DOCKING PROBE EXT/REL TB(2)-BP(VERIFY)  REPORT CAPTURE TO LM  SC CONT-CMC(VERIFY)  CMC MODE-FREE  ALLOW PROBE TO DAMP S/C MOTION(10 SEC)  DOCKING PROBE RETRACT SEC-1  PRIM-2(IF REQ'D)</p> <p><u>PERFORM AT DOCK LATCH</u>  DOCKING PROBE EXTD/REL TB(2)-GRAY  (VERIFY)</p> <p><u>PERFORM AT HARD DOCK</u>  SEQ EVENTS CONT SYS PYRO ARM(BOTH)-SAFE  LOGIC(BOTH)-OFF  CB SEQ EVENTS CONT SYS(4)-OPEN</p> <p>THC-LOCKED  RHC 2-LOCKED(VERIFY)  BMAG MODE(3)-RATE 2(VERIFY)  DOCKING PROBE-OFF  DOCKING PROBE RETRACT(BOTH)-OFF(CTR)  EXTERIOR LIGHTS RUN/EVA-OFF</p>	F 16 83	+XXXX.X +XXXX.X +XXXX.X		2 1 1 2 2 2 8 8 8 2 2 2	DOCKING  WHEN WITHIN +3 DEG OF DOCKING ATTITUDE

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					COAS POWER-OFF AUTO RCS SELECT ROLL(4)-OFF TRANS CONTR PWR-OFF ROT CONTR PWR DIRECT(BOTH)-OFF VHF RANGING-OFF			15 8 1 1 3	
					<u>TERMINATE LM PHOTOGRAPHY AND P47</u>				
					DAC-OFF TV-OFF				
					PRO	F 37 BB			
					OOE	BB BB			
DOCK+2MIN	29	POO			<u>RECONFIGURE DAP</u>				
					V48E	F 04 46	11102 X1111		
					V21E 61111E	F 04 46	61111 X1111		
					PRO	F 06 47	+XXXXXX. +XXXXXX.		
					PRO	F 06 48	+XXX.XX +XXX.XX		
					PRO	BB BB			
DOCK+3MIN	30	POO			<u>CONFIGURE SWITCHES FOR POST-DOCKING</u>			1 100	
					CMC MODE-AUTO RNDZ XPNDR-OFF				

#### 4.0 CMP SUPPLEMENTARY PROCEDURES

The supplemental CMP procedures are non-nominal procedures for backing up a LM active plane change burn, performing a CSM active burn, or obtaining a LM insertion state vector uplink. The format used for the procedures is identical to the format used for the abort detailed procedures (Section 3.3).

#### 4.1 PLANE CHANGE BURNS

During a coelliptic rendezvous, the LM is scheduled to apply a plane change burn 30 minutes prior to the CDH maneuver if the required PC DV is greater than five feet per second. The CMC MINKEY logic schedules either an RCS or an SPS burn to enable the CMP to backup the maneuver. The PC is not applied if it is less than five feet per second. In this event the CMP bypasses the MINKEY PC burn sequence by loading N81 with zeros.

##### 4.1.1 RCS PLANE CHANGE

If the CMC computed CSM PC DV is less than seven feet per second, the MINKEY logic will specify that the CMP backup the LM PC with P41. To apply the burn the CMP would use the following procedures to burn the P41 N85 values to zero.

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-M DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
PC-35SEC				P36	***** RCS PLANE CHANGE *****	F 06 81	+0000.0 +000X.X +0000.0		
PC-30SEC				P52	PRO	F 16 45	+XXBXX -XXBXX +XXX.XX		
				P41	PRO	F 06 22	+XXX.XX +XXX.XX +XXX.XX		
					ENTER	F 50 25	00020		BYPASS IMU TORQUE
					ENTER	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
					MONITOR DSKY BLANK	06 85	+XXXX.X +XXXX.X +XXXX.X		BYPASS MNVR
PC TIG						BB BB	—		
						16 85	+XXXX.X +XXXX.X +XXXX.X		AVE G ON
					VERIFY LM BURN COMPLETE	F 16 85	+XXXX.X +XXXX.X +XXXX.X		LM PC

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					P36 UPDATE LM S.V. IN CMC PRO  P76 PRO ***** CONTINUE WITH STEP 5 OF THE COMMON COELLIPTIC SEQUENCE, SECTION 3.3.3 *****	F 06 33	+00XXX. +000XX. +0XX.XX	F 06 84	+0000.0 +000X.X +0000.0	

#### 4.1.2 SPS PLANE CHANGE

If the CMC computed CSM PC DV is equal to or greater than seven feet per second, the MINKEY logic will provide the option to torque the platform so that the PC burn can be made with the SPS engine. The following procedures for the PC include torquing the platform, backing up the burn, and torquing the platform back to its original orientation.

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					* * * * * * * * * * SPS PLANE CHANGE * * * * * * * * * *				
				P36	PRO  PRO	F 06 81  F 16 45  F 06 22	+0000.0 +XXXX.X +0000.0  +XXBXX -XXBXX +XXX.XX  +XXX.XX +XXX.XX +XXX.XX		
				P52	<u>ALIGN GDC</u> ATT SET TW-SET TO ROLL-90 OR 270 DEG PITCH- 0 OR 180 DEG YAW- 0 DEG FDAI SELECT-1 FDAI SOURCE-ATT SET(VERIFY) ATT SET-GDC(VERIFY) GDC ALIGN PB-PUSH UNTIL NEEDLES NULLED FDAI SELECT-1/2  CMC MODE-FREE			1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
					PRO  PRO  MONITOR PLATFORM TORQUING	F 50 25  F 16 20	00020  +XXX.XX +XXX.XX +XXX.XX	1	TORQUE PLATFORM

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
			P40		CMC MODE-AUTO PRO MONITOR MANEUVER <u>RECORD P76 DATA</u> <u>CONFIGURE EMS</u> EMS MODE-STBY EMS FUNCTION-OFF EMS FUNCTION-DV SET/VHF RNG LOAD DV MINUS 11 FPS INTO EMS EMS FUNCTION-DV  <u>CONFIGURE SCS</u> CB STAB CONT SYS(ALL)-CLOSE CB SPS(12)-CLOSE MANUAL ATTITUDE(3)-RATE CMD(VERIFY) RATE-LOW(VERIFY) DV CG-CSM(VERIFY) SPS HE VLVS(BOTH)-AUTO(VERIFY) CHECK N2 A AND N2 B	F 50 18  06 18  F 50 18	+XXX.XX +XXX.XX +XXX.XX  +XXX.XX +XXX.XX +XXX.XX  +XXX.XX +XXX.XX +XXX.XX	1	1 1 1 1 1  8 8 1 1 1 3 3	OBTAİN TPI P76 FROM CDR

GET H:M:S	L N G	S T D N	S T D P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p><b>TVC PREPARATION</b></p> <p>SCS TVC(BOTH)-RATE CMD(VERIFY)      TVC GIMBAL DRIVE(BOTH)-AUTO(VERIFY)      MAIN BUS TIE(2)-ON      TVC SERVO POWER 1-AC1/MNA      TVC SERVO POWER 2-AC2/MNB      ROT CONTR PWR NORMAL 2-AC      ROT CONTR PWR DIRECT 2-OFF(VERIFY)      ATT DEADBAND-MIN      BMAG MODE(3)-ATT 1/RATE 2      SC CONT-SCS      RHC 2-ARMED</p> <p><b>PRIMARY TVC CHECK</b></p> <p>SPS GIMBAL MOTORS PITCH 1-START/ON      YAW 1-START/ON      VERIFY TRIM CONTROL AND SET      VERIFY MTVC      SC CONT-CMC      THC-CLOCKWISE      VERIFY NO MTVC</p> <p><b>SECONDARY TVC CHECK:</b></p> <p>SPS GIMBAL MOTORS PITCH 2-START/ON      YAW 2-START/ON</p> <p>SET GPI TRIM      VERIFY MTVC      THC-NEUTRAL      VERIFY NO MTVC      VERIFY GPI RETURNS TO 0,0      ROT CONTR PWR NORMAL(BOTH)-AC/DC      ROT CONTR PWR DIRECT(BOTH)-MNA/MNB      BMAG MODE(3)-RATE 2</p>			1 1 5 7 7 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
PC-01MIN					PRO  MONITOR TRIM MANEUVER  BMAG MODE(3)-ATT 1/RATE 2 ENTER  PRO MONITOR GPI RESPONSE:  FDAI SCALE-5/1(VERIFY) VERIFY DET SET RATE-HIGH EMS MODE-NORMAL TRANS CONTR PWR-ON THC-ARMED	06 18  F 50 18  F 50 25  BB BB 06 40	+XXX.XX +XXX.XX +XXX.XX  +XXX.XX +XXX.XX +XXX.XX  00204  -XXBXX +XXXX.X +0000.0	1	
PC-35SEC PC-30SEC					MONITOR DSKY BLANK  CHECK PIPA BIAS LESS THAN 2 FPS FOR 5 SEC	BB BB  06 40	-00B29 +XXXX.X +XXXX.X	1 1 1 1 1 1 1 1	AVE G ON

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
PC-05SEC						F 99 40	-00B05 +XXXX.X +0000.0		ENGINE ON ENABLE REQUEST	
PC TIG					CONFIRM LM BURN COMPLETE  ENTER  SPS GIMBAL MOTORS(4)-OFF SEQUENTIALLY TVC SERVO POWER(BOTH)-OFF RHC 2-LOCKED THC-LOCKED TRANS CONTR PWR-OFF ROT CONTR PWR DIRECT(BOTH)-OFF CB DIRECT ULLAGE(BOTH)-OPEN CB SPS PITCH 1 AND YAW 1-OPEN RECORD DV COUNTER AND RESIDUALS EMS FUNCTION-OFF EMS MODE-STBY  P40 UPDATE LM S.V. IN THE CMC PRO	F 16 85	+XXXX.X +XXXX.X +XXXX.X —	1 7	1 1 8 8	LM PC
					P76	F 06 33	+00XXX. +00XXX. +0XX.XX	1 1 1 5		
					ATT DEADBAND-MAX RATE-LOW BMAG MODE(3)-RATE 2 MAIN BUS TIE(2)-OFF					

GET H:M:S	L G	S T	S T	P R	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
	N D	T E	D P	O G					
					PRO				
					RHC-MANUALLY MANEUVER BACK TO ORIGINAL GDC ATTITUDE(IF REQUIRED)	F 06 84	+XXX.XX +XXX.XX +XXX.XX		
					PRO				
					P20	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
					PRO	06 18	+XXX.XX +XXX.XX +XXX.XX		
					MONITOR MANEUVER	F 06 22	+XXX.XX +XXX.XX +XXX.XX		
					PRO				

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p>CMC MODE-FREE</p> <p>PRO</p> <p>MONITOR PLATFORM TORQUING</p> <p>CMC MODE-AUTO</p> <p>RECONFIGURE EMS FOR RANGING</p> <p>EMS FUNCTION-DV SET/VHF RNG</p> <p>EMS MODE-BACKUP/VHF RNG</p> <p>VHF RNG-RESET</p> <p>* * * * *</p> <p>CONTINUE WITH STEP 5 OF THE COMMON</p> <p>COELLIPTIC SEQUENCE, SECTION 3.3.3</p> <p>* * * * *</p>	F 50 25	00020	1		TORQUE PLATFORM
						F 16 20	+XXX.XX +XXX.XX +XXX.XX	1		
								1		
								9		

#### 4.2 CSM ACTIVE BURNS

The CSM active burn procedures used by the CMP to perform TPI, MCC, and braking are presented. In all cases it is assumed that the LM has lost all translation capability and did not perform any part of the burn.

##### 4.2.1 TPI BURN

The following procedures for performing the TPI burn involve recalling P40, applying the CMC computed TPI burn and re-entering the MINKEY sequencer by calling P35.

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p>* * * * *</p> <p>TPI BURN</p> <p>* * * * *</p> <p>P40 <u>RECALL SPS THRUSTING PROGRAM</u></p> <p>V37E 40E</p> <p>P40</p> <p><u>TVC PREPARATION</u></p> <p>SCS TVC(BOTH)-RATE CMD(VERIFY)</p> <p>TVC GIMBAL DRIVE(BOTH)-AUTO(VERIFY)</p> <p>MAIN BUS TIE(2)-ON</p> <p>TVC SERVO POWER 1-AC1/MNA</p> <p>TVC SERVO POWER 2-AC2/MNB</p> <p>ROT CONTR PWR NORMAL 2-AC</p> <p>ROT CONTR PWR DIRECT 2-OFF(VERIFY)</p> <p>ATT DEADBAND-MIN</p> <p>BMAG MODE(3)-ATT 1/RATE 2</p> <p>SC CONT-SCS</p> <p>RHC 2-ARMED</p> <p><u>PRIMARY TVC CHECK</u></p> <p>SPS GIMBAL MOTORS PITCH 1-START/ON</p> <p>YAW 1-START/ON</p> <p>VERIFY TRIM CONTROL AND SET</p> <p>VERIFY MTVC</p> <p>SC CONT-CMC</p> <p>THC-CLOCKWISE</p> <p>VERIFY NO MTVC</p>	F 50 18	+XXX.XX +XXX.XX +XXX.XX	1 1 5 7 7 1 1 1 1 1 1 1 1 1 1 1 1 1 1	-101-	

GET H:M:S	L G	S N	S P	P R O G	OPERATIONS	V-M DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					SECONDARY TVC CHECK SPS GIMBAL MOTORS PITCH 2-START/ON YAW 2-START/ON SET GPI TRIM VERIFY MTVC THC-NEUTRAL VERIFY NO MTVC VERIFY GPI RETURNS TO 0,0 ROT CONTR PWR NORMAL(BOTH)-AC/DC ROT CONTR PWR DIRECT(BOTH)-MNA/MNB BMAG MODE(3)-RATE 2			1 1 1 1 1 1 1 1 1	
				PRO		06 18	+XXX.XX +XXX.XX +XXX.XX		
					MONITOR TRIM MANEUVER	F 50 18	+XXX.XX +XXX.XX +XXX.XX		
					BMAG MODE(3)-ATT 1/RATE 2 FDAI SCALE-5/1(VERIFY) VERIFY DET SET RATE-HIGH EMS MODE-NORMAL TRANS CONTR PWR-ON DV THRUST A(B)-NORMAL THC-ARMED			1 1 1 1 1 1 1	
				ENTER		F 50 25	00204		
				PRO		BB BB			PROG LT-ON(SLIPPED TIG)
					MONITOR GPI RESPONSE	06 40	+XXBXX +XXXX.X +0000.0		
					RESET				PROG LT-OFF

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI-35SEC TPI-30SEC					MONITOR DSKY BLANK  CHECK PIPA BIAS LESS THAN 2 FPS FOR 5 SEC	BB BB  06 40	-00B29 +XXXX.X +0000.0		AVE G ON
TPI-11SEC TPI-05SEC					THC-APPLY ULLAGE	F 99 40	-00B05 +XXXX.X +XXXX.X		ENGINE ON ENABLE REQUEST
TPI TIG				PRO	THC-TERMINATE ULLAGE AT TIG+1 SEC MONITOR CSM TPI BURN	06 40	-00BXX +XXXX.X +XXXX.X		
				PRO	DV THRUST A(B)-OFF	F 16 40	+00BXX +XXXX.X +XXXX.X	1	
						F 16 85	+XXXX.X +XXXX.X +XXXX.X		

GET H:M:S	L T N G	I S D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					SPS GIMBAL MOTORS(4)-OFF SEQUENTIALLY TVC SERVO POWER(BOTH)-OFF THC-NULL RESIDUALS	F 16 85	+ XXXX.X + XXXX.X + XXXX.X	1 7		
					THC-LOCKED RHC 2-LOCKED TRANS CONTR PWR-OFF ROT CONTR PWR DIRECT(BOTH)-OFF CB DIRECT ULLAGE(BOTH)-OPEN CB SPS PITCH 1 AND YAW 1-OPEN RECORD DV COUNTER AND RESIDUALS EMS FUNCTION-OFF EMS MODE-STBY				1 1 8 8	
					PRO	F 37 BB		1 1		
TPI+03MIN		P40			INITIATE P35 AND RNDZ NAVIGATION 35E	F 50 25	00017			
		P20 P35			ATT DEADBAND-MAX RATE-LOW BMAG MODE(3)-RATE 2 MAIN BUS TIE(2)-OFF			1 1 1 5		
					PRO	F 16 45	+XXBXX +03BXX -00001			

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p><u>CONFIGURE EMS FOR RANGING</u></p> <p>EMS FUNCTION-DV SET/VHF RNG</p> <p>EMS MODE-BACKUP/VHF RNG</p> <p>VHF RNG-RESET</p> <p><u>START SEXTANT MARKING</u></p> <p>OPTICS ZERO-OFF</p> <p>OPTICS MODE-MAN</p> <p>OHC-CENTER LM IN SXT</p> <p>TAKE ONE SXT MARK PER MIN</p> <p>* *</p> <p>FOR DIRECT ASCENT RENDEZVOUS, CONTINUE WITH STEP 23 OF SECTION 2.3. FOR AN ABORT, CONTINUE WITH STEP 16 OF SECTION 3.3.3.</p> <p>* *</p>			1 1 9	122 122 122	-114-

#### 4.2.2 MCC BURN

If the LM attempts to apply the MCC burn but fails, the CMP would use the following procedures to burn the P41 N85 values to zero.

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
MCC TIG					<p style="text-align: center;">* * * * *</p> MCC BURN <p style="text-align: center;">* * * * *</p>				
MCC+02MIN					P41 <u>VERIFY NO LM BURN</u> THC-ARMED RHC 2-ARMED TRANS CONTR PWR-ON  THC-NULL VG'S  THC-LOCKED RHC 2-LOCKED TRANS CONTR PWR-OFF  <u>UPDATE LM S.V. IN THE CMC</u> PRO  PRO  ***** FOR A DIRECT ASCENT RENDEZVOUS CONTINUE WITH STEP 26(30) OF SECTION 2.3. FOR AN ABORT, CONTINUE WITH STEP 19(23) OF SECTION 3.3.3. *****	F 16 85	+XXXXX.X +XXXXX.X +XXXXX.X	1	
						F 16 85	+00000.0 +00000.0 +00000.0		
						F 06 33	+00XXX. +00XXX. +0XX.XX	1	
						F 06 84	+00000.0 +00000.0 +00000.0		

#### 4.2.3 PRE-BRAKING SPS BURN

If the CSM is the active vehicle and an excessive TPF DV exists (Register 3 of N58 greater than 55 feet per second), the CMP should use the following procedures to perform a pre-braking burn. The burn procedures are initiated by recalling P34 after MCC-1. The burn is scheduled for TPI+37 minutes and a transfer angle equal to one-half the TPF DV in N58 is loaded into N55. The burn re-establishes the nominal closing rate at the desired range.

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
TPI+18MIN					<pre> * * * * * PRE-BRAKING SPS BURN * * * * *</pre> <p>COMPUTE TPI(2)TIG=TPI TIG+37 MIN      COMPUTE TRANSFER ANG=(TPF DELTA V)/2</p> <p><u>INITIATE P34 AND RNDZ NAVIGATION</u></p> <p>V93E      V37E 34E</p> <p>P20      P34</p> <p>PRO</p> <p>V25E +XXXE +XXE +XXXXE</p> <p>PRO</p> <p>V23E +XXXXXE</p> <p>PRO</p>					

GET H:M:S	L N G	S T D	S T E	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					P34 <u>START SEXTANT MARKING</u> OPTICS ZERO-OFF OPTICS MODE-MAN OHC-CENTER LM IN SXT TAKE ONE SXT MARK PER MIN			122 122 122	
TIG-10MIN				P34	<u>COMPUTE P34 SOLUTION AND TERMINATE NAV</u>  OPTICS SPEED-HI OHC-DRIVE TRUNNION TO LESS THAN 10 DEG OPTICS ZERO-ZERO OPTICS SPEED-LOW OPTICS MODE-CMC			122 122 122 122 122	
					PRO	F 06 55	+00000 +XXX.XX +XXX.XX		
					RECORD DATA	F 06 58	+XXXX.X +XXXX.X +XXXX.X		
					PRO	F 06 81	+XXXX.X +XXXX.X +XXXX.X		
					RECORD DATA	F 16 45	+XXBXX -08BXX +XXX.XX		
					PRO				
					RECORD DATA				
					PRO				

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TIG-08MIN				P34	RECONFIGURE DAP V48E  V21E 11103E  PRO  PRO  PRO	F 04 46  F 04 46  F 06 47  F 06 48  F 16 45	11102 X1111  11103 X1111  +XXXXX. +05900.  +XXX.XX +XXX.XX  +XXBXX -07BXX +XXX.XX		
TIG-07MIN				P34 P40	INITIATE P40 THRUSTING PROGRAM PRO  PRO  MONITOR MANEUVER	F 50 18  06 18  F 50 18	+XXX.XX +XXX.XX +XXX.XX  +XXX.XX +XXX.XX +XXX.XX  +XXX.XX +XXX.XX +XXX.XX		-120-

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
TIG-05MIN					<p><u>CONFIGURE EMS</u></p> <p>EMS MODE-STBY</p> <p>EMS FUNCTION-OFF</p> <p>EMS FUNCTION-DV SET/VHF RNG</p> <p>LOAD DV MINUS 11 FPS INTO EMS</p> <p>EMS FUNCTION-DV</p> <p><u>CONFIGURE SCS</u></p> <p>CB STAB CONT SYS(ALL)-CLOSE</p> <p>CB SPS(12)-CLOSE</p> <p>MANUAL ATTITUDE(3)-RATE CMD(VERIFY)</p> <p>RATE-LOW(VERIFY)</p> <p>DV CG-CSM(VERIFY)</p> <p>SPS HE VLVS(BOTH)-AUTO(VERIFY)</p> <p>CHECK N2 A AND N2 B</p> <p><u>TVC PREPARATION</u></p> <p>SCS TVC(BOTH)-RATE CMD(VERIFY)</p> <p>TVC GIMBAL DRIVE(BOTH)-AUTO(VERIFY)</p> <p>MAIN BUS TIE(2)-ON</p> <p>TVC SERVO POWER 1-AC1/MNA</p> <p>TVC SERVO POWER 2-AC2/MNB</p> <p>ROT CONTR PWR NORMAL 2-AC</p> <p>ROT CONTR PWR DIRECT 2-OFF(VERIFY)</p> <p>ATT DEADBAND-MIN</p> <p>BMAG MODE(3)-ATT 1/RATE 2</p> <p>SC CONT-SCS</p> <p>RHC 2-ARMED</p>				1 1 1 1 1 8 8 1 1 1 3 3	

GET H:M:S	L T N G	S T D E	S T P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p><u>PRIMARY TVC CHECK:</u></p> <p>SPS GIMBAL MOTORS PITCH 1-START/ON YAW 1-START/ON</p> <p>VERIFY TRIM CONTROL AND SET</p> <p>VERIFY MTVC</p> <p>SC CONT-CMC</p> <p>THC-CLOCKWISE</p> <p>VERIFY NO MTVC</p> <p><u>SECONDARY TVC CHECK:</u></p> <p>SPS GIMBAL MOTORS PITCH 2-START/ON YAW 2-START/ON</p> <p>SET GPI TRIM</p> <p>VERIFY MTVC</p> <p>THC-NEUTRAL</p> <p>VERIFY NO MTVC</p> <p>VERIFY GPI RETURN TO 0,0</p> <p>ROT CONTR PWR NORMAL(BOTH)-AC/DC DIRECT(BOTH)-MNA/MNB</p> <p>BMAG MODE(3)-RATE 2</p> <p>PRO</p> <p>MONITOR TRIM MANEUVER</p> <p>BMAG MODE(3)-ATT 1/RATE 2</p>				1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	

GET H:M:S	L N G	S T D	S T E	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
					ENTER PRO MONITOR GPI RESPONSE:  FDAI SCALE-5/1(VERIFY) VERIFY DET SET RATE-HIGH EMS MODE-NORMAL TRANS CONTR PWR-ON DV THRUST A(B)-NORMAL THC-ARMED	F 50 25  BB BB 06 40	00204  -XXBXX +XXXX.X +0000.0	1 1 1 1 1	
TIG-01MIN					MONITOR DSKY BLANK	BB BB  06 40	-00B29 +XXXX.X +0000.0		AVE G ON
TIG-35SEC TIG-30SEC					CHECK PIPA BIAS LESS THAN 2 FPS FOR 5 SEC				
TIG-11SEC TIG-05SEC					THC-APPLY ULLAGE	F 99 40  06 40	-00B05 +XXXX.X +XXXX.X  -00BXX +XXXX.X +XXXX.X		ENGINE ON ENABLE REQUEST
TPI(2)TIG					PRO  THC-TERMINATE ULLAGE AT TIG +1 SEC MONITOR CSM TPI(2) BURN				

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
TIG+02MIN					DV THRUST A(B)-OFF PRO  SPS GIMBAL MOTORS(4)-OFF SEQUENTIALLY TVC SERVO POWER(BOTH)-OFF THC-NULL RESIDUALS  RHC 2-LOCKED THC-LOCKED TRANS CONTR PWR-OFF ROT CONTR PWR DIRECT(BOTH)-OFF CB DIRECT ULLAGE(BOTH)-OPEN CB SPS PITCH 1 AND YAW 1-OPEN RECORD DV COUNTER AND RESIDUALS EMS FUNCTION-OFF EMS MODE-STBY  <u>MANEUVER TO COAS TRACK ATTITUDE</u> V37E 79E  ATT DEADBAND-MAX RATE-LOW BMAG MODE(3)-RATE 2 MAIN BUS TIE(2)-OFF	F 16 40    F 16 85   F 16 85	+00BXX +XXXX.X +XXXX.X  +XXXX.X +XXXX.X +XXXX.X  +XXXX.X +XXXX.X +XXXX.X	1  1 7  1 1 8 8  1 1		-124-

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
				POO	V37E 00E V49E  PRO  PRO  MONITOR MANEUVER  ENTER V83E  CONFIGURE EMS FOR RANGING EMS FUNCTION-DV SET/VHF RNG EMS MODE-BACKUP/VHF RNG VHF RNG-RESET	BB BB  F 06 22  F 50 18  06 18  F 50 18  BB BB  F 16 54	+XXX.XX +XXX.XX +XXX.XX  +XXX.XX +XXX.XX +XXX.XX  +XXX.XX +XXX.XX +XXX.XX  +XXX.XX +XXX.XX +XXX.XX  +XXX.XX -XXXX.X +XXX.XX		119

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
TPI+40MIN					<p>POO <u>RECONFIGURE DAP</u></p> <p>PRO</p> <p>V48E</p> <p>V21E 11102E</p> <p>PRO</p> <p>PRO</p> <p>PRO</p> <p>POO <u>PERFORM DOCKING PREPARATION ACTIVITIES</u></p> <p>PERFORM PRE-DOCK CHECKLIST</p> <p><u>MANUAL ATTITUDE(3)-RATE CMD(VERIFY)</u></p> <p>LIMIT CYCLE-OFF(VERIFY)</p> <p>ATT DEADBAND-MIN</p> <p>RATE-LOW(VERIFY.)</p> <p>TRANS CONTR PWR-ON</p> <p>ROT CONTR PWR DIRECT(BOTH)-MNA/MNB</p> <p>SC CONT-CMC(VERIFY)</p> <p>CMC MODE-AUTO(VERIFY)</p> <p>AUTO RCS SELECT(16)-MNA/MNB(VERIFY)</p> <p>CB DOCK PROBE(2)-CLOSE</p>	BB BB F 04 46 F 04 46 F 06 47 F 06 48 BB BB	11103 X1111 11102 X1111 +XXXXX. +05900. +XXX.XX +XXX.XX	1 1 1 1 1 1 1 1 8 8	-

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p>DOCKING PROBE RETRACT(BOTH)-OFF(CTR) (VERIFY)</p> <p>DOCKING PROBE-RETRACT</p> <p>DOCKING PROBE EXTD/REL TB(2)-GRAY (VERIFY)</p> <p>CB SEQ EVENTS CONT SYS(4)-CLOSE(VERIFY)</p> <p>COAS POWER-ON(UP)(VERIFY)</p> <p>EXTERIOR LIGHTS RUN/EVA-ON(UP)(VERIFY)</p> <p><u>PHOTOGRAPH LM</u></p> <p>UTILITY POWER-ON(UP)(VERIFY)</p> <p>TV-ON</p> <p>DAC-ON</p> <p>BEGIN PHOTOS WITH DAC AND TV</p> <p><u>CONFIGURE SWITCHES FOR POST-TPF</u></p> <p>EMS MODE-STBY</p> <p>EMS FUNCTION-OFF</p> <p>EXTERIOR LIGHTS RNDZ-OFF(CTR)</p> <p><u>TERMINATE LM PHOTOS</u></p> <p>DAC-OFF</p> <p>TV-OFF</p> <p style="text-align: center;">* * * * *</p> <p>FOR DIRECT ASCENT RENDEZVOUS, CONTINUE WITH STEP 33 OF SECTION 2.3.</p> <p>FOR AN ABORT, CONTINUE WITH STEP 25 OF SECTION 3.3.3.</p> <p style="text-align: center;">* * * * *</p>		2 2 2 8 15 2  15		2 2 8 15 2  1 1 2	<p>IF CSM ACTIVE BRAKING, SEE SECTION 4.2.4.</p> <p>TPF</p>

#### **4.2.4 BRAKING**

If the CSM is the active vehicle, the following braking procedures are used by the CMP after MCC-2 to achieve station-keeping.

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p style="text-align: center;">* * * *</p> <p>BRAKING</p> <p style="text-align: center;">* * * *</p> <p>P00 INITIATE THRUST MONITOR PROGRAM</p> <p>MONITOR EMS RANGE UNTIL 1.25 NM</p> <p>V37E 47E</p> <p>P47</p> <p>SM RCS SEC PRPLNT FUEL PRESS(4)-OPEN</p> <p>V83E</p> <p>THC-ARMED</p> <p>RHC 2-ARMED</p> <p>MONITOR EMS RANGE UNTIL 1.11 NM (APPROX)</p> <p>N83E</p>	F 16 83 F 16 54 F 16 83	+0000.0 +0000.0 +0000.0  +001.XX -XXXX.X +XXX.XX  +0000.0 +0000.0 +0000.0	2		PERFORM WHEN RANGE = 1.25 NM  KEY RELEASE LT-ON

GET H:M:S	L T N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p>MONITOR F 16 83, R1 THC-THRUST AFT TO REDUCE RDOT TO -30.0 FPS AT 1.00 NM</p> <p>KEY "KEY RELEASE"</p> <p>THC-NULL LINE-OF-SIGHT RATES MONITOR EMS RANGE UNTIL 0.65 NM (APPROX)</p> <p>N83E</p> <p>MONITOR F 16 83, R1 THC-THRUST AFT TO REDUCE RDOT TO -20.0 FPS AT 0.50 NM</p> <p>KEY "KEY RELEASE"</p> <p>THC-NULL LINE-OF-SIGHT RATES MONITOR EMS RANGE UNTIL 0.35 NM (APPROX)</p> <p>N83E</p> <p>MONITOR F 16 83, R1 THC-THRUST AFT TO REDUCE RDOT TO -10.0 FPS AT 0.25 NM</p>	F 16 54  F 16 83  F 16 54  F 16 83	+001.00 -0030.0 +XXX.XX  +XXXX.X +XXXX.X +XXXX.X  +000.50 -0020.0 +XXX.XX  +XXXX.X +XXXX.X +XXXX.X			KEY RELEASE LT-OFF  KEY RELEASE LT-ON  KEY RELEASE LT-OFF  KEY RELEASE LT-ON

GET H:M:S	L G	S N	S D	P E	R O	G G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS
							KEY "KEY RELEASE"	F 16 54	+000.25 -0010.0 +XXX.XX		KEY RELEASE LT-OFF
							THC-NULL LINE-OF-SIGHT RATES MONITOR EMS RANGE UNTIL .09 NM (APPROX)				
							N83E	F 16 83	+XXXX.X +XXXX.X +XXXX.X		KEY RELEASE LT-ON
							MONITOR F 16 83, R1 THC-THRUST AFT TO REDUCE RDOT TO -5.0 FPS AT .08 NM				
							KEY "KEY RELEASE"	F 16 54	+000.08 -0005.0 +XXX.XX		KEY RELEASE LT-OFF
							MONITOR LM THRU COAS RHC-CENTER LM IN COAS THC-NULL LINE-OF-SIGHT RATES MONITOR LM GROWTH IN COAS FOR RANGE AND RDOT THC-THRUST AFT TO REDUCE RDOT TO ZERO AT 100 FT(LM DIAMETER APPROX 8.5 DEG)				
							PRO	F 16 83	+XXXX.X +XXXX.X +XXXX.X		
							RECORD N83 VALUES				

GET H:M:S	L N G	S T D N	S T E P	P R O G	OPERATIONS	V-N DISPLAY	REGISTER DISPLAYS	STA PANEL	COMMENTS	
					<p>P47 <u>MAINTAIN STATION KEEPING</u></p> <p>P47 <u>PHOTOGRAPH LM</u></p> <p>UTILITY POWER-ON(UP)(VERIFY)</p> <p>TV-ON</p> <p>DAC-ON</p> <p>BEGIN PHOTOS WITH DAC AND TV</p> <p>P47 <u>CONFIGURE SWITCHES FOR POST-TPF</u></p> <p>EMS MODE-STBY</p> <p>EMS FUNCTION-OFF</p> <p>EXTERIOR LIGHTS RNDZ-OFF(CTR)</p> <p>P47 <u>TERMINATE LM PHOTOS AND P47</u></p> <p>PRO</p> <p>OOE</p> <p>P00</p> <p>DAC-OFF</p> <p>TV-OFF</p> <p>* * * * *</p> <p>FOR DIRECT ASCENT RENDEZVOUS, CONTINUE WITH STEP 33 OF SECTION 2.3. FOR AN ABORT, CONTINUE WITH STEP 25 OF SECTION 3.3.3.</p> <p>* * * * *</p>				15	

## 5.0 ACRONYMS AND ABBREVIATIONS

AC	Alternating Current
ACCEL	Acceleration
AGS	Abort Guidance System
AIM	Abort Initiation Maneuver
ALT	Altitude
AM	Amplitude Modulation
AMPL	Amplifier
ANG, ANGL	Angle
ANLG	Analog
ANT	Antenna
AOS	Acquisition of Signal
AOT	Alignment Optical Telescope
APPROX	Approximate
APS	Ascent Propulsion System
ATT	Attitude
AUTO	Automatic
AUX	Auxiliary
AVE	Average
B	Blank
BMAG	Body-Mounted Attitude Gyro
BP	Barber Pole
BU	Backup
CALIB	Calibration
CB	Circuit Breaker
CCW	Counterclockwise
CDH	Constant Delta Altitude
CDR	Commander
CG	Center of Gravity
CM	Command Module
CMC	Command Module Computer
CMD	Command
CMP	Command Module Pilot
COAS	Crew Optical Alignment Sight

COMM	Communication
COMP	Computation
COND R	Conditioner
CONT	Control, Controller
CONTR	Control, Controller
CSI	Concentric Sequence Initiation
CSM	Command and Service Module
CTR	Center
CW	Clockwise
DAC	Data Acquisition Camera
DAP	Digital Autopilot
DC	Direct Current
DEG	Degree
DET	Digital Event Timer
DH	Delta Height
DN	Down
DPS	Descent Propulsion System
DSE	Data Storage Equipment
DSKY	Display and Keyboard
DV	Delta Velocity
E	Enter
ELEC	Electronics
ELEV	Elevation Angle
ELS	Earth Landing Subsystem
EMS	Entry Monitor System
EVA	Extravehicular Activity
EXTD	Extended
F	Flashing Verb-Noun Display
FDAI	Flight Director Attitude Indicator
FPS	Feet Per Second
FWD	Forward
G	Gravitational Acceleration
GDC	Gyro Display Coupler

GET	Ground Elapsed Time
GETI	Ground Elapsed Time of Ignition
GMBL	Gimbal
GND	Ground (Mission Control)
G&N	Guidance and Navigation
GPI	Gimbal Position Indicator
HA	Height of Apolune
HAM	Height Adjust Maneuver
HE	Helium
HGA	High Gain Antenna
HI	High
HORIZ	Horizontal
HP	Height of Perilune
HR	Hours
ICDU	Inertial Coupling Data Unit
IMU	Inertial Measurement Unit
IND	Indicator
INRTL	Inertial
INS	Insertion
LBS	Pounds
LEB	Lower Equipment Bay
LGC	Lunar Module Guidance Computer
LM	Lunar Module
LMP	Lunar Module Pilot
L/O	Lift-off
LO	Low
LOS	Loss of Signal, Line-of-Sight
LT	Light
LTNG	Lighting
LV	Local Vertical, Launch Vehicle
m	Minkey
MAN	Manual
MAX	Maximum

MCC	Midcourse Correction
MCC-H	Mission Control Center-Houston
MDC	Main Display Console
MGA	Middle Gimbal Angle
MIN	Minute, Minimum
MIN IMP	Minimum Impulse
MINKEY	Minimum Keystroke
MNA	Main Bus A
MNB	Main Bus B
MNVR	Maneuver
MSFN	Manned Space Flight Network
MTVC	Manual Thrust Vector Control
N	Noun
NASA	National Aeronautics and Space Administration
NAV	Navigation
NM	Nautical Miles
NO.	Number
NONESS	Nonessential
NORM	Normal
OCDU	Optical Coupling Data Unit
OHC	Optics Hand Controller
OMNI	Omnidirectional Antenna
OPR	Operate
OPT	Optics
ORB	Orbital
ORDEAL	Orbital Rate Drive Earth and Lunar
OSS	Optical Subsystem
P	Program, Pitch
PB	Pushbutton
PC	Plane Change, Chamber Pressure
PCM	Pulse Code Modulation
PDI	Powered Descent Initiation
PGNCS	Primary Guidance, Navigation and Control System

PHOTO	Photography, Photograph
PIPA	Pulse Integrating Pendulous Accelerometer
PL	Postlanding
PRIM	Primary
PRO	Proceed
PROG	Program
PROP, PRPLNT	Propellant
PWR	Power
PYRO	Pyrotechnic
R	Range, Register
RCS	Reaction Control System
RCV	Receive, Receiver
RDOT	Range Rate
REACQ	Reacquire
REFSMMAT	Reference Stable Member Matrix
REL	Release
REQ'D	Required
REV	Revolution
RNDZ	Rendezvous
RHC	Rotational Hand Controller
RNG	Ranging, Range
ROT	Rotation
RR	Rendezvous Radar
RSLV	Resolver
RSS	Root Sum Square
S	Shaft, Seconds
S/C, SC	Spacecraft
SCS	Stabilization and Control System
SEC	Seconds, Secondary
SECS	Sequential Events Control System
SEP	Separation
SEQ	Sequential
SIG	Signal
SIM	Scientific Instrument Module
SM	Service Module
SPS	Service Propulsion System

STA/PANEL	Station/Panel
STBY	Standby
STDN	Spacecraft Tracking and Data Network
S.V.	State Vector
SXT	Sextant
SYS	System
TB	Talkback
TEL	Telescope
TFI	Time from Ignition
TIG	Time of Ignition
THC	Translational Hand Controller
TLM	Telemetry
TPF	Terminal Phase Finalization
TPI	Terminal Phase Initiation
TRNFR	Transfer
TRUN	Trunnion
TV	Television
TVC	Thrust Vector Control
TW	Thumbwheel
V	Verb, Velocity
VG	Velocity to be Gained
VGX	Velocity to be Gained, X-Component
VGY	Velocity to be Gained, Y-Component
VGZ	Velocity to be Gained, Z-Component
VHF	Very High Frequency
VLV	Valve
VX	Velocity; X-Component
VY	Velocity; Y-Component
VZ	Velocity; Z-Component
WRI	W-Matrix Reinitialization
WT	Weight
XPNDR	Transponder
Y	Yaw

## 6.0 REFERENCES

1. Apollo 17 Flight Plan for 6 December 1972 Launch (Final); dated 23 October 1972.
2. Apollo 17 CSM Rescue Book (Basic); dated 18 September 1972.
3. Apollo 17 CSM G&C Checklist (Basic); dated 30 August 1972.
4. Apollo 16 CSM Rendezvous Procedures, MSC-06723; dated 16 March 1972.
5. Apollo Operations Handbook - Command and Service Module CSM 114 - Volume 2, MSC-04904 (Volume 2); dated 16 June 1972.
6. CSM/LM Spacecraft Operational Trajectory, Volume II; MSC-72-FM-187; dated 31 July 1972.
7. Guidance System Operations Plan for Manned CM Earth Orbital and Lunar Missions Using Program COLOSSUS 3, Section 4, Revision 18; dated July 1972.
8. LM Rendezvous Procedures J2 and J3 Missions (Final, Revision 1); MSC-05183; dated 16 March 1972.
9. Operational LM Abort and Rescue Plan for Apollo 13, Volume II; MSC Internal Note 70-FM-9; dated 30 January 1970.

## APPENDIX A

### CMP RENDEZVOUS NAVIGATION SCHEDULES

- NOMINAL RENDEZVOUS NAVIGATION SCHEDULE FOR THE DIRECT ASCENT RENDEZVOUS
- CONTINGENCY RENDEZVOUS NAVIGATION SCHEDULES FOR THE DIRECT ASCENT RENDEZVOUS
- NOMINAL RENDEZVOUS NAVIGATION SCHEDULES FOR COELLIPTIC RENDEZVOUS

APPENDIX A  
-2-

NOMINAL RENDEZVOUS NAVIGATION SCHEDULE  
FOR  
THE DIRECT ASCENT RENDEZVOUS

A STDN uplink is scheduled approximately two hours prior to lift-off and contains the predicted CSM state vector at lift-off and the predicted LM state vector at insertion +5 minutes. A LM state vector uplink will be performed at insertion +9 minutes to update the CMC LM state vector to include LM insertion dispersions.

The W-matrix reinitializations are controlled by the MINKEY logic. The logic reinitializes the W-matrix to 10,000 feet and 10 feet per second prior to the processing of the first mark of the pre-TPI marking period. After TPI the logic will reinitialize the W-matrix to 2,000 feet and two feet per second prior to the processing of the first mark after TPI and MCC-1. Figure A-1 contains the nominal rendezvous navigation schedule.

## APPENDIX A

-3-




FIGURE A-1. NOMINAL NAVIGATION SCHEDULE FOR THE DIRECT ASCENT RENDEZVOUS

APPENDIX A  
-4-

CONTINGENCY RENDEZVOUS NAVIGATION SCHEDULES  
FOR  
THE DIRECT ASCENT RENDEZVOUS

Contingency navigation procedures are required for sextant, LM tracker light, and VHF failures. A schedule for each failure is contained in Figure A-2.

SEXTANT FAILURE (USABLE). In the event of a frozen but optically usable sextant, the COAS variance is manually loaded into the CMC prior to each marking period. This is done by keying V25 N7E, 76E, 2000E, OE, V21 N1E, 301E, 3777E. The CMP must then maneuver the CSM to center the LM in the frozen sextant. Upon centering the LM the CMP presses the mark button to record the mark. The nominal WRI schedule is followed.

LM TRACKER LIGHT FAILURE. In the event of a tracker light failure, optical marks cannot be taken during periods of darkness. Optics marks are possible after the LM enters daylight immediately after MCC-1. The CMC P35 computation for MCC-2 will yield an acceptable solution if these sextant marks are taken. The WRI prior to MCC-1 is inhibited by keying V57 (R2=1) prior to TPI. A WRI is forced prior to the first mark after MCC-1 by keying V93. (The V57 would normally schedule the WRI after the third mark.)

SEXTANT FAILURE (UNUSABLE). COAS marking is required in the event of an unusable sextant. The procedure for taking COAS marks requires manual X-axis tracking and use of Routine 23 (V54). This routine will:

APPENDIX A  
-5-

- A. Load the COAS variance into the CMC.
- B. Allow the CMP to load the shaft and trunnion angles that would result if the optics could be pointed along the X-axis (i.e., shaft = 0.00° and trunnion = 57.470°.)
- C. Provide a COAS marking display.

To take a COAS mark the CMP maneuvers the CSM with the RHC to center the LM in the COAS. Once the LM has been centered, a mark is taken by pressing the ENTER key. The WRI schedule described for the LM tracker light failure is followed.

VHF FAILURE. In the event of a VHF failure, the nominal sextant marking schedule is followed and the LM tracker light failure WRI schedule is followed.

## APPENDIX A

-6-

EVENT	CONTINGENCY MARKING SCHEDULE															
	SXT FAILURE (USABLE)				TRACKER LIGHT FAILURE				SXT FAILURE (UNUSABLE)				VHF FAILURE			
-50	VHF	SXT	COAS	WRI	VHF	SXT	COAS	WRI	VHF	SXT	COAS	WRI	VHF	SXT	COAS	WRI
INSERTION																
BEGIN PRE-THRUST					AUTO				AUTO				AUTO			AUTC
										V57				V57		V57
RECYCLE																
FINAL COMP	-10															
TPI	0															
BEGIN PRE-THRUST					AUTO											
FINAL COMP	+10															
MCC-1																
BEGIN PRE-THRUST					AUTO				-V93				-V93		V93	
FINAL COMP	+20															
MCC-2	+30															

FIGURE A-2. CONTINGENCY NAVIGATION SCHEDULES FOR THE DIRECT ASCENT RENDEZVOUS

## APPENDIX A

-7-

### NOMINAL RENDEZVOUS NAVIGATION SCHEDULES FOR COELLIPTIC RENDEZVOUS

A STDN uplink of the LM state vector will be required for LM aborts after PDI. The uplink is scheduled immediately after LM insertion. In the event of a no-PDI abort, P76 (rather than the STDN uplink) is used to update the state vector. A second uplink prior to the HAM is scheduled for the Two Rev rendezvous because ranges greater than 327 nm will result in loss of CSM navigation. Ranges greater than 327 nm are probable during this period.

The W-matrix is nominally reinitialized by the MINKEY logic. This logic will reinitialize the W-matrix diagonals to 10,000 feet and 10 feet per second until a final comp has been performed; thereafter it will reinitialize to 2,000 feet and two feet per second. The diagonal values should be re-defined to 10,000 feet, 10 feet per second after HAM via V67 so that the first hybrid navigation will occur using the larger diagonals. The navigation schedule for the One Rev rendezvous through TPI is shown in Figure A-3. Figure A-4 contains the Two Rev navigation schedule through TPI. This schedule assumes the full VHF navigation period prior to HAM.

APPENDIX A  
-8-

EVENT	ONE REV SCHEDULE		
	VHF	SXT	WRI
INSERTION			AUTO
RECYCLE	-20		
FINAL COMP	-12		
CSI	0	+3	+5
FINAL COMP	-12		
PC	0		
RECYCLE	-20		
FINAL COMP	-12		
CDH	0	+3	+5
RECYCLE	-20		
FINAL COMP	-12		
TPI	0		

EVENT	TWO REV SCHEDULE		
	VHF	SXT	WRI
BOOST			
MSFN UPLINK			AUTO
RECYCLE	-20		
FINAL COMP	-12		
HAM	0	+3	+5
RECYCLE	-20		
FINAL COMP	-12		
CSI	0	+3	+5
FINAL COMP	-12		
PC	0		
RECYCLE	-20		
FINAL COMP	-12		
CDH	0	+3	+5
RECYCLE	-20		
FINAL COMP	-12		
TPI	0		

FIGURE A-3. NOMINAL NAVIGATION SCHEDULE FOR THE ONE REV RENDEZVOUS

FIGURE A-4. NOMINAL NAVIGATION SCHEDULE FOR THE TWO REV RENDEZVOUS

## APPENDIX B

### CSM ATTITUDE REQUIREMENTS FOR THE NOMINAL APOLLO 17 RENDEZVOUS

The Apollo 17 CSM G&N rendezvous attitude requirements begin approximately two hours prior to LM lift-off and continue until docking.

The attitude maneuver and the events which impact or are impacted by CSM attitude are presented in Table B-1.

Figures B-1, B-2, and B-3 present the CSM attitude history for REV 50, 51, and 52, respectively.

GET (HR:MIN)	EVENT	INERTIAL ATTITUDE (ROLL, PITCH, YAW)		MANEUVER TIME (MIN:SEC)
		START	STOP	
186:12	MNVR TO COAS CAL ATTITUDE	(XXX,XXX,XXX)	(180,244,341)	X:XX
186:21	STDN UPLINK			
186:28	P52 (OPTION 3)			
186:34	COAS CALIBRATION			
187:42	MNVR TO P20 TRACK ATTITUDE	(180,214,341)	(180,026,000)	5:44
188:19	STDN UPLINK			
188:24	MNVR TO TRACK LM	(180,026,000)	(180,312,000)	23:00
188:49	MNVR TO TPI BURN ATTITUDE	(180,312,000)	(180,279,000)	1:06
188:57	TPI BURN			
189:00	MNVR TO TRACK LM	(180,279,000)	(180,259,000)	9:00
189:12	MCC-1*			
189:15	MNVR TO TRACK LM	(180,259,000)*	(180,246,000)	9:00
189:27	MCC-2*			
189:30	MNVR TO COAS TRACK ATTITUDE	(180,246,000)	(180,282,000)	1:12
189:40	TPF			
189:46	MNVR TO SIM BAY INSPECTION ATT	(180,282,000)	(319,254,000)	4:40
189:55	MNVR TO DOCKING ATTITUDE	(319,254,000)	(180,282,000)	4:40
190:05	DOCKING			

\* The maneuver to the X-axis burn attitude is bypassed.

TABLE B-1. APOLLO 17 CSM MANEUVER REQUIREMENTS FOR DIRECT ASCENT RENDEZVOUS

APPENDIX B

-3-




FIG. B-1 CSM ATTITUDE HISTORY FOR REV 50

APPENDIX B

-4-




FIG. B-2 CSM ATTITUDE HISTORY FOR REV 51

## APPENDIX B

-5-




FIG. B-3 CSM ATTITUDE HISTORY FOR REV 52

## APPENDIX C

### CMP INTERFACE REQUIREMENTS FOR THE NOMINAL APOLLO 17 RENDEZVOUS

During a rendezvous, data must constantly be transferred between STDN, the CSM, and the LM. This appendix documents those data exchanges which concern the CMP during rendezvous.

TIME	STDN	CMP	CDR/LMP
186:18	VERIFY  UPLINK TO CMC: LM S.V. FOR INS+5 CSM S.V. FOR L/O RESET SURFACE FLAG	ACQUIRE STDN WITH HGA  ACCEPT	
	UPDATE TO CSM: CONSUMABLES STATUS CSM S.V. FOR L/O LM S.V. FOR INS+5	COPY	
	UPDATE TO LM: ASCENT PADS CSI PAD CSM WEIGHT	COPY AS REQUIRED	COPY
186:25	DSE DUMP		
186:33	COPY	REPORT P52 GYRO TORQUING ANGLES	
186:52	START DSE  ENABLE S-BAND RELAY		
187:00		VERIFY DSE AND S-BAND RELAY OPERATION	
187:39	DSE DUMP	ACQUIRE STDN WITH HGA	
187:56	GO/NO-GO FOR LIFT-OFF	ACKNOWLEDGE	ACKNOWLEDGE

TIME	STDN	CMP	CDR/LMP
TPI-38 MIN	UPLINK LM S.V. TO CMC	ACCEPT	
TPI-34 MIN		CHECK VHF COMM WITH LM	
		REQUEST LM TRACKER LT STATUS	VERIFY LM TRACKER LT ON
TPI-6 MIN	START DSE	VERIFY	
		SUPPLY TPI SOLUTION AT CDR REQUEST	COMPARE TPI SOLUTIONS
		REQUEST TPI P76 PAD FROM CDR	SUPPLY P76 PAD TO CMP
TPI-5 MIN	DISABLE S-BAND RELAY	GO VHF COMM	GO VHF COMM
TPI		ACKNOWLEDGE	VERIFY GOOD TPI BURN TO CMP
TPI+13 MIN		SUPPLY MCC-1 SOLUTION AT CDR REQUEST	REQUEST MCC-1 SOLUTION
		REQUEST MCC-1 P76 PAD FROM CDR	
MCC-1		ACKNOWLEDGE	VERIFY GOOD MCC-1 BURN TO CMP

TIME	STDN	CMP	CDR/LMP
TPI-28 MIN		SUPPLY MCC-2 SOLUTION AT CDR REQUEST	REQUEST MCC-2 SOLUTION
		REQUEST MCC-2 P76 PAD FROM CDR	SUPPLY P76 PAD TO CMP
MCC-2		ACKNOWLEDGE	VERIFY GOOD MCC-2 BURN TO CMP
189:57	VERIFY SWITCH POSITION	POSITION SWITCH: SECS LOGIC(BOTH)-ON	
	GO/NO-GO FOR PYRO ARM	ACKNOWLEDGE	
	VERIFY SWITCH POSITION	POSITION SWITCH: SECS PYRO ARM(2)-ON	

APPENDIX D  
FLIGHT DATA FILE  
NOMINAL RENDEZVOUS PROCEDURES


The Apollo 17 nominal CSM rendezvous procedures are contained in the FLIGHT PLAN for inclusion in the Flight Data File to be carried onboard the spacecraft. This appendix presents the CMP rendezvous procedures as contained in the Apollo 17 FLIGHT PLAN.

# CSM FLIGHT PLAN

<p>186:00 (P20) (0.5°DB)</p> <p>(11101) (_1111)</p> <p>3:50 - DAC - ON</p> <p>4:50 - T2 (LDMK ACQ) OPT MODE - MAN, TAKE MARKS 10 SEC APART</p> <p>6:30 - TCA 7:18 - T3 (LDMK LOSS) DAC - OFF</p> <p>POO</p> <p>VHF AM B - OFF (CTR) MODE - INTERCOM/PTT RNDZ XPNDR - HTR</p> <p>:10</p> <p>(11102) (_1111)</p> <p>V48 (11102) (_1111)</p> <p>V49 MNVR TO P52/COAS CAL ATT (186:18) (180,244,341) HGA P <u>-58.</u> Y <u>52</u></p> <p>S T D N</p> <p>:20</p> <p>UPLINK: LM S.V. (INS +5) CSM S.V. (L/O) RESET SURFACE FLAG</p> <p>UPDATE: CONSUMABLES STATUS CSM S.V. (L/O) LM S.V. (INS +5) ASCENT PADS AND CSM WEIGHT (COPY AT 187:15) FLIGHT PLAN</p> <p>CMDS: DSE DUMP</p> <p>P52 (OPTION 3) (LIFT-OFF ORIENT) REPORT: <u>GYRO TORQUING ANGLES</u></p> <p>186:30</p>	<p style="text-align: center;">SIM EXP STATUS (*0000) (01000)</p> <p style="text-align: center;">P27 UPDATE</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="3">PURP</th> <th colspan="6">CSM</th> <th colspan="6">LM</th> </tr> <tr> <th colspan="2">CSM (INS+T)</th> <th>V</th> <th>7</th> <th>1</th> <th>V</th> <th colspan="2">LM (INS+1)</th> <th>V</th> <th>7</th> <th>1</th> <th>V</th> </tr> <tr> <th>GET</th> <th>188</th> <th>:</th> <th>11</th> <th>:</th> <th>32</th> <th>:</th> <th>:</th> <th>188</th> <th>:</th> <th>11</th> <th>:</th> <th>32</th> </tr> </thead> <tbody> <tr><td>304</td><td>01</td><td>INDEX</td><td>2</td><td>1</td><td>INDEX</td><td></td><td></td><td>INDEX</td><td>2</td><td>1</td><td>INDEX</td><td></td></tr> <tr><td>305</td><td>02</td><td>0</td><td>1</td><td>5</td><td>0</td><td>1</td><td></td><td>0</td><td>1</td><td>5</td><td>0</td><td>1</td></tr> <tr><td>306</td><td>03</td><td>0</td><td>0</td><td>0</td><td>0</td><td>2</td><td></td><td>7</td><td>7</td><td>7</td><td>7</td><td>5</td></tr> <tr><td>307</td><td>04</td><td>7</td><td>7</td><td>4</td><td>7</td><td>7</td><td></td><td>7</td><td>7</td><td>5</td><td>2</td><td>5</td></tr> <tr><td>310</td><td>05</td><td>5</td><td>1</td><td>3</td><td>7</td><td>7</td><td></td><td>7</td><td>7</td><td>7</td><td>3</td><td>2</td></tr> <tr><td>311</td><td>06</td><td>7</td><td>7</td><td>6</td><td>3</td><td>1</td><td></td><td>7</td><td>7</td><td>6</td><td>0</td><td>4</td></tr> <tr><td>312</td><td>07</td><td>6</td><td>5</td><td>3</td><td>6</td><td>1</td><td></td><td>6</td><td>4</td><td>4</td><td>7</td><td>6</td></tr> <tr><td>313</td><td>10</td><td>0</td><td>0</td><td>0</td><td>7</td><td>2</td><td></td><td>0</td><td>0</td><td>0</td><td>5</td><td>1</td></tr> <tr><td>314</td><td>11</td><td>1</td><td>0</td><td>7</td><td>2</td><td>2</td><td></td><td>1</td><td>4</td><td>2</td><td>0</td><td>4</td></tr> <tr><td>315</td><td>12</td><td>7</td><td>2</td><td>5</td><td>2</td><td>3</td><td></td><td>7</td><td>0</td><td>2</td><td>0</td><td>5</td></tr> <tr><td>316</td><td>13</td><td>7</td><td>1</td><td>7</td><td>3</td><td>3</td><td></td><td>4</td><td>6</td><td>3</td><td>3</td><td>5</td></tr> <tr><td>317</td><td>14</td><td>1</td><td>5</td><td>6</td><td>6</td><td>6</td><td></td><td>1</td><td>4</td><td>7</td><td>6</td><td>3</td></tr> <tr><td>320</td><td>15</td><td>1</td><td>5</td><td>5</td><td>3</td><td>2</td><td></td><td>1</td><td>1</td><td>6</td><td>6</td><td>2</td></tr> <tr><td>321</td><td>16</td><td>0</td><td>6</td><td>5</td><td>3</td><td>0</td><td></td><td>0</td><td>7</td><td>4</td><td>1</td><td>1</td></tr> <tr><td>322</td><td>17</td><td>1</td><td>4</td><td>0</td><td>2</td><td>4</td><td></td><td>3</td><td>2</td><td>5</td><td>0</td><td>0</td></tr> <tr><td>323</td><td>20</td><td>1</td><td>0</td><td>0</td><td>4</td><td>7</td><td></td><td>1</td><td>0</td><td>0</td><td>4</td><td>7</td></tr> <tr><td>324</td><td>21</td><td>1</td><td>0</td><td>1</td><td>0</td><td>0</td><td></td><td>1</td><td>0</td><td>1</td><td>0</td><td>0</td></tr> <tr><td>325</td><td>22</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> <tr><td>326</td><td>23</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> <tr><td>327</td><td>24</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> </tbody> </table>	PURP	CSM						LM						CSM (INS+T)		V	7	1	V	LM (INS+1)		V	7	1	V	GET	188	:	11	:	32	:	:	188	:	11	:	32	304	01	INDEX	2	1	INDEX			INDEX	2	1	INDEX		305	02	0	1	5	0	1		0	1	5	0	1	306	03	0	0	0	0	2		7	7	7	7	5	307	04	7	7	4	7	7		7	7	5	2	5	310	05	5	1	3	7	7		7	7	7	3	2	311	06	7	7	6	3	1		7	7	6	0	4	312	07	6	5	3	6	1		6	4	4	7	6	313	10	0	0	0	7	2		0	0	0	5	1	314	11	1	0	7	2	2		1	4	2	0	4	315	12	7	2	5	2	3		7	0	2	0	5	316	13	7	1	7	3	3		4	6	3	3	5	317	14	1	5	6	6	6		1	4	7	6	3	320	15	1	5	5	3	2		1	1	6	6	2	321	16	0	6	5	3	0		0	7	4	1	1	322	17	1	4	0	2	4		3	2	5	0	0	323	20	1	0	0	4	7		1	0	0	4	7	324	21	1	0	1	0	0		1	0	1	0	0	325	22												326	23												327	24											
PURP	CSM						LM																																																																																																																																																																																																																																																																																																				
	CSM (INS+T)		V	7	1	V	LM (INS+1)		V	7	1	V																																																																																																																																																																																																																																																																																															
	GET	188	:	11	:	32	:	:	188	:	11	:	32																																																																																																																																																																																																																																																																																														
304	01	INDEX	2	1	INDEX			INDEX	2	1	INDEX																																																																																																																																																																																																																																																																																																
305	02	0	1	5	0	1		0	1	5	0	1																																																																																																																																																																																																																																																																																															
306	03	0	0	0	0	2		7	7	7	7	5																																																																																																																																																																																																																																																																																															
307	04	7	7	4	7	7		7	7	5	2	5																																																																																																																																																																																																																																																																																															
310	05	5	1	3	7	7		7	7	7	3	2																																																																																																																																																																																																																																																																																															
311	06	7	7	6	3	1		7	7	6	0	4																																																																																																																																																																																																																																																																																															
312	07	6	5	3	6	1		6	4	4	7	6																																																																																																																																																																																																																																																																																															
313	10	0	0	0	7	2		0	0	0	5	1																																																																																																																																																																																																																																																																																															
314	11	1	0	7	2	2		1	4	2	0	4																																																																																																																																																																																																																																																																																															
315	12	7	2	5	2	3		7	0	2	0	5																																																																																																																																																																																																																																																																																															
316	13	7	1	7	3	3		4	6	3	3	5																																																																																																																																																																																																																																																																																															
317	14	1	5	6	6	6		1	4	7	6	3																																																																																																																																																																																																																																																																																															
320	15	1	5	5	3	2		1	1	6	6	2																																																																																																																																																																																																																																																																																															
321	16	0	6	5	3	0		0	7	4	1	1																																																																																																																																																																																																																																																																																															
322	17	1	4	0	2	4		3	2	5	0	0																																																																																																																																																																																																																																																																																															
323	20	1	0	0	4	7		1	0	0	4	7																																																																																																																																																																																																																																																																																															
324	21	1	0	1	0	0		1	0	1	0	0																																																																																																																																																																																																																																																																																															
325	22																																																																																																																																																																																																																																																																																																										
326	23																																																																																																																																																																																																																																																																																																										
327	24																																																																																																																																																																																																																																																																																																										

MISSION	EDITION	DATE	PAGE
APOLLO 17	FINAL (12/6)	10/23/72	3-277

# CSM FLIGHT PLAN



# CSM FLIGHT PLAN

<p>187:00 (11102) (_1111)</p> <p>:10</p> <p><b>REV 51</b></p> <p>:20</p> <p>187:30</p>	<p>EAT PERIOD</p>	<p>SIM EXP STATUS (*0000) (01000)</p> <table border="1" style="margin-top: 20px; border-collapse: collapse;"> <thead> <tr> <th colspan="5">DIRECT ASCENT RNDZ PAD</th> <th colspan="3">UPDATE (IF REQ)</th> </tr> <tr> <th>GETI</th> <th>HRS</th> <th>+</th> <th>0</th> <th>0</th> <th></th> <th></th> <th></th> </tr> </thead> <tbody> <tr> <td>LIFT-OFF</td> <td>MIN</td> <td>+</td> <td>0</td> <td>0</td> <td>0</td> <td></td> <td></td> </tr> <tr> <td></td> <td>SEC</td> <td>+</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>GETI</td> <td>HRS</td> <td>+</td> <td>0</td> <td>0</td> <td></td> <td></td> <td></td> </tr> <tr> <td>TPI</td> <td>MIN</td> <td>+</td> <td>0</td> <td>0</td> <td>0</td> <td></td> <td></td> </tr> <tr> <td>N37</td> <td>SEC</td> <td>+</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <table border="1" style="margin-top: 20px; border-collapse: collapse;"> <thead> <tr> <th colspan="2">CSM WT</th> <th>+</th> <th></th> <th></th> <th></th> <th></th> </tr> </thead> <tbody> <tr> <td>LM WT</td> <td></td> <td>+</td> <td>0</td> <td>5</td> <td>9</td> <td>3</td> </tr> </tbody> </table> <table border="1" style="margin-top: 20px; border-collapse: collapse;"> <thead> <tr> <th colspan="5">COELLIPTIC RNDZ PAD</th> <th colspan="3">UPDATE (IF REQ)</th> </tr> <tr> <th>GETI</th> <th>HRS</th> <th>+</th> <th>0</th> <th>0</th> <th></th> <th></th> <th></th> </tr> </thead> <tbody> <tr> <td>LIFT-OFF</td> <td>MIN</td> <td>+</td> <td>0</td> <td>0</td> <td>0</td> <td></td> <td></td> </tr> <tr> <td></td> <td>SEC</td> <td>+</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>GETI</td> <td>HRS</td> <td>+</td> <td>0</td> <td>0</td> <td></td> <td></td> <td></td> </tr> <tr> <td>CSI</td> <td>MIN</td> <td>+</td> <td>0</td> <td>0</td> <td>0</td> <td></td> <td></td> </tr> <tr> <td>N11</td> <td>SEC</td> <td>+</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>GETI</td> <td>HRS</td> <td>+</td> <td>0</td> <td>0</td> <td></td> <td></td> <td></td> </tr> <tr> <td>TPI</td> <td>MIN</td> <td>+</td> <td>0</td> <td>0</td> <td>0</td> <td></td> <td></td> </tr> <tr> <td>N37</td> <td>SEC</td> <td>+</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	DIRECT ASCENT RNDZ PAD					UPDATE (IF REQ)			GETI	HRS	+	0	0				LIFT-OFF	MIN	+	0	0	0				SEC	+	0					GETI	HRS	+	0	0				TPI	MIN	+	0	0	0			N37	SEC	+	0					CSM WT		+					LM WT		+	0	5	9	3	COELLIPTIC RNDZ PAD					UPDATE (IF REQ)			GETI	HRS	+	0	0				LIFT-OFF	MIN	+	0	0	0				SEC	+	0					GETI	HRS	+	0	0				CSI	MIN	+	0	0	0			N11	SEC	+	0					GETI	HRS	+	0	0				TPI	MIN	+	0	0	0			N37	SEC	+	0				
DIRECT ASCENT RNDZ PAD					UPDATE (IF REQ)																																																																																																																																																			
GETI	HRS	+	0	0																																																																																																																																																				
LIFT-OFF	MIN	+	0	0	0																																																																																																																																																			
	SEC	+	0																																																																																																																																																					
GETI	HRS	+	0	0																																																																																																																																																				
TPI	MIN	+	0	0	0																																																																																																																																																			
N37	SEC	+	0																																																																																																																																																					
CSM WT		+																																																																																																																																																						
LM WT		+	0	5	9	3																																																																																																																																																		
COELLIPTIC RNDZ PAD					UPDATE (IF REQ)																																																																																																																																																			
GETI	HRS	+	0	0																																																																																																																																																				
LIFT-OFF	MIN	+	0	0	0																																																																																																																																																			
	SEC	+	0																																																																																																																																																					
GETI	HRS	+	0	0																																																																																																																																																				
CSI	MIN	+	0	0	0																																																																																																																																																			
N11	SEC	+	0																																																																																																																																																					
GETI	HRS	+	0	0																																																																																																																																																				
TPI	MIN	+	0	0	0																																																																																																																																																			
N37	SEC	+	0																																																																																																																																																					

MISSION	EDITION	DATE	PAGE
APOLLO 17	FINAL (12/6)	10/23/72	3-281

# CSM FLIGHT PLAN

187:30  
 (11102)  
 (\_1111) EAT PERIOD  
 ACQ STDN HGA P -58, Y +52 AUTO, NARROW  
 CMDS:  
 DSE DUMP  
 :40  
 LOAD CSM AND LM WEIGHTS  
 V49 MNVR TO P20 ATT (187:48)  
 (180,026,000) OMNI D  
 CONFIGURE CAMERAS: (DOCKING)  
 CM2/DAC/18/CEX-BRKT,MIR (T8,1/250,=) 6 fps (40% MAG)  
 MAG (BB) \_\_\_\_\_ MAG % \_\_\_\_\_  
 UTILITY PWR - ON  
 CM/EL/80/CEX (f8,1/250,FOCUS) 10 FR  
 MAG (NN) \_\_\_\_\_ FR # \_\_\_\_\_  
 CMA/TY-BRKT  
 (f44,PEAK,=,150MM)  
 S T D N C  
 :50  
 PRESSURIZE CABIN TO 5.5 PSIA  
 VHF AM T/R - OFF (PNL 9)  
 VHF AM B - DUPLEX  
 VHF AM A - OFF (CTR) (VERIFY)  
 VHF RANGING - ON (UP)  
 VHF ANT - RIGHT (VERIFY)  
 EXT LIGHTS RUN/EVA - ON (UP)  
 EXT LIGHTS RNDZ - RNDZ  
 RNDZ XPNDR - PWR  
 UPDATE:  
 GO/NO-GO FOR LM LIFT-OFF  
 GDC ALIGN  
 188:00

SIM EXP STATUS  
(\*0000)  
(01000)

EVENT	CONTINGENCY MARKING SCHEDULES														
	SXT FROZEN (USABLE)*			TRACKER LIGHT FAILURE			SXT FAILURE (UNUSABLE)			VHF FAILURE					
VHF	SXT	COAS	WRI	VHF	SXT	COAS	WRI	VHF	SXT	COAS	WRI	VHF	SXT	COAS	WRI
-50	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				
INSERTION	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				
-40	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				
P34	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				
-30	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				
-20	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				
FINAL COMP	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				
TPI P35	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				
+10	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				
MCC-1 P35	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				
+20	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				
MCC-2 +30	[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]		[REDACTED]				


\* (1) SXT MARKS ARE TAKEN BY MANEUVERING SPACECRAFT  
 (2) TO USE COAS VARIANCE (MUST BE DONE PRIOR TO EACH MARKING PERIOD)  
 V25 N7E, 76E, 20000E, OE, V21 N1E, 301E, 3777E  
 (IF MARK REJECT BUTTON INADVERTENTLY PUSHED: BEFORE PROCEEDING  
 ON FS1: V21 N1E, 1336E, 31264E)

# CSM FLIGHT PLAN


<p>188:00 (11102) (_1111)</p> <p>PRE-SPS BURN SIM PREP (CUE CARD)</p> <p><b>LM LIFT-OFF</b></p> <p>188:03:14.6</p> <p>VHF RNG - RESET</p> <p><b>LM INSERTION</b></p> <p>188:10:32.3</p> <p>S T D N</p> <p>VHF VOICE CHECK</p> <p><b>UPLINK: LM S.V.</b></p> <p>P34 (TRIM) (180,172/26,0)</p> <p>83.29 -328.4</p> <p>188:30</p> <p>BEFORE STEADY STATE PRE-TPI: N49 &gt; (+00200,+00120) REJECT/REPEAT POST-TPI:N49 &gt; (+00080,+00050) REJECT/REPEAT AFTER STEADY STATE ANYTIME: N49 &gt; (+00030,+00020) REJECT/REPEAT</p>	<p style="text-align: center;">SIM EXP STATUS (*0000) (01000)</p> <p>188:13:32.3 (INS +3) TWEAK 188:15:32.3 (INS +5) LM B/O 188:22:32.3 (INS +12) CSM B/O</p> <p style="text-align: right;">P30 MANUVER</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: left; padding-bottom: 5px;">N/A SET STARS</th> <th>C</th> <th>S</th> <th>M</th> <th>B</th> <th>O</th> <th>PURPOSE</th> </tr> <tr> <th>S</th> <th>P</th> <th>S</th> <th>K</th> <th>G</th> <th>R</th> <th>H</th> <th>POP/GUID</th> </tr> </thead> <tbody> <tr> <td>+</td> <td></td> <td>N</td> <td>A</td> <td></td> <td>A</td> <td></td> <td>N47</td> </tr> <tr> <td>O</td> <td>O</td> <td>N</td> <td>A</td> <td></td> <td>A</td> <td></td> <td>PTRIM N43</td> </tr> <tr> <td>O</td> <td>O</td> <td>N</td> <td>A</td> <td></td> <td>A</td> <td></td> <td>TTRIM</td> </tr> <tr> <td>O</td> <td>O</td> <td>O</td> <td>O</td> <td></td> <td>O</td> <td></td> <td>HRS GETI</td> </tr> <tr> <td>O</td> <td>O</td> <td>O</td> <td>O</td> <td></td> <td>O</td> <td></td> <td>MIN N33</td> </tr> <tr> <td>O</td> <td>O</td> <td>O</td> <td>O</td> <td></td> <td>O</td> <td></td> <td>SEC</td> </tr> <tr> <td>O</td> <td>O</td> <td>O</td> <td>O</td> <td></td> <td>O</td> <td></td> <td>ΔV X N81</td> </tr> <tr> <td>O</td> <td>O</td> <td>O</td> <td>O</td> <td></td> <td>O</td> <td></td> <td>ΔV Y</td> </tr> <tr> <td>O</td> <td>O</td> <td>O</td> <td>O</td> <td></td> <td>O</td> <td></td> <td>ΔV Z</td> </tr> <tr> <td>O</td> <td>O</td> <td>O</td> <td>O</td> <td></td> <td>X</td> <td>X</td> <td>R</td> </tr> <tr> <td>O</td> <td>O</td> <td>O</td> <td>O</td> <td></td> <td>X</td> <td>X</td> <td>P</td> </tr> <tr> <td>O</td> <td>O</td> <td>O</td> <td>O</td> <td></td> <td>X</td> <td>X</td> <td>V</td> </tr> <tr> <td>O</td> <td>O</td> <td>O</td> <td>O</td> <td></td> <td>+</td> <td>N</td> <td>H A N44</td> </tr> <tr> <td>O</td> <td>O</td> <td>O</td> <td>O</td> <td></td> <td>N</td> <td>A</td> <td>H P</td> </tr> </tbody> </table> <p>ULLAGE _____</p> <p>4 JET, 11 SEC</p> <p>ΔVC _____</p> <p>***** *IF LM BAILOUT REQ: * COPY P76 DATA FROM LM * *33 : : . *84 . . . *GO TO RESCUE BOOK PG 4 ***** ***** *IF CSM BAILOUT REQ: * *UPDATE: * CSM BAILOUT P30 PAD *P30 *P40; SET UP EMS *SPS BURN CUE CARD *CSM BAILOUT BURN *GO TO RESCUE BOOK PG 4 ***** *****</p> <p style="text-align: center;"><b>P34 INPUT</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">37</td> <td colspan="3">LM GETI-TPI : : .</td> </tr> <tr> <td style="width: 25%;">55</td> <td style="width: 25%;">INTEG OPT +00000</td> <td style="width: 25%;">ELEVATION +00000</td> <td style="width: 25%;">TRANSFER +130.00</td> </tr> </table>	N/A SET STARS		C	S	M	B	O	PURPOSE	S	P	S	K	G	R	H	POP/GUID	+		N	A		A		N47	O	O	N	A		A		PTRIM N43	O	O	N	A		A		TTRIM	O	O	O	O		O		HRS GETI	O	O	O	O		O		MIN N33	O	O	O	O		O		SEC	O	O	O	O		O		ΔV X N81	O	O	O	O		O		ΔV Y	O	O	O	O		O		ΔV Z	O	O	O	O		X	X	R	O	O	O	O		X	X	P	O	O	O	O		X	X	V	O	O	O	O		+	N	H A N44	O	O	O	O		N	A	H P	37	LM GETI-TPI : : .			55	INTEG OPT +00000	ELEVATION +00000	TRANSFER +130.00
N/A SET STARS		C	S	M	B	O	PURPOSE																																																																																																																																		
S	P	S	K	G	R	H	POP/GUID																																																																																																																																		
+		N	A		A		N47																																																																																																																																		
O	O	N	A		A		PTRIM N43																																																																																																																																		
O	O	N	A		A		TTRIM																																																																																																																																		
O	O	O	O		O		HRS GETI																																																																																																																																		
O	O	O	O		O		MIN N33																																																																																																																																		
O	O	O	O		O		SEC																																																																																																																																		
O	O	O	O		O		ΔV X N81																																																																																																																																		
O	O	O	O		O		ΔV Y																																																																																																																																		
O	O	O	O		O		ΔV Z																																																																																																																																		
O	O	O	O		X	X	R																																																																																																																																		
O	O	O	O		X	X	P																																																																																																																																		
O	O	O	O		X	X	V																																																																																																																																		
O	O	O	O		+	N	H A N44																																																																																																																																		
O	O	O	O		N	A	H P																																																																																																																																		
37	LM GETI-TPI : : .																																																																																																																																								
55	INTEG OPT +00000	ELEVATION +00000	TRANSFER +130.00																																																																																																																																						

MISSION	EDITION	DATE	PAGE
APOLLO 17	FINAL (12/6)	10/23/72	3-285

## CSM FLIGHT PLAN



# CSM FLIGHT PLAN



# CSM FLIGHT PLAN

189:30

(11102)  
(\_1111)3.56  
-40.8

PERFORM PRE-DOCK CHECKLIST

IF CSM ACTIVE:  
 P47 AT R=1.25 NM  
 SEC PRPLNT FUEL PRESS (4) - OPEN  
 V83E  
 N83E  
 KEY REL

SIM EXP STATUS  
 (\*0000)  
 (31000)

ACQ STDN HGA P -35, Y +37 AUTO, NARROW  
 UTILITY PWR - ON (VERIFY)  
 DAC/TV - ON  
 LM PHOTOS WITH DAC/TV

TPF

189:40:28.1  
 LM 31.5 (TOTAL)  
 CSM 33.6 (TOTAL)  
 180,304/282,0

:40

EMS MODE - STBY  
 EMS FUNC - OFF  
 EXT LIGHT RNDZ - OFF

LM STATION KEEP

DAC/TV - OFF

V49 MNVR TO SIM BAY INSPECTION ATTITUDE (189:52)  
 (319,254,000) OMNI D

:50

V49 MNVR TO DOCKING ATT (190:00)  
 (180,282,0) HGA P -35, Y +37

CUE STDN FOR LOGIC ARM  
 SECS LOGIC (BOTH) - ON (UP)

UPDATE:  
 GO/NO GO FOR PYRO ARM

SECS PYRO ARM (2) - ON (UP)

190:00

## PRE-DOCK CHECKLIST

MAN ATT (3)-RATE CMD (VERIFY)  
 LIMIT CYCLE - OFF (VERIFY)  
 ATT DB - MIN  
 RATE - LOW (VERIFY)  
 TRANS CONTR PWR - ON (UP)  
 ROT CONTR PWR DIRECT (BOTH) - MNA/MNB  
 SC CONT - CMC (VERIFY)  
 AUTO RCS SEL (16) - MNA/MNB

CB DOCK PROBE (2) - CLOSE  
 PROBE RETRACT (2) - OFF (VERIFY)  
 PROBE EXTD/REL - RETRACT  
 PROBE EXTD/REL TB (2) - GRAY (VERIFY)  
 (IF TB NOT GRAY, GO TO PG S/2-13,E)  
 CB SECS LOGIC (2) - CLOSE (VERIFY)  
 CB SECS ARM (2) - CLOSE  
 EXT LIGHTS RUN/EVA - ON (UP) (VERIFY)  
 COAS PWR - ON (UP) (VERIFY)

## BRAKING GATES

R,NM	R,FPS	RETICLE ANG,DEG	R,FT
1.50	45	.08	9000
1.00	30	.13	6000
.50	20	.26	3000
.25	10	.54	1500
.08	5	1.60	500
.05		2.70	300
.03		4.00	200
.02		8.50	100

# CSM FLIGHT PLAN

190:00  
 (11102)  
 (\_1111) X  
 P47  
 DAC/TV - ON  
  
 T  
 TRANSLATE TO CAPTURE LATCH  
 PERFORM DOCKING CHECKLIST  
 V  
 DOCKING  
 : : .  
 190:05:00  
  
 (61111)  
 (\_1111)  
 DAC/TV - OFF  
 POO  
 V48 (61111)  
 (\_1111)  
 CMC MODE - AUTO  
  
 :10  
 RNDZ XPNDR - OFF  
 V49 MNVR TO LM JETT ATT (190:25)  
 (020,007,349) HGA P -42, Y 349  
 S-BAND AUX TV - SCI  
 DATA SYSTEMS - ON  
 UV - ON  
 IR - ON  
 CMDS:  
 DSE DUMP  
  
 S  
 T  
 D  
 N  
 POST-SPS BURN SIM PREP (CUE CARD)  
  
 STOW OPTICS  
  
 :20  
 PREPARE COUCHES: CDR - 0°, CMP - 0°, LMP - 180°  
 REMOVE PROBE STRAPS (R5)  
 CDR - VERIFY FWD DUMP VLV - AUTO  
 CABIN FANS - ON (UP)  
  
 CM/LM PRESSURE EQUALIZATION (LOD) (DECAL)  
  
 TUNNEL LIGHTS - ON (UP)  
 TUNNEL HATCH REMOVAL (DECAL)  
  
 VERIFY DOCKING LATCHES ENGAGED (AT LEAST 3, 120° APART)  
  
 PROBE REMOVAL (CM SIDE) (DECAL)  
 DROGUE REMOVAL (DECAL)  
  
 190:30

SIM EXP STATUS  
 (\*0000)  
 (31000)

## DOCKING CHECKLIST

### AT CAPTURE

PROBE EXTD/REL TB (2) - BP (VERIFY)  
 (IF TB NOT BP, GO TO PG S/2-11, A)  
 REPORT CAPTURE TO LM  
 SC CONT - CMC (VERIFY)  
 CMC MODE - FREE  
 ALLOW PROBE TO DAMP SC MOTION (10 SEC)  
 WHEN WITHIN +3° OF DOCKING ATTITUDE  
 PROBE RETRACT SEC - 1 (PRIM - 2 IF REQD)

### AT DOCK LATCH

PROBE EXTD/REL TB (2) - GRAY

### AT HARD DOCK


SECS PYRO ARM (2) - SAFE  
 SECS LOGIC (BOTH) - OFF  
 CB SECS ARM (2) - OPEN  
 CB DOCK PROBE (2) - OPEN  
 THC - LOCKED  
 RHC - LOCKED  
 BMAG MODE (3) - RATE 2 (VERIFY)  
 PROBE EXTD/REL - OFF  
 PROBE RETRACT (2) - OFF

EXT LIGHTS (2) - OFF  
 COAS PWR - OFF  
 AUTO RCS SEL: ROLL (4) - OFF  
 TRANS CONTR PWR - OFF  
 ROT CONTR PWR DIRECT (BOTH) - OFF  
 VHF RANGING - OFF

APPENDIX E  
FLIGHT DATA FILE  
ABORT AND RESCUE RENDEZVOUS PROCEDURES


Two LM active rendezvous techniques are available in case of an abort. These are commonly referred to as the One Rev and Two Rev rendezvous. Three other techniques are available but require one or more CSM SPS burns and will not be used except under extreme conditions. These are the Rescue Two, Dwell, and Manual Insertion rendezvous.

CMP procedures for these five techniques are contained in the CSM RESCUE BOOK for inclusion in the Apollo 17 Flight Data File.



**ONE REV  
RELATIVE MOTION PLOT  
LM CENTERED**

NOMINAL COELLIPTIC SEQ	BAILOUT	NO PDI 1+12
PDI 1+	9 8 7 6 5 4 3 2 1	
PDI 2+	15 14 13 12 11 10 9 8 7	



**ONE REV  
BURN TIMES**

NO PDI 1+12 ABORT
CSI AT PDI TIME +67 MIN

PDI 1, EARLY ABORT
CSI AT INS +55 MIN

NOMINAL COELLIPTIC SEQUENCE
CSI AT INS +50 MIN

LM BAILOUT
CSI AT INS +55 MIN

PDI 2, LATE ABORT
CSI AT INS +55 MIN

EARLY COELLIPTIC SEQ. FOR APS LEAK
CSI AT INS +60 MIN

CSM BAILOUT
CSI AT INS +55 MIN

ONE REV  
RENDEZVOUS

**ONE REV  
TIMELINE**

POWER DOWN SIM (SEE EXP/EVA CHECKLIST)  
POO; V48 (11102,X1111)

**INSERTION OR A.I.M.**

MSFN UPLINK: LM S.V.

OBTAINT LM CSI AND TPI GETI'S (COPY)

P32 (SEE INPUT)

BEFORE STEADY STATE
N49>(+00200,+00120):REJECT/REPEAT
AFTER STEADY STATE
N49>(+00030,+00020):REJECT/REPEAT

SXT/VHF

-20  
RECYCLE(COPY)

-12  
FINAL COMP(COPY); OBTAIN LM CSI DV(COPY); P40m

0  
**CSI BURN**

SXT/VHF  
P76m; OBTAIN LM PC GETI(COPY); P36m WITH LM GETI

BEFORE STEADY STATE
N49>(+00030,+00050):REJECT/REPEAT
AFTER STEADY STATE
N49>(+00030,+00020):REJECT/REPEAT

-9  
FINAL COMP (COPY) [TO BYPASS P52m AND P4Xm, ZERO DVY]  
OBTAINT LM PC DV (COPY)

P52m; P4Xm

TO BYPASS GYRO TORQUE: ENTER ON F 50 25
TO GYRO TORQUE: SEE P. 38

0  
**PLANE CHANGE**

-20  
SXT/VHF  
P76m  
OBTAINT LM CDH GETI(COPY); P33m WITH LM GETI

-12  
RECYCLE(COPY)

FINAL COMP(COPY); OBTAIN LM CDH DV(COPY); P40m

0  
**CDH BURN**

P76m

INSERTION		LM INSERTION TIME	:	:	:
A.I.M.	33	LM A.I.M.GETI	:	:	:
	84	LM A.I.M.DV-LV	.	.	.

CSI COMPUTATION					
	INPUT	LM CSI GETI	:	:	:
INPUT	11		:	:	:
	55	+00001	ELEVATION +208.30	180° OPT	+130.00
	37	LM TPI GETI	:	:	:
RECYCLE	90	Y	Y DOT	LM Y DOT	.
	81	CSI ΔV-LV	.	.	+0000.0
FINAL COMP	90	Y	Y DOT	LM Y DOT	.
	81	CSI ΔV-LV	.	.	+0000.0
P76	84	LM CSI ΔV-LV	.	.	.

PLANE CHANGE COMPUTATION					
	INPUT	LM PC GETI	:	:	:
FINAL COMP	90	Y	Y DOT	LM Y DOT	.
	81	PC ΔV-LV	.	.	+0000.0
P76	84	LM PC ΔV-LV	.	.	+0000.0

CDH COMPUTATION					
	INPUT	LM CDH GETI	:	:	:
RECYCLE	13		:	:	:
	90	Y	Y DOT	LM Y DOT	.
	81	CDH ΔV-LV	.	.	.
FINAL COMP	90	Y	Y DOT	LM Y DOT	.
	81	CDH ΔV-LV	.	.	.
P76	84	LM CDH ΔV-LV	.	.	.

P34m, OVERWRITE N55 R2.

SXT  
AND  
VHF

RECYCLE(COPY)

OBTAINT LM TPI GETI AND DV(COPY); FINAL  
COMP, OVERWRITE N37 WITH LM TPI GETI

P40m

TPI BURN

S/V P76m; P35m

FINAL COMP(COPY); OBTAIN LM MCC1 DV(COPY); P41m

MCC1

S/V P76m; P35m

FINAL COMP(COPY); OBTAIN LM MCC2 DV(COPY); P41m

MCC2

GO TO TPF ACTIVITIES(PAGE 36)


TPF

BEFORE STEADY STATE
N49>(+00080,+00050):REJECT/REPEAT
AFTER STEADY STATE
N49>(+00030,+00020):REJECT/REPEAT

TPI-ELEVATION OPTION			
INPUT	37	TPI GETI	
	55	PROCEED ON DISPLAYED GETI	
RECYCLE	37	TPI GETI	
	58	PERILUNE ALT	TPF ΔV
	81	TPI ΔV-LV	
FINAL COMP	37	LM TPI GETI	
	55	INTEG OPT +00000	ELEVATION TRANSFER
	58	PERILUNE ALT	+130.00
P76	81	TPI ΔV-LV	
	33	LM TPI GETI	
	84	LM TPI ΔV-LV	

MCC COMPUTATION				
FIN COMP	81	MCC1 ΔV-LV		
P76	84	LM MCC1 ΔV-LV		


MCC COMPUTATION				
FIN COMP	81	MCC2 ΔV-LV		
P76	84	LM MCC2 ΔV-LV		




TWO REV  
RELATIVE MOTION PLOT

LM CENTERED


PDI 1 ABORTS (EXCEPT T2)



PDI 2 ABORTS (EXCEPT T2)



T 2 ABORTS (PDI 1 AND PDI 2)



NOTE: (-----) INDICATES THE ADDITIONAL REV  
NECESSARY TO MODIFY THE TWO REV TECHNIQUE FOR A T2-1  
ABORT.

**TWO REV  
BURN TIMES**

PDI 1, LATE ABORT

BOOST AT INS + 50 MIN  
HAM AT BOOST + 60 MIN  
CSI AT HAM + 50 MIN

NO PDI 2+12 ABORT

BOOST AT PDI TIME +72 MIN  
HAM AT BOOST +60 MIN  
CSI AT HAM +60 MIN

PDI 2, EARLY ABORT

BOOST AT INS +60 MIN  
HAM AT BOOST +60 MIN  
CSI AT HAM +60 MIN

T2 ABORT, 1ST OPP

BOOST AT INS +50 MIN  
HAM AT BOOST +180 MIN  
CSI AT HAM + 50 MIN

T2 ABORT, 2ND OPP

BOOST AT INS +50 MIN  
HAM AT BOOST +60 MIN  
CSI AT HAM +50 MIN

**TWO REV  
TIMELINE**

POWER DOWN SIM (SEE EXP/EVA CHECKLIST)  
POO; V48(11102,X1111)

INSERTION OR A. I. M.

MSFN UPLINK: LM S.V.

INSERTION		LM INSERTION TIME			
A.I.M.	33	LM AIM GETI.		.	.
	84	LM AIM ΔV-LV		.	.


LM BOOST P76	33	LM BOOST GETI		.	.
	84	LM BOOST ΔV-LV	+0000.0	+0000.0	.

OBTAİN LM BOOST GETI AND DV(COPY)

LM BOOST

P76

## MODIFIED TWO REV RNDZ (FOR T2-1 ABORT ONLY)



MSFN UPLINK: CSM S.V.; LM S.V.  
OBTAIN LM CSI, TPI AND HAM GETI(COPY)  
P31 WITH LM GETI

IF 15 VHF MARKS CAN NOT  
BE TAKEN PRIOR TO FINAL  
COMP:  
V88

BEFORE STEADY STATE  
N49>(+00200,+00120):REJECT/REPEAT  
AFTER STEADY STATE  
N49>(+00030,+00020):REJECT/REPEAT

RECYCLE(COPY)

FINAL COMP, OVERWRITE DVY (COPY);  
OBTAIN LM HAM  $\Delta V$ (COPY)  
P41m

HAM

P76m; V67(+10000,+00100,+00001)

IF NO MARKS HAVE BEEN TAKEN:  
V87

HAM COMPUTATION			
INPUT	11	LM CSI GETI	:
	55	N +00001	ELEVATION 9 +208.30 180° OPT +130.00
	37	LM TPI GETI	:
	33	LM HAM GETI	:
RECYCLE	90	Y .	LM Y DOT .
	81	HAM $\Delta V$ -LV .	+0000.0
FINAL COMP	90	Y .	LM Y DOT .
	81	HAM $\Delta V$ -LV .	+0000.0 +0000.0
P76	84	LM HAM $\Delta V$ -LV .	+0000.0

P32m

SXT/VHF

RECYCLE(COPY)

FINAL COMP(COPY); OBTAIN LM CSI DV(COPY); P40m

CSI BURN

P76m; OBTAIN LM PC GETI(COPY); P36m WITH LM GETI

SXT/VHF

FINAL COMP (COPY) TO BYPASS P52m AND P4Xm, ZERO DVY  
OBTAIN LM PC DV(COPY)

P52m;P4Xm

PLANE CHANGE

TO BYPASS GYRO TORQUE: ENTER ON F 50 25  
TO GYRO TORQUE: SEE P. 38P76m  
OBTAIN LM CDH GETI(COPY); P33m WITH LM GETI

RECYCLE (COPY)

FINAL COMP (COPY); OBTAIN LM CDH DV (COPY); P40m

CDH BURN

P76m

BEFORE STEADY STATE  
N49>(-00200,-00120):REJECT/REPEAT  
AFTER STEADY STATE  
N49>(-00030,-00020):REJECT/REPEAT

CSI COMPUTATION				
INPUT	LM CSI GETI	•	•	•
	11 55 37	PROCEED ON DISPLAYED GETI • ELEVATION + 208.30 180° OPT + 130.00	•	•
RECYCLE	90 81	Y DOT	LM Y DOT	•
	CSI ΔV-LV	•	•	+0000.0
FINAL COMP	90 81	Y DOT	LM Y DOT	•
	CSI ΔV-LV	•	•	+0000.0
P76	84	LM CSI ΔV-LV	•	•

PLANE CHANGE COMPUTATION				
INPUT	LM PC GETI	•	•	•
	33	Y	Y DOT	LM Y DOT
FINAL COMP	90 81	PC ΔV-LV +0000.0	•	+0000.0
	LM PC ΔV-LV +0000.0	•	•	+0000.0
P76	84	•	•	+0000.0

CDH COMPUTATION				
INPUT	LM CDH GETI	•	•	•
	13	Y	Y DOT	LM Y DOT
RECYCLE	90 81	CDH ΔV-LV	•	•
	CDH ΔV-LV	•	•	•
FINAL COMP	90 81	Y	Y DOT	LM Y DOT
	CDH ΔV-LV	•	•	•
P76	84	LM CDH ΔV-LV	•	•

P34m, OVERWRITE N55 R2

BEFORE STEADY STATE
N49>(+00080,+00050):REJECT/REPEAT
AFTER STEADY STATE
N49>(+00030,+00020):REJECT/REPEAT

-20  
RECYLE(COPY)

-12  
OBTAIN LM TPI GETI AND DV(COPY); FINAL  
COMP, OVERWRITE N37 WITH LM TPI GETI

P40m

0  
TPI BURN

+12  
P76m; P35m

+15  
FINAL COMP(COPY); OBTAIN LM MCC1 DV(COPY); P41m

MCC1

+27  
P76m; P35m

+30  
FINAL COMP(COPY); OBTAIN LM MCC2 DV(COPY); P41m

MCC2

+42  
GO TO TPF ACTIVITIES(PAGE 36)

TPF

### TPI-ELEVATION OPTION


INPUT	37	TPI GETI	PROCEED ON DISPLAYED GETI	
	55	INTEG OPT +000000	ELEVATION +208.30	TRANSFER +130.00
RECYCLE	37	TPI GETI	.	.
	58	PERILUNE ALT	TPI ΔV	TPF ΔV
	81	TPI ΔV-LV	.	.
FINAL COMP	37	LM TPI GETI	.	.
	55	INTEG OPT +000000	ELEVATION	TRANSFER +130.00
	58	PERILUNE ALT	TPI ΔV	TPF ΔV
P76	81	TPI ΔV-LV	.	.
	33	LM TPI GETI	.	.
	84	LM TPI ΔV-LV	.	.

### MCC COMPUTATION

FIN COMP	81	MCC1 ΔV-LV	.	.	.
P76	84	LM MCC1 ΔV-LV	.	.	.


### MCC COMPUTATION

FIN COMP	81	MCC2 ΔV-LV	.	.	.
P76	84	LM MCC2 ΔV-LV	.	.	.



**RESCUE TWO  
RELATIVE MOTION PLOT**

LM CENTERED



**RESCUE TWO  
TIMELINE**

POWER DOWN SIM (SEE EXP/EVA CHECKLIST)  
POO; V48. (11102,X1111)

**INSERTION OR A.I.M.**

MSFN UPLINK: LM S.V.

MSFN UPDATE: RESCUE TWO P30 PAD  
P32 INITIALIZATION PAD

P30; P40

**RESCUE TWO BURN**

POO



**RESCUE TWO P30 PAD**


	R	2	/	N	=		PURPOSE
	S	P	S	G	&	N	PROP/GUID
R ALIGN	+						WT N47
P ALIGN			0	0			P TRIM N48
Y ALIGN			0	0			Y TRIM
			+	0	0		HRS GETI
			+	0	0	0	MIN N33
			+	0			SEC
ULLAGE							$\Delta V_X$ N81
			+	0	0	0	$\Delta V_Y$
			+	0	0	0	$\Delta V_Z$
		X	X	X			R
		X	X	X			P
OTHER		X	X	X			Y
		+					$H_A$
							$H_P$ N44
							$\Delta V_T$
		X	X	X			BT
		X					$\Delta V_C$

**P32 INITIALIZATION PAD**

N11	CSI GETI	+	:	:	:	.
	N	+	0	0	0	
N55	ELEV 4 180° OPT	+	2	0	8	30
		+	1	3	0	00
N37	TPI GETI	+	:	:	:	.

## RESCUE TWO BURN INFORMATION

DuPont/MAB/MPAD (for CSM Rescue)


Data source Spacecraft O.T.Data confirmed LLD

Pont/MAB/MPAD (for CSM Rescue)

Data source Spacelab 07

Data confirmed 07/22

# CSI ONE BURN INFORMATION



P32 (LOAD P32 INITIALIZATION PAD ON PAGE 14)



BEFORE STEADY STATE
N49>(+00200,+00120):REJECT/REPEAT
AFTER STEADY STATE
N49>(+00030,+00020):REJECT/REPEAT

-12  
0  
FINAL COMP, OVERWRITE DVY(COPY); P40m

CSI ONE BURN

P76m; V67(+10000,+00100,+00001)

IF INITIAL N>4, CONTINUE ON PAGE 18
IF INITIAL N=4, CONTINUE ON PAGE 19
IF INITIAL N=2, CONTINUE ON PAGE 20

P32	90	Y	Y DOT	LM Y DOT
FINAL COMP	81	CSI SV-LV	+0000.0	+0000.0

GROUND  
ΔVX



COMPARISON  
LIMIT=±3 FPS

(A)

P32m, [REDUCE PREVIOUS N BY 2], OVERWRITE N55 R1(COPY)

VHF ONLY

P52,OPT 3; P32

BEFORE STEADY STATE  
N49>(+00200,+00120):REJECT/REPEAT  
AFTER STEADY STATE  
N49>(+00030,+00020):REJECT/REPEAT

VHF ONLY

IF NECESSARY: MSFN UPLINK-LM S.V.  
CSM S.V.

VHF ONLY

FINAL COMP, OVERWRITE DVY(COPY);  
P41m

CSI BURN

P76m; V67(+10000,+00100,+00001)

RECYCLE TO (A) UNTIL  
N=4 WAS INPUT FOR THE  
PREVIOUS CSI BURN,  
THEN CONTINUE TO PAGE 19.

FOR N=8

CSI COMPUTATION			
INPUT	11	CSI GETI	
	55	PROCEED ON DISPLAYED GETI	
	37	ELEVATION 9 180° OPT	
FINAL COMP	N +00008	ELEVATION 9 +208.30	180° OPT +130.00
	TPI GETI	PROCEED ON DISPLAYED GETI	
FINAL COMP	90	Y	Y DOT LM Y DOT
	81	CSI ΔV-LV	+0000.0 +0000.0

FOR N=6

CSI COMPUTATION			
INPUT	11	CSI GETI	
	55	PROCEED ON DISPLAYED GETI	
	37	ELEVATION 9 180° OPT	
FINAL COMP	N +00006	ELEVATION 9 +208.30	180° OPT +130.00
	TPI GETI	PROCEED ON DISPLAYED GETI	
FINAL COMP	90	Y	Y DOT LM Y DOT
	81	CSI ΔV-LV	+0000.0 +0000.0

FOR N=4

CSI COMPUTATION			
INPUT	11	CSI GETI	
	55	PROCEED ON DISPLAYED GETI	
	37	ELEVATION 9 180° OPT	
FINAL COMP	N +00004	ELEVATION 9 +208.30	180° OPT +130.00
	TPI GETI	PROCEED ON DISPLAYED GETI	
FINAL COMP	90	Y	Y DOT LM Y DOT
	81	CSI ΔV-LV	+0000.0 +0000.0

P31m (COPY), LOAD  $\Delta H = 10.0$ 

V24	N1E
2367E	
OE	
22062E	

VHF ONLY

VHF ONLY

VHF ONLY

RECYCLE (COPY)

FINAL COMP, OVERWRITE DVY(COPY); P41m

HAM

P76m; V67(+10000,+00100,+00001)

BEFORE STEADY STATE
N49>(+00200,+00120):REJECT/REPEAT
AFTER STEADY STATE
N49>(+00030,+00020):REJECT/REPEAT

HAM COMPUTATION			
INPUT	CSI GETI	PROCEED ON DISPLAYED GETI	
	N +00001	ELEVATION	180' OPT +130.00
TPI GETI			
37			
HAM GETI			
33			
		PROCEED ON DISPLAYED GETI	
RECYCLE	Y	Y DOT	L'M'Y DOT
	.	.	.
	HAM AV-LV		
90	.	.	
81	.	.	+0000.0
FINAL COMP	Y	Y DOT	L'M'Y DOT
	.	.	.
	HAM AV-LV		
90	.	.	
81	.	+0000.0	+0000.0

P32m(COPY)

IF P36 IN MODE LITES:  
OBTAIN CSI GETI FROM GRND(COPY)  
P32 WITH GRND GETI

BEFORE STEADY STATE  
N49>(+00200,+00120):REJECT/REPEAT  
AFTER STEADY STATE  
N49>(+00030,+00020):REJECT/REPEAT

SXT / VHF

RECYCLE(COPY)

FINAL COMP(COPY); P41m

CSI FINAL BURN

P76m; P36m (COPY)

SXT / VHF

FINAL COMP (COPY) TO BYPASS P52m AND P4Xm, ZERO DVY  
P52m; P4Xm

PLANE CHANGE

TO BYPASS GYRO TORQUE: ENTER ON F 50 25  
TO GYRO TORQUE: SEE P. 38

P76m

P33m(COPY)

RECYCLE(COPY)

FINAL COMP(COPY); P40m

CDH BURN

P76m

S

T

V

H

F

## CSI COMPUTATION

	INPUT	CSI GETI	PROCEED ON DISPLAYED GETI	
	11	•	•	•
	55	+00001	+208.30	+130.00
	37	TPI GETI	•	•
	90	•	•	•
	81	CSI AV-LV	•	•
	90	•	•	•
	81	CSI AV-LV	•	•

## PLANE CHANGE COMPUTATION

	INPUT	PC GETI	PROCEED ON DISPLAYED GETI	
	33	•	•	•
	90	•	•	•
	81	PC AV-LV +0000.0	•	•

## CDH COMPUTATION

	INPUT	LM CDH GETI	PROCEED ON DISPLAYED GETI	
	13	•	•	•
	90	•	•	•
	81	CDH AV-LV •	•	•
	90	•	•	•
	81	CDH AV-LV •	•	•

P34m, OVERWRITE N55 R2

BEFORE STEADY STATE
N49>(+00080,+00050):REJECT/REPEAT
AFTER STEADY STATE
N49>(+00030,+00020):REJECT/REPEAT

-20 RECYLE (COPY)

-12 FINAL COMP (COPY); P40m

0 TPI BURN

+12 S/V P76m; P35m

+15 MCC1

+27 S/V P35 FINAL COMP (COPY); P41m

+30 MCC2


+42 GO TO TPF ACTIVITIES (PAGE 36)

TPF

TPI-ELEVATION OPTION			
INPUT	PROCEED ON DISPLAYED GETI		
	TPI GETI	ELEVATION <sup>4</sup>	TRANSFER <sup>4</sup>
37	INTEG OPT +000000	+208.30	+130.00
55	TPI GETI		
RECYLE	PERILUNE ALT	TPI ΔV	TPF ΔV
37		.	.
58		.	.
81	TPI ΔV-LV	.	.
FINAL COMP	TPI GETI		
37	INTEG OPT +000000	ELEVATION <sup>4</sup>	TRANSFER <sup>4</sup>
55		.	+130.00
58	PERILUNE ALT	TPI ΔV	TPF ΔV
81	TPI ΔV-LV	.	.


MCC COMPUTATION			
FIN COMP	MCC1 ΔV-LV	.	.
81	.	.	.

MCC COMPUTATION			
FIN COMP	MCC2 ΔV-LV	.	.
81	.	.	.



CSM DWELL  
RELATIVE MOTION PLOT

LM CENTERED



**CSM DWELL  
TIMELINE**

POWER DOWN SIM (SEE EXP/EVA CHECKLIST)

**INSERTION**

MSFN UPLINK: LM S.V.

MSFN UPDATE: DWELL INITIATION P30 PAD (COPY)  
P32 INITIALIZATION PAD (COPY)

P30; P40

**DWELL INITIATION BURN**

P00

**DWELL INITIATION P30 PAD**

	SET STARS	D	W	E	L	I	PURPOSE
		S	P	S/G	&	N	PROP/GUID
R ALIGN	+			0	0		WT N47
P ALIGN				0	0		P TRIM N48
Y ALIGN	+	0	0				Y TRIM
ULLAGE	+	0	0	0			HRS GETI
	+	0					MIN N33
							SEC
							$\Delta V_x$ N81
							$\Delta V_y$
							$\Delta V_z$
OTHER	X	X	X				R
REMAIN IN	X	X	X				P
THE DWELL	X	X	X				Y
ORBIT FOR	+						$H_A$ N44
REVS							$H_P$
							$\Delta V_t$
	X	X	X				BT
	X						$\Delta V_c$

**P32 INITIALIZATION PAD**

N11	CSI GETI	+	:	:	:
		+ 0 0 0 0 1			
N55	ELEV 4 180° OPT	+ 2 0 8 3 0			
		+ 1 3 0 0 0			
N37	TPI GETI	+ :	:	:	.

## DWELL TWO P30 PAD

	D	W	E	L	L	2	PURPOSE
SET STARS				G	&	N	PROP/GUID
R ALIGN	+						WT N47
P ALIGN		0	0				P TRIM N48
Y ALIGN		0	0				Y TRIM
	+	0	0				HRS GETI
	+	0	0	0			MIN N33
	+	0					SEC
ULLAGE							$\Delta V_x$ N81
							$\Delta V_y$
							$\Delta V_z$
	X	X	X				R
	X	X	X				P
	X	X	X				Y
	+						H <sub>A</sub> N44
							H <sub>P</sub>
	+						$\Delta V_T$
	X	X	X				BT
	X						$\Delta V_C$

MSFN UPDATE: DWELL TWO P30 PAD (COPY)  
P32 INITIALIZATION PAD (COPY)

P52, OPT 3  
POO

P30; P41

DWELL TWO BURN

POO

## P32 INITIALIZATION PAD

N11	CSI GETI	+	:	:	:
N55	N	+	0	0	0
	ELEV	+	2	0	8
	180° OPT	+	1	3	0
N37	TPI GETI	+	:	:	:

THIS PAGE IS FOR A  
THREE REV DWELL  
ONLY.

IF DWELL TERMINATION  
IS THE NEXT BURN,  
GO TO PAGE 27.

MSFN UPDATE: DWELL THREE P30 PAD (COPY)  
P32 INITIALIZATION PAD (COPY)

P52, OPT 3  
P00

P30; P41

DWELL THREE BURN

P00

DWELL THREE P30 PAD

SET STARS	D	W	E	L	L	3	PURPOSE
				G	&	N	PROP/GUID
R ALIGN	+						WT N47
P ALIGN		0	0				P TRIM N48
Y ALIGN		0	0				Y TRIM
ULLAGE	+	0	0				HRS GETI
	+	0	0	0			MIN N33
	+	0					SEC
							$\Delta V_x$ N81
							$\Delta V_y$
							$\Delta V_z$
	X	X	X				R
	X	X	X				P
	X	X	X				Y
	+						$H_A$ N44
							$H_p$
	+						$\Delta VT$
	X	X	X				BT
	X						$\Delta VC$

P32 INITIALIZATION PAD

N11	CSI GETI	+	:	:	:
	N	+	0	0	0
N55	ELEV 4	+	2	0	8
	180° OPT	+	1	3	0
N37	TPI GETI	+		:	:

## DWELL TERMINATION PAD

SET STARS	D	W	E	L	L	T	PURPOSE
	S	P	S/G	&	N		PROP/GUID
R ALIGN	+						WT N47
P ALIGN			0	0			P TRIM N48
Y ALIGN			0	0			Y TRIM
ULLAGE			0	0	0		HRS GETI
			0				MIN N33
							SEC
							$\Delta V_x$ N81
							$\Delta V_y$
							$\Delta V_z$
OTHER	X	X	X				R
BURN INCLUDES	X	X	X				P
PLANE CHANGE	X	X	X				Y
COMPONENT	+						$H_A$ N44
							$H_p$
							$\Delta V_t$
	X	X	X				BT
	X						$\Delta V_c$

## P32 INITIALIZATION PAD

N11	CSI GETI	+	:	:	.
	N	+	0	0	0
N55	ELEV $\downarrow$	+	2	0	8
	180° OPT	+	1	3	0
N37	TPI GETI	+		:	.

MSFN UPDATE: DWELL TERMINATION  
P30 PAD INCLUDING  
OUT OF PLANE COMPONENT (COPY)  
P32 INITIALIZATION PAD (COPY)

P52, OPT 3  
P00

V48(11102,X1111)  
P30; P40

DWELL TERMINATION BURN

SXT / VHF

P32 (LOAD P32 INITIALIZATION PAD)

BEFORE STEADY STATE  
N49>(+00200,+00120):REJECT/REPEAT  
AFTER STEADY STATE  
N49>(+00030,+00020):REJECT/REPEAT

FINAL COMP(COPY); P40m

CSI BURN

P76m; P36m(COPY)

FINAL COMP(COPY), TO BYPASS P52m AND P4Xm, ZERO DVY  
P52m; P4Xm

TO BYPASS GYRO TORQUE: ENTER ON F 50 25  
TO GYRO TORQUE: SEE P. 38

PLANE CHANGE

P76m  
P33m(COPY)

RECYCLE(COPY)

FINAL COMP(COPY); P40m

CDH BURN

P76m

CSI COMPUTATION				
	90	Y .	Y DOT .	LM Y DOT .
FINAL COMP	81	CSI ΔV-LV .	.	+0000.0

PLANE CHANGE COMPUTATION				
	33	PC GETI .	• PROCEED ON DISPLAYED GETI •	.
INPUT	90	Y .	Y DOT .	LM Y DOT .
FINAL COMP	81	PC ΔV-LV +0000.0	.	+0000.0

CDH COMPUTATION				
	13	CDH GETI .	• PROCEED ON DISPLAYED GETI •	.
INPUT	90	Y .	Y DOT .	LM Y DOT .
RECYCLE	81	CDH ΔV-LV .	.	.
FINAL COMP	90	Y .	Y DOT .	LM Y DOT .
	81	CDH ΔV-LV .	.	.

P34m, OVERWRITE N55 R2

BEFORE STEADY STATE  
 N49>(+00080,+00050):REJECT/REPEAT  
 AFTER STEADY STATE  
 N49>(+00030,+00020):REJECT/REPEAT

RECYLE(COPY)

FINAL COMP(COPY); P40m

TPI BURN

P76m; P35m

FINAL COMP (COPY); P41m

MCC1

P76m, P35m

FINAL COMP(COPY); P41m

MCC2

GO TO TPF ACTIVITIES (PAGE 36)


TPF

TPI ELEVATION OPTION			
INPUT	37	TPI GETI	
	55	PROCEED ON DISPLAYED GETI	
RECYLE	37	INTEG OPT	ELEVATION TRANSFER
	58	+00000	+208.30 +130.00
	81	TPI GETI	PROCEED ON DISPLAYED GETI
		PERILUNE ALT	TPI ΔV TPF ΔV
FINAL COMP	37	TPI ΔV-LV	
	55	INTEG OPT	ELEVATION TRANSFER
	58	+00000	+130.00
	81	PERILUNE ALT	TPI ΔV TPF ΔV
		TPI ΔV-LV	

MCC COMPUTATION			
FIN COMP	81	MCC1 ΔV-LV	
		.	.

MCC COMPUTATION			
FIN COMP	81	MCC2 ΔV-LV	
		.	.


**MANUAL INSERTION  
ORBITAL MOTION PLOT**



**MANUAL INSERTION  
RELATIVE MOTION PLOTS**

LM CENTERED

- ① INSERTION
- ② LM BOOST
- ③ PHASING ONE
- ④ PHASING TWO (NOMINALLY ZERO)
- ⑤ PHASING THREE (NOMINALLY ZERO)
- ⑥ CSI
- ⑦ CDH
- ⑧ TPI



MANUAL INS  
RENDEZVOUSMANUAL INSERTION  
TIMELINE

POWER DOWN SIM (SEE EXP/EVA CHECKLIST)

## INSERTION

MSFN UPLINK: LM S.V.

P52, OPT 3  
P00

LM	33	LM GETI-BOOST	:	:	:
BOOST		LM BOOST AV-LV.			
P76	84	+0010.0	+0000.0	+0000.0	

## LM BOOST

VERIFY LM BOOST BURN  
P76MSFN UPDATE: PHASING P30 PAD (COPY)  
P32 INITIALIZATION PAD (COPY)

P30; P40

PHASING ONE

## PHASING P30 PAD

SET STARS	P	H	A	S	E	T	PURPOSE
	S	P	S	G	&	N	PROP/GUID
R ALIGN	+						WT N47
P ALIGN			0	0			P TRIM N48
Y ALIGN		+	0	0			Y TRIM
			+	0	0	0	HRS GETI
			+	0	0	0	MIN N33
			+	0			SEC
ULLAGE							$\Delta V_X$ N81
							$\Delta V_Y$
							$\Delta V_Z$
		X	X	X			R
		X	X	X			P
OTHER		X	X	X			Y
		+					$H_A$ N44
							$H_P$
		+					$\Delta V_T$
		X	X	X			BT
		X					$\Delta V_C$

## P32 INITIALIZATION PAD

N11	CSI GETI	+	:	:	:
N55	N ELEV $\downarrow$	+	0	0	0
	180° OPT	+	2	0	8
N37	TPI GETI	+	3	0	0

(A)

P52, OPT 3  
POOMSFN UPDATE:  
PHASING P30 PAD  
(COPY)  
P32 INITIALIZATION  
PAD (COPY)

P30; P41

PHASING  
POOIF THE NEXT BURN IS NOT CSI,  
RETURN TO (A)

## PHASING TWO P30 PAD

SET STARS	P	H	A	S	E	2	PURPOSE
			/	G	&	N	PROP/GUID
R ALIGN	+						WT N47
P ALIGN		0	0				P TRIM N48
Y ALIGN		0	0				Y TRIM
ULLAGE	+	0	0				HRS GETI
	+	0	0	0			MIN N33
	+	0					SEC
							$\Delta V_x$ N81
							$\Delta V_y$
							$\Delta V_z$
	X	X	X				R
	X	X	X				P
	X	X	X				Y
	+						$H_A$ N44
							$H_p$
	+						$\Delta VT$
	X	X	X				BT
	X						$\Delta VC$

## PHASING THREE P30 PAD

SET STARS	P	H	A	S	E	3	PURPOSE
			/	G	&	N	PROP/GUID
R ALIGN	+						WT N47
P ALIGN		0	0				P TRIM N48
Y ALIGN		0	0				Y TRIM
ULLAGE	+	0	0				HRS GETI
	+	0	0	0			MIN N33
	+	0					SEC
							$\Delta V_x$ N81
							$\Delta V_y$
							$\Delta V_z$
	X	X	X				R
	X	X	X				P
	X	X	X				Y
	+						$H_A$ N44
							$H_p$
	+						$\Delta VT$
	X	X	X				BT
	X						$\Delta VC$

## P32 INITIALIZATION PAD

N11	CSI GETI	+	:	:	:
N		+	0	0	0
N55	ELEV ↗	+	2	0	8
	180° OPT	+	1	3	0
N37	TPI GETI	+	:	:	.

## P32 INITIALIZATION PAD.

N11	CSI GETI	+	:	:	:
N		+	0	0	0
N55	ELEV ↗	+	2	0	8
	180° OPT	+	1	3	0
N37	TPI GETI	+	:	:	.

V48(11102,X1111)  
P32(LOAD P32 INITIALIZATION PAD)

BEFORE STEADY STATE  
N49>(+00200,+00120):REJECT/REPEAT  
AFTER STEADY STATE  
N49>(+00030,+00020):REJECT/REPEAT

SXT/VHF

RECYLE(COPY)

FINAL COMP(COPY); P40m

CSI BURN

P76m; P36m(COPY)

SXT/VHF

FINAL COMP(COPY), TO BYPASS P52m AND P4Xm, ZERO DVY  
P52m; P4Xm

BEFORE STEADY STATE  
N49>(+00080,+00050):REJECT/REPEAT  
AFTER STEADY STATE  
N49>(+00030,+00020):REJECT/REPEAT

TO BYPASS GYRO TORQUE: ENTER ON F 50 25  
TO GYRO TORQUE: SEE P 38

PLANE CHANGE

P76m

P33m(COPY)

RECYLE(COPY)

FINAL COMP(COPY); P40m

CDH BURN

P76m

SXT/VHF

CSI COMPUTATION				
	90	Y	Y DOT	LM Y DOT
RECYCLE	90	.	.	.
	81	CSI ΔV-LV	.	.
FINAL COMP	90	Y	Y DOT	LM Y DOT
	81	CSI ΔV-LV	.	.
				+0000.0
				+0000.0

PLANE CHANGE COMPUTATION				
	33	PC GETI	• PROCEED ON DISPLAYED GETI •	
INPUT	33	.	.	.
FINAL COMP	90	Y	Y DOT	LM Y DOT
	81	PC ΔV-LV	.	.
		+0000.0	.	+0000.0

CDH COMPUTATION				
	13	CDH GETI	• PROCEED ON DISPLAYED GETI •	
INPUT	13	.	.	.
RECYCLE	90	Y	Y DOT	LM Y DOT
	81	CDH ΔV-LV	.	.
FINAL COMP	90	Y	Y DOT	LM Y DOT
	81	CDH ΔV-LV	.	.

P34m, OVERWRITE N55 R2

SXT/VHF

RECYCLE (COPY)

FINAL COMP (COPY); P40m

TPI BURN

P76m; P35m

FINAL COMP(COPY); P41m

MCC1

S/V

P76m; P35m

FINAL COMP(COPY); P41m

MCC2

GO TO TPF ACTIVITIES (PAGE 36)

TPF

BEFORE STEADY STATE  
N49-(+00080,+00050):REJECT/REPEAT  
AFTER STEADY STATE  
N49>(+00030,+00020):REJECT/REPEAT

TPI-ELEVATION OPTION			
INPUT	37	PROCEED ON DISPLAYED GETI	
	INTEG OPT +00000	ELEVATION +208.30	TRANSFER +130.00
RECYCLE	37	TPI GETI	•
	58	PERILUNE ALT	PROCEED ON DISPLAYED GETI
	81	TPI ΔV-LV	TPF ΔV
FINAL COMP	37	TPI GETI	•
	55	INTEG OPT +00000	PROCEED ON DISPLAYED GETI
	58	PERILUNE ALT	ELEVATION +130.00
	81	TPI ΔV-LV	TPF ΔV

MCC COMPUTATION			
FIN COMP	81	MCC1 ΔV-LV	•

MCC COMPUTATION			
FIN COMP	81	MCC2 ΔV-LV	•

## TPF ACTIVITIES

+30

(11102)  
(X1111)

MCC2

P76m; P79m; POO  
V49 MNVR TO X-AXIS TRACK ATTITUDE  
ACQ MSFN

PERFORM PRE-DOCK CHECKLIST

IF CSM ACTIVE  
P47 AT 1.25 N.M.  
SEC PRPLNT FUEL PRESS(4)-OPEN  
V83E ←  
N83E  
KEY REL

UTILITY PWR-ON (VERIFY)  
TV-ON  
DAC-ON  
LM PHOTOS WITH DAC/TV

+42

TPF

EMS MODE-STBY  
EMS FUNC-OFF

EXT RNDZ LT-OFF  
LM STATION KEEP

DAC/TV-OFF

## PRE-DOCK CHECKLIST

MAN ATT(3)-RATE CMD(VERIFY)  
LIMIT CYCLE-OFF(VERIFY)  
ATT DB-MIN  
RATE-LOW(VERIFY)  
TRANS CONTR PWR-ON(UP)  
ROT CONTR PWR DIRECT(BOTH)-MNA/MNB  
SC CONT-CMC(VERIFY)

AUTO RCS SEL(16)-MNA/MNB  
CB DOCK PROBE(2)-CLOSED  
PROBE RETR(2)-OFF(VERIFY)  
PROBE EXTD/REL-RETR  
PROBE EXTD/REL TB(2)-GRAY(VERIFY)  
(IF TB NOT GRAY, GO TO PG S/2-13,E)  
CB SECS LOGIC(2)-CLOSED(VERIFY)  
CB SECS ARM(2)-CLOSED  
EXT LIGHTS RUN/EVA-ON(UP)(VERIFY)  
COAS PWR-ON(UP)(VERIFY)

## BRAKING GATES

R,NM	R,FPS	RETICLE ANG,DEG	R,FT
1.50	45	.08	9000
1.00	30	.13	6000
.50	20	.26	3000
.25	10	.54	1500
.08	5	1.60	500
.05		2.70	300
.03		4.00	200
.02		8.50	100.

V49 MNVR TO SIM BAY INSPECTION ATTITUDE (319,254,000)

V49 MNVR TO DOCKING ATTITUDE (180,285,0)

DOCKING ATTITUDE  
VERIFY HGA

CUE MSFN FOR LOGIC ARM  
SECS LOGIC (BOTH)-ON(UP)  
MSFN GO FOR PYRO ARM  
SECS PYRO ARM (2)-ON(UP)

P47  
DAC/TV-ON  
LM MNVR TO DOCKING ATTITUDE  
TRANSLATE TO CAPTURE LATCH  
PERFORM DOCKING CHECKLIST

**DOCKING**  
DAC/TV-OFF  
POO  
V48 (61111)  
(X1111)

CMC MODE-AUTO  
RNDZ XPONDER-OFF  
GO TO VOLUME II OF THE FLIGHT PLAN

### DOCKING CHECKLIST

#### AT CAPTURE

PROBE EXTD/REL TB(2)-BP(VERIFY)  
(IF TB NOT BP, GO TO PG S/2-11, A)  
REPORT CAPTURE TO LM  
SC CONT-CMC(VERIFY)  
CMC MODE-FREE  
ALLOW PROBE TO DAMP S/C MOTION(10 SEC)  
WHEN WITHIN  $\pm 3^\circ$  OF DOCKING ATTITUDE  
PROBE RETRACT SEC-1 (PRIM-2 IF REQ)

#### AT DOCK LATCH

##### PROBE EXTD/REL TB(2)-GRAY

#### AT HARD DOCK

SECS PYRO ARM (2) - SAFE  
SECS LOGIC (BOTH) - OFF  
CB SECS ARM (2) - OPEN  
CB DOCK PROBE (2) - OPEN  
THC - LOCKED  
RHC - LOCKED  
BMAG MODE (3) - RATE 2(VERIFY)  
PROBE EXTD/REL - OFF  
PROBE RETRACT (2) - OFF  
EXT RUN/EVA LIGHT - OFF  
EXT RNDZ LIGHT - OFF  
COAS PWR - OFF  
AUTO RCS SEL ROLL (4)-OFF  
TRANS CONTR PWR-OFF  
ROT CONTR PWR DIRECT (BOTH)-OFF  
VHF RANGING OFF

**SPS PLANE CHANGE  
(G&C CHECKLIST P. G/4-2)**

36.1 P52 F 06 22  
 PRO  
 F 50 25 (00020)  
 ALIGN GDC TO 90° OR 270° ROLL  
 0° OR 180° PITCH  
 0° YAW  
 LIMIT CYCLE-ON  
 ATT DB-MIN  
 RATE LOW  
 BMAG MODE(3)-ATT1/RATE2  
 SC CONT-SCS  
 PRO  
 16 20  
 MONITOR TORQUING  
 \* \* \* \* \* \* \* \* \* \* \* \* \* \* \* \*  
 IF RESTART OCCURS: CONTINUE  
 ON P. 39  
 \* \* \* \* \* \* \* \* \* \* \* \* \* \* \* \*  
 P40 F 50 18  
 BMAG MODE(3)-RATE2  
 SC CONT-CMC  
 PRO  
 06 18  
 MONITOR MNVR  
 PERFORM P40, STARTING AT STEP 5


36.2 P76 F 06 33  
 PRO  
 F 06 84  
 PRO  
 36.4 P20 F 50 18  
 SC CONT-CMC  
 PRO  
 06 18  
 MONITOR MNVR  
 \* \* \* \* \* \* \* \* \* \* \* \* \* \* \* \*  
 IF AUTO MNVR INTERRUPTED:  
 MNVR TO 0° YAW ON GDC  
 V32E  
 \* \* \* \* \* \* \* \* \* \* \* \* \* \* \* \*  
 36.5 P52 F 06 22  
 PRO  
 F 50 25 (00020)  
 SC CONT-SCS  
 BMAG MODE(3)-ATT1/RATE2  
 PRO  
 16 20  
 MONITOR TORQUING  
 \* \* \* \* \* \* \* \* \* \* \* \* \* \* \* \*  
 IF RESTART OCCURS: CONTINUE  
 ON P. 39  
 \* \* \* \* \* \* \* \* \* \* \* \* \* \* \* \*  
 P33 F 06 13  
 BMAG MODE(3)-RATE2  
 SC CONT-CMC  
 CONTINUE IN P33, STEP 3

**PRE-PLANE CHANGE PULSE TORQUING  
RESTART RECOVERY (EMP 518)**

**POST-PLANE CHANGE PULSE TORQUING  
RESTART RECOVERY (EMP 518)**

'52 F 50 25 (00020) V41 N20E	P52 F 06 22 PRO	P52 F 50 25 (00020) V41 N20E
F 21 22 V33E	F 50 25 (00020) V37E 52E	F 21 22 V33E
41 NO ATT LITE-ON	MNVR TO ACQUIRE STARS	41 NO ATT LITE-ON
F 50 25 (00020) V40E	PERFORM P52, OPT 1, COURSE ALIGN	F 50 25 (00020) V40E
NO ATT LITE-OFF	F 37 33E	NO ATT LITE-OFF
V21 N1E 1214E E	P33 F 50 25 00017	V21 N1E 1214E E
V71E 24E 1733E	PRO	V71E 24E 1733E
V21E 303E 24E	F 50 18 PRO	V21E 303E 24E
V33E	06 18 MONITOR MNVR	V33E
F 50 25 (00020) V21 N46E 11103E	F 06 13 V21 N46E 11102E	F 50 25 (00020) BMAG MODE(3)-RATE2
V46E	V46E	SC CONT-CMC
PRO	CONTINUE IN P33, STEP 3	PRO
'40 F 50 18 BMAG MODE(3)-RATE2	P33 06 13 V37E 52E	
SC CONT-CMC	P52 F 37 PERFORM P52, OPT 3	
PRO	P33 33E	
PERFORM P40, STARTING AT	CONTINUE IN P33	
STEP 5		
'76 F 06 33 PRO		
F 06 84 PRO		
'20 F 50 18 SC CONT-CMC		
PRO		
06 18 MONITOR MNVR		

## PRE-BRAKING SPS BURN PROCEDURES



GETI-TPI	•	•	•
AT: TPI-PRE-BRAKING	•	+37	00.00
GETI- PRE-BRAKING	•	•	•
	•	•	•

TRANSFER COMPUTATION  
OBTAIN TPF  $\Delta V$  FROM N58 OF TPI SOLUTION

$$\text{TRANSFER } \frac{\Delta V}{2}$$

$$= \frac{\text{TPF } \Delta V}{2}$$

TRANSFER  $\frac{\Delta V}{2}$  = •

LOAD INTO N55 (R3)

PRE-BRAKING BURN COMPUTATION				
INPUT	37	COMPUTED P34 GETI		
	55	INTEG OPT +00000	ELEVATION +0000.0	COMPUTED TRANSFER
FINAL COMP	55	INTEG OPT +00000	ELEVATION	TRANSFER
	58	PERILUNE ALT	P34 $\Delta V$	TPF $\Delta V$
	81	P34 $\Delta V$ -LV	•	•

P40

## SPS CHECKLIST

+30

## PRE-BRAKING BURN

P79; P00; V49 MNVR TO X-AXIS TRACK ATTITUDE  
 ACQ MSFN HGA  
 V48(11102,X1111)  
 PERFORM PRE-DOCK CHECKLIST

P47 AT R=1.25 NM  
 SEC PRPLNT FUEL PRESS(4)-OPEN  
 V83E KEY REL  
 N83E

UTIL PWR-ON (VERIFY)  
 DAC/TV-ON  
 LM PHOTOS WITH DAC/T V

## TPF

EMS MODE-STBY  
 EMS FUNC-OFF  
 EXT RNDZ LT-OFF  
 LM STATION KEEP  
 GO TO VOL II OF FLIGHT PLAN

## PRE-DOCK CHECKLIST

MAN ATT(3)-RATE CMD(VERIFY)  
 LIMIT CYCLE-OFF(VERIFY)  
 ATT DB-MIN  
 RATE-LOW(VERIFY)  
 TRANS CONTR PWR-ON(UP)  
 ROT CONTR PWR DIRECT(BOTH)-MNA/MNB  
 SC CONT-CMC(VERIFY)

AUTO RCS SEL(16)-MNA/MNB  
 CB DOCK PROBE(2)-CLOSED  
 PROBE RETR(2)-OFF(VERIFY)  
 PROBE EXTD/REL-RETR  
 PROBE EXTD/REL TB(2)-GRAY(VERIFY)  
 (IF TB NOT GRAY, GO TO PG S/2-13,E)  
 CB SECS LOGIC(2)-CLOSED(VERIFY)  
 CB SECS ARM(2)-CLOSED  
 EXT LIGHTS RUN/EVA-ON(UP)(VERIFY)  
 COAS PWR-ON(UP)(VERIFY)

BRAKING GATES			
R, NM	R, FPS	RETICLE ANG, DEG	R, FT
1.50	45	.08	9000
1.00	30	.13	6000
.50	20	.26	3000
.25	10	.54	1500
.08	5	1.60	500
.05		2.70	300
.03		4.00	200
.02		8.50	100

## IMU FAILURE RENDEZVOUS

WHEN IMU FAILURE KNOWN:

PERFORM IMU FAILURE SWITCH CHECKLIST  
 PERFORM GDC REFSMMAT DETERMINATION PROCEDURE(G/7-13)  
 (IF REQD: PERFORM GDC REFSMMAT REALIGN(P52-OPT 4)(G/7-15)

MNVR TO TRACK/STAR FIELD ATT(180,280,0), ACQ HGA  
 LOAD N20 AND ATT SET TW'S TO(180,280,0)  
 MNVR BY NULLING ERROR NEEDLES

## IMU FAILURE SWITCH CHECKLIST

IMU POWER-OFF
FDAI SELECT-1
FDAI SOURCE-ATT SET
ATT SET-GDC
ATT DB-MIN
RATE-LOW
SC CONT-SCS
BMAG MODE(3)-ATT 1/RATE 2

DIRECT ASCENT RNDZ PAD			UPDATE (IF REQ'D)		
GETI	HRS	+ 0 0		+ 0 0	
LIFT-OFF	MIN	+ 0 0 0		+ 0 0 0	
	SEC	+ 0		+ 0	
GETI	HRS	+ 0 0		+ 0 0	
TPI	MIN	+ 0 0 0		+ 0 0 0	
N37	SEC	+ 0		+ 0	

SET REFSMMAT FLAG(VERIFY)  
 V25 N7E,77E,10000E,1E

PRE SPS BURN SIM PREP (CUE CARD)

COELLIPTIC RNDZ PAD			UPDATE (IF REQ'D)		
GETI	HRS	+ 0 0		+ 0 0	
LIFT-OFF	MIN	+ 0 0 0		+ 0 0 0	
	SEC	+ 0		+ 0	
GETI	HRS	+ 0 0		+ 0 0	
CSI	MIN	+ 0 0 0		+ 0 0 0	
N11	SEC	+ 0		+ 0	
GETI	HRS	+ 0 0		+ 0 0	
TPI	MIN	+ 0 0 0		+ 0 0 0	
N37	SEC	+ 0		+ 0	

UPDATE:  
NO GO FOR LIFT-OFF

LM LIFT-OFF

: : .

VHF RNG-RESET

LM INSERTION

: : .

P52(OPTION 3)

RECORD STAR NO.



SHAFT



TRUNNION

POO

MSFN UPLINK:  
LM S.V.

P34(ACCEPT MNKY)(BYPASS MNVR)  
V57-LOAD R2=1

V  
H  
F  
O  
N  
L  
Y

BEFORE STEADY STATE

PRE-TPI: N49 > (+00200,+00120) REJECT/REPEAT  
POST-TPI: N49 > (+00080,+00050) REJECT/REPEAT

AFTER STEADY STATE

ANYTIME: N49 > (+00030,+00020) REJECT/REPEAT

VERIFY LM TRACKER LT-ON

ALIGN GDC TO N20

PERFORM GDC REFSMMAT DETERMINATION PROCEDURE

V37E00E; V96E; V21 N1E,1214E,63E;  
V25 N26E,13001E,3425E,30005E; V30E

### SCS BURN MANEUVER

N/A SET STARS	C	S	M	B	/	O	PURPOSE
	S	P	S/G	&	N		PROP/GUID
R ALIGN	N	/	A		N	/	A
P ALIGN	N	/	A		N	/	A
Y ALIGN	N	/	A		+ 0 0		HRS GETI
					+ 0 0 0		MIN N33
					+ 0		SEC
ULLAGE							$\Delta V_X$ N81
4 JET, 11 SEC							$\Delta V_Y$
							$\Delta V_Z$
AVC	X	X	X				R ..
	X	X	X				P
	X	X	X				Y
	+ N	/	A				$H_A$ N44
		N	/	A			$H_P$

\* \* \* \* \*  
\* IF LM BAILOUT REQ'D:  
\* COPY P76 DATA FROM LM

\* 33      : : .  
\* 84      . . . .

\* GO TO RESCUE BOOK PG 4

\* \* \* \* \*  
\* IF CSM BAILOUT REQ'D:  
\* \*  
\* \* MSFN UPDATE:  
\* \* CSM BAILOUT P30 PAD  
\* \* P30  
\* \* P40; SET UP EMS  
\* \* SPS BURN CUE CARD  
\* \* CSM BAILOUT BURN  
\* \* GO TO RESCUE BOOK PG 4

P34 INPUT			
37	LM GETI-TPI	:	:
55	INTEG OPT +00000	ELEVATION +000.00	TRANSFER +130.00

IMU FAILURE  
RENDEZVOUS

PAGE 44

APPENDIX E

DATE 9/18/72

-25

P34 (ACCEPT MNKY)(NO SXT MARKS UNTIL TPI - 17)  
V25 N7E,76E,2000E,OE  
V21 N1E,301E,3777E  
(V86E TO REJECT MARK)

VHF ONLY  
MNVR TO SXT TRACK ATT (180,334,0)  
LOAD N20 AND ATT SET TW'S TO(180,334,0)  
MNVR BY NULLING ERROR NEEDLES

-17

BEGIN SXT MARKS

VHF AND SXT  
\*  
\* IF MARK REJECT BUTTON INADVERTENTLY PUSHED: \*  
\* BEFORE PROCEEDING ON F 51  
\* V21 N1E,1336E,31264E  
\* \*

VERIFY DSE TAPE MOTION(LBR/RCD/FWD/CMD RESET)

-10

P34 FINAL COMP  
COMPARE SOLUTIONS

-8

P40  
LOAD N18 VALUES IN N20 AND ATT SET TW'S  
MNVR BY NULLING ERROR NEEDLES

-6


SPS CHECKLIST

0

TPI

LM +75.1,-0.5,+14.1  
CSM -76.1,+0.5,-12.1  
(180,279,0)

GROUND TPI FOR LM



P34 FINAL COMP			
	INTEG OPT +00000	ELEVATION	TRANSFER
55	PERILUNE ALT	•	+130.00
58	TPI ΔV	•	TPF ΔV
81	TPI ΔV-LV	•	•
84	LM TPI ΔV-LV	•	•
84	LM TPI ΔV-LV	•	•

P76

P76(P77)

P35(ACCEPT MNKY)

CALL N22; LOAD N20 VALUES IN N20 AND ATT SET TW'S  
MNVR BY NULLING ERROR NEEDLESV25 N7E,76E,20000E,OE  
V21 N1E,301E,37777EV  
H  
F  
  
A  
N  
D  
  
S  
X  
T

P35 FINAL COMP

P41(P40); LOAD N18 VALUES IN N20 AND ATT SET TW'S  
MNVR BY NULLING ERROR NEEDLES

POO

MCC-1

: : .

P76(P77)

P34(ACCEPT MNKY)

V93

CALL N22; LOAD N22 VALUES IN N20 AND ATT SET TW'S  
MNVR BY NULLING ERROR NEEDLESV25 N7E,76E,20000E,OE  
V21 N1E,301E, 37777EV  
H  
F  
  
A  
N  
D  
  
S  
X  
T

P34 FINAL COMP

P41(P40); LOAD N18 VALUES IN N20 AND ATT SET TW'S  
MNVR BY NULLING ERROR NEEDLES

POO

MCC-2

: : .

P76

## P35 FINAL COMP

81	MCC1 ΔV-LV	.	.	.
84	LM MCC1 ΔV-LV	.	.	.
84	LM MCC1 ΔV-LV	.	.	.

P76

## P34 INPUT

37	GETI-MCC2	:	:	.
55	INTEG OPT +00000	ELEVATION } +000.00	TRANSFER }	+040.00

## P34 FINAL COMP

55	INTEG OPT +00000	ELEVATION } .	TRANSFER }	+040.00
58	PERILUNE ALT	MCC2 ΔV	TPF ΔV	.
81	MCC2 ΔV-LV	.	.	.
84	LM MCC2 ΔV-LV	.	.	.
84	LM MCC2 ΔV-LV	.	.	.

3

12

-15

-18

26

-30

P76(P77)

P79

LOAD N22 VALUES IN ATT SET TW'S  
MNVR BY NULLING ERROR NEEDLES

ACQ MSFN HGA

PERFORM PRE-DOCK CHECKLIST

CENTER LM IN COAS

CYCLE BMAG MODE SWITCHES-RATE 2/ATT 1 RATE 2  
FDAI SOURCE-GDC(VERIFY)

IF CSM ACTIVE:

AT R=1.25 NM; LOAD EMS WITH -(100+TPFΔV)  
FOR DSKY DISPLAY OF VHF RANGE:  
V25 N7E,75E,100E,1E; V87E; V16 N2E,3703E  
SEC PRPLNT FUEL PRESS(4)-CPEN  
EMS FUNC-AV  
EMS MODE-NORMAL

TPF

:

LM 30.9 (TOTAL)  
CSM 32.7 (TOTAL)  
180,285,0

EMS MODE-STBY

EMS FUNC-OFF

EXT RNDZ LT-OFF

LM STATION KEEP

POO

CUE MSFN FOR LOGIC ARM  
SECS LOGIC(BOTH)-ON(UP)  
MSFN GO FOR PYRO ARM  
SECS PYRO ARM(2)-ON(UP)

LM MNVR TO DOCKING ATTITUDE

TRANSLATE TO CAPTURE LATCH  
PERFORM DOCKING CHECKLIST

DOCKING

:

## PRE-DOCK CHECKLIST

FDAI SOURCE-GDC  
LIMIT CYCLE-OFF(VERIFY)  
TRANS CONTR PWR-ON(UP)  
ROT CONTR PWR DIRECT(BOTH)-MNA/MNB  
AUTO RCS SEL(16)-MNA/MNB  
CB DOCK PROBE(2)-CLOSED  
PROBE RETRACT(2)-OFF(VERIFY)

PROBE EXTD/REL - RETR  
PROBE EXTD/REL TB (2) - GRAY (VERIFY)  
(IF TB NOT GRAY, GO TO PG S/2-13,E)  
CB SECS LOGIC (2) - CLOSED (VERIFY)  
CB SECS ARM (2) - CLOSED  
EXT LIGHTS RUN/EVA - ON (UP) (VERIFY)  
COAS PWR - ON (UP) (VERIFY)

BRAKING GATES			
R,NM	R,FPS	RETICLE ANG,DEG	R,FT
1.50	45	.08	9000
1.00	30	.13	6000
.50	20	.26	3000
.25	10	.54	1500
.08	5	1.60	500
.05		2.70	300
.03		4.00	200
.02		8.50	100

## DOCKING CHECKLIST

## AT CAPTURE

PROBE EXTD/REL TB (2) - BP (VERIFY)  
(IF TB NOT BP, GO TO PG S/2-11, A)  
REPORT CAPTURE TO LM  
BMAG MODE (3) - RATE 2  
ALLOW PROBE TO DAMP SC MOTION (10 SEC)  
WHEN WITHIN  $\pm 3^\circ$  OF DOCKING ATTITUDE  
PROBE RETRACT SEC - 1 (PRIM - 2 IF REQ'D)

## AT DOCK LATCH

PROBE EXTD/REL TB (2) - GRAY

## AT HARD DOCK

SECS PYRO ARM1 (2) - SAFE	EXT RUN/EVA LIGHT - OFF
SECS LOGIC (BOTH) - OFF	EXT RNDZ LIGHT - OFF
CB SECS ARM (2) - OPEN	COAS PWR - OFF
CB DOCK PROBE (2) - OPEN	LIMIT CYCLE - ON
THC - LOCKED	ATT DB - MAX
RHC - LOCKED	
BMAG MODE (3) - ATT 1/RATE 2	
PROBE EXTD/REL - OFF	AUTO RCS SEL ROLL(4)-OFF
PROBE RETRACT (2) - OFF	THC PWR - OFF
VHF RANGING-OFF	RHC PWR DIR (2) - OFF

## SPS RESCUE BURN TABLE

ENGINE LIMITS	P OR Y RATES	ATT DEVIATION	MANUAL START ACTION	RESIDUALS
LOOSE	10°/SEC. COMPLETE	±10° COMPLETE	START IF $\Delta V$ TO GO >12 FPS	TRIM ALL AXES TO 0.2 FPS

BURN TABLE

THIS PAGE INTENTIONALLY BLANK