


















Table 2
Symbols with
No Color or Illumination Requirements

Column 1 ITEM	Column 2 SYMBOL	Column 1 ITEM	Column 2 SYMBOL
Fifth wheel height adjustment		Snowplow Platform and rear axle may be omitted from the symbol if appropriate.	
Fuel temperature	 or 	Fuel heating	 or 
Transmission malfunction		Transmission fluid level	
Transmission temperature		Transmission converter temperature	
Transmission converter fluid level		Transmission converter malfunction	
Axle malfunction		Axle lifting	
Axle fluid level			
Cab lock Platform and rear axle may be omitted if appropriate.		Winch	
Tire temperature	