[1.6] Manual error for SetMode() codes for Angle modes

3

1

2

The on-line PDF verson of the *TI-89 / TI-92 Plus Guidebook* has an error in Appendix D, page 585. The codes for Angle should be

Angle Radian Degree

The manual mistakenly gives the Angle code as 0, and omits the codes for Radian and Degree.