

952-6497-1

IBM NO 65-554-0097

GEMINI CATCH-UP
AND
RENDEZVOUS
ANALYSIS
AND
SIMULATION
REPORT #4

ORIGINATING GROUP Gemini Systems Engineering

CONTENT APPROVED BY

H.Fraunier

CONTRACT NO Y50188L

DATE 31 December 1965

Prepared by: F. Reiner

IBM FEDERAL SYSTEMS DIVISION
SPACE GUIDANCE CENTER
OWEGO NEW YORK

TABLE OF CONTENTS

	<u>Page</u>
List of Figures	1
List of Tables	ii
I. Introduction	1
II. Functional Descriptions	2
Dynamic Simulator	2
Static Simulator	7
III. Detail Description of the Rendezvous Environment System	8
Appendix A - FORTRAN/FAP Program Listings	
Dynamic Environment (MAIN)	1
Executor Subroutine (DYNAMIC)	23
Catch-Up, Rendezvous Subroutine (DYNAMIC)	27
Static Environment (BENCH)	38
Executor Subroutine (STATIC)	477
Individual MQ Key Reading Subroutine	51
Quantization Subroutine	53
Disable/Enable Subroutine	55

TABLE OF CONTENTS (Continued)

	<u>Page</u>
Data Insertion Subroutine	57
Go-No-Go Subroutine	59
AGE Subroutine	61
Ascent Subroutine	63
Touchdown Predict Subroutine	65
Re-entry Subroutine	67
Accelerometer Subroutine	69
Wait 5 Milliseconds Subroutine	71
Gimbal Angle Subroutine	73
Self-Loading Tape Generation Subroutine	75
Position Integration Subroutine	84
Attitude Integration Subroutine	87
Control Subroutine	90
MQ Keys Reading Subroutine	94
Error Angle Subroutine	96
Tape Density Setting Subroutines	
High Density A7	98
High Density A9	100
Low Density B6	102

TABLE OF CONTENTS (Continued)

	<u>Page</u>
IVI Set Zero Subroutine	104
IVI Display Subroutine	106
Tape File Skipping Subroutine	108
Appendix B - Sample Output	109

LIST OF FIGURES

<u>Number</u>	<u>Title</u>	<u>Page</u>
1	Dynamic Simulation Block Diagram	33
2	Functional Flow Diagram, Dynamic Environment	6
3	Detail Flow Diagram, Dynamic Environment	52

LIST OF TABLES

<u>Number</u>	<u>Title</u>	<u>Page</u>
1	Guidance Computer Output Variable Names	19
2	Input Data Supplied Only Once for Each Set of Dynamic Simulations (Type 1 Data)	30
3	Input Data Supplied for Each Dynamic Simulation (Type 2 Data)	31
4	Insertable Data - For Dynamic or Static Simulation - (Type 3 Data)	39
5	Inputs Necessary for Plotting (Type 4 Data)	45
6	Definition of Terms Used on Detail Dynamic Environment Flow Diagram	46

I. INTRODUCTION

A report describing the analysis and simulation work for the Catch-Up and Rendezvous modes completed through 30 March 1965 was issued on 29 April 1965. This report describes the work done on the FORTRAN simulations since that time.

Following is a list of the changes made to the simulation programs:

A. Static Simulation -

1. A tolerance generation scheme used for Acceptance and Pad Tests has been added.

B. Dynamic Simulation -

1. The integration scheme has been changed.
2. A change has been made to insure that the program will run only if the MQ keys are set properly.
3. All tape density setting are controlled by the program.
4. Errors are injected into the sines of the radar angles to simulate hardware errors.
5. Logic has been added to the automated output routine to account for Self-Test (Module III).

Appendix A of this report gives listings of all the programs used for FORTRAN simulations of the Catch-Up and Rendezvous modes. These listings as well as the explanations given in this report, should enable competent computer programmers with a knowledge of FORTRAN to duplicate the results obtained by IBM.

II. FUNCTIONAL DESCRIPTIONS

This section of the report is intended to present a general simplified description of the Catch-Up and Rendezvous simulation programs. In this perspective functional flow charts are presented without the required inputs or the simulation outputs but stripped down to the broad functional purposes of the simulation programs.

Dynamic Simulator

The Catch-Up and Rendezvous dynamic simulation is composed of:

- I. The Executor and Rendezvous programs of the Gemini Seventh System Math Flow, Module V.
- II. The Rendezvous Environment program which simulates the physical environment in which the Gemini guidance computer operates.
- III. The Control program which provides the interface between the Environment program and the simulated operational programs.

Figure 1 is a simplified Block Diagram of the Catch-Up and Rendezvous Dynamic Simulation Programs which shows the Environment program supplying the following quantities to the Executor and Rendezvous programs:

1. Three Gimbal Angles
2. Three Radar Parameters
3. Three Accelerometer Outputs
4. Several Discrete Inputs.

Simulation Cycle

The simulation cycle begins with the initialization of the Environment Program. When this has been completed transfer is made to the simulated guidance computer via the control program.

The guidance computer operates in a closed loop, transferring from Executor to Rendezvous and back to Executor. This loop continues until the control program indicates to the Executor that one simulated time increment has elapsed. The guidance computer loop is then broken in the Executor and transfer is to the Environment program through the control program.




FIGURE /
DYNAMIC SIMULATION BLOCK DIAGRAM

Simulation Cycle (continued)

One cycle is then made through the Environment program. During this cycle, the simulated physical environment is updated in accordance with the information received from the guidance computer. When the environment has been updated, transfer is to the guidance computer where the closed loop begins again.

The transfer cycle from the Environment program to the Executor, around the Executor-Rendezvous loop, and back to the Environment program continues until the simulated flight is terminated.

Figure 2 is a functional flow diagram of the Dynamic Environment program.

Function Sequence

The Environment program is initialized with input data to allow calculation of the target and spacecraft initial position and velocity. In addition, all logical decisions and variables which can be set by input data are initialized.

The mode status is checked and the appropriate discrete inputs are initialized, depending upon the mode.

The equations of motion for the target and spacecraft including spacecraft thrust terms are integrated for the time step of the Rendezvous program.

The accelerometer outputs are calculated in the navigation coordinate system. The applied incremental velocity components are calculated in the spacecraft coordinate system.

The spacecraft orbital parameters are calculated.

The elements of the inertial-to-navigation coordinate transformation matrix are calculated and the elements of the navigation-to-body coordinate transformation matrix are calculated.

The platform gimbal angles are calculated.

Sense light four (4) on the IBM 7090 is made to correspond to the condition of the Computer Running Light.

Function Sequence (continued)

The data insertion program indicator is checked and if it is time for data insertion, the pertinent data is read.

Radar data is calculated and checked to see whether it lies within the operating range of the Gemini radar. The radar ready discrete (DI 00) is turned ON or OFF, depending on the characteristics of the calculated radar data.

The spacecraft position is calculated in target-centered curvilinear coordinates.

The calculated values of the gimbal angles and radar data are saved while they are quantized, along with the accelerometer data, for use by the Rendezvous program.

Transfer is made to the control program to allow the Rendezvous program to be simulated for the Rendezvous time step.

On return from the control program, the gimbal angles and radar data are restored and the attitude error angles calculated by the simulated Rendezvous program are quantized.

Selected data is recorded both off-line and on-line.

A check is made to determine if the problem should be terminated.

Spacecraft attitude errors are used to calculate spacecraft correction maneuver rates. The attitude errors used may be those calculated in the simulated Gemini computer or they may be computed in the Environment program. If computer calculated errors about the platform are used, the pitch correction rate is limited to prevent excessive cross-coupling of attitude correction maneuvers.

The equations of motion of the spacecraft attitude are integrated over the time step of the Rendezvous program.

When the velocity to be added exceeds the thrusting capacity of the appropriate thrusters, the body thrust term is set to the thrust acceleration capacity. Also, discretes are set to indicate the zero or non-zero status of the IVI's.

The body acceleration terms are transformed to the inertial coordinate frame and transfer is back to the integration of the equations of motion.




FIGURE 2
FUNCTIONAL FLOW DIAGRAM
DYNAMIC ENVIRONMENT

Static Simulator

Unlike the dynamic simulator, this simulator operates with inputs which are static. The inputs to the simulated Gemini Computer are not changed by the program but remain constant until they are changed by an input card. This data is read in using the method described in Table 4, page 39. Initially all quantities are zeroed and will remain zero unless another value is inserted. Time is updated by DT (usually 1.0 second) every cycle through the program. Thus, time in the Gemini computer and in the environment is advanced the same increment (DT) for each Gemini computation cycle executed.

Because of the static nature of the inputs, the programmer must have a working knowledge of the Rendezvous and Catch-Up math flow in order to be able to insert the proper quantities at the proper time. For example, the programmer must know what discrete turns the radar on and off and at what time in the mission the radar will be sampled if he wants to investigate the effects of bad radar data. He must also have this knowledge if he wants to use different radar data for several points used in calculating ΔV_T .

This program is used to generate tolerances for acceptance and pad test specifications. Because it is an open-loop operation as opposed to the closed-loop dynamic simulation, the static simulation has a much greater data manipulating capability than the dynamic simulation. Because of this capability, it is possible to test certain paths in the Catch-Up and Rendezvous Math Flow which are not easily traversed by the dynamic simulation.

This program has a much shorter execution time than the dynamic simulation. A complete Rendezvous mission can be simulated in two minutes. This is due to the fact that this simulation uses the full speed capability of the 7090 and that time is advanced by the same increment (DT, usually 1.0 second) for all computer cycles which actually are considerably less than one second.

III. DETAIL DESCRIPTION OF THE RENDEZVOUS ENVIRONMENT SYSTEM

This section is a detail description of the Dynamic Environment Flow Diagrams found on Pages 52, 53, 54, 55, and 56.

Dimension, Common, Equivalence

These statements are needed to set up the FORTRAN program.

SELFLD - Tape A7

The first step in the Rendezvous simulation is to generate a self-loading tape containing all the programs used in the simulation. This tape is generated on Tape A7 by calling the subroutine SELFLD. If it should be necessary to read the programs into the 7090 computer memory again, this can be done by putting the tape on drive A1 and pushing the CLEAR and LOAD TAPE buttons on the 7090 control console.

Clear Tables

Several data tables and all of common are cleared. This insures proper initialization of each run when several runs are made in sequence without stopping the computer.

Input Data

There are four types of input data:

1. Guidance computer output variable names. These names are used to label the outputs from the simulated guidance computer. They do not determine the quantities which are printed out. There are 165 names in all. The names used and the symbols for which they stand are listed in Table 1. The format of these data cards is given in Table 2.
2. Initial conditions, environment control variables, and space-craft constants. These quantities and the format used to read them in are given in Table 3.

Input Data (continued)

3. Insertable Data. These data cards are used to simulate MDIU or DCS insertions or to change any variable in Common after the initialization of the Catch-Up and Rendezvous modes. If such insertions are not to be made during a given run, these cards should be eliminated from the data for that run. More information about these cards is given in Table 4.
4. Plot Data. These cards are used to specify the quantities to be plotted. If no plots are desired from a given run, these cards should be eliminated for that run. More information about these cards is given in Table 5.

Type 1 data is read in once for each set of runs. Type 2 data for the first run is read in, stored, and written on Tape A3 to provide a record of the values used.

The control variable LMDI is tested. If LMDI is non-zero, type 3 data will be read in and stored. As each card is read, the ILIST value on that card is tested. If ILIST is non-zero, another card is read. When a zero value of ILIST is sensed, reading of type 3 data is terminated and the stored type 3 data is recorded on Tape A3. If LMDI is zero, the program will not attempt to read type 3 data cards, and no data of type 3 should be included in the data for the run.

The control variable LOC is tested. If LOC is non-zero, type 4 data will be read in, stored, and recorded on Tape A3. If LOC is zero, the program will not attempt to read type 4 data cards, and no data of type 4 should be included in the data for the run.

When the end of the first run is reached, the control variable IEXIT is tested. If IEXIT is non-zero, there are no more runs to be made, and the simulation is terminated. If IEXIT is zero, there is at least one more run to be made. In this case the process of reading, testing, and recording data for the next run is repeated, beginning with type 2 data.

Test of MQ Key Settings - 57-58

The octal pattern set in the MQ keys is read and stored as the variable KOMBO. KOMBO is then compared with the input variable KEYSET. If the two variables do not agree, the program prints an error message to the operators and issues a Pause. When the START button on the control console is depressed, the MQ keys are read again, and a new value of KOMBO is set up. Only when KOMBO and KEYSET agree is the execution of the rest of the program allowed to continue.

Rendezvous Problem Initialization - 94-996

The Rendezvous problem is initialized by determining the positions and velocities of both the target and the spacecraft in inertial rectangular coordinates at the starting point for the flight to be simulated. This may be done in one of four ways:

1. Direct specification (MACOP = 0; MACINT = 0). The initial positions and velocities are specified by the input quantities.
2. Computation (MACOP ≠ 0, MACNTR = 0, MACINT = 0). The initial positions and velocities are given in inertial polar coordinates and are then computed in inertial rectangular coordinates.
3. Alternate computation (MACOP ≠ 0, MACNTR ≠ 0, MACINT = 0). The initial target position and velocity are specified and computed as in 2. The initial spacecraft position and velocity are specified in components relative to the target and are then computed in inertial rectangular coordinates.
4. Reverse integration (MACINT ≠ 0). The target and spacecraft positions and velocities for some point in time are determined by one of the three methods given above. The Rendezvous problem is initialized from some earlier point in time by integrating backwards in time for a time interval given by BINT. A single precision Cowells integration routine is used for this reverse integration. The time step used is 10 times the input integration time step (DT).

MODCR

The input variable MODCR is tested to ascertain which mode has been selected. If MODCR is less than one, Rendezvous has been selected; if MODCR is one, Catch-Up has been selected; and if MODCR is greater than one, Pre-Launch has been selected.

Selection of a particular mode sets the three mode discrete inputs for the guidance computer as follows:

<u>Rendezvous</u>	<u>Catch-Up</u>	<u>Pre-Launch</u>
DI 10 +	DI 10 -	DI 10 +
DI 11 -	DI 11 +	DI 11 +
DI 13 +	DI 13 -	DI 13 +

Position and Velocity Integration 101

This loop solves and integrates the equations of motion of both the target and spacecraft using a single-precision Cowells method in subroutine form. Spacecraft thrust terms, if any, are included in the computations. The time step used is equal to the input integration time step (DT).

Accelerometer Outputs - 71

The outputs of the integrating accelerometers in navigation coordinates and the total velocity change (ΔV) made along each of the spacecraft axes are computed by means of rectangular integration. There is little error with this method since the spacecraft thrust is either on or off over a complete time step and the spacecraft turning rates are low when thrust is applied.

Computation of Gimbal Angles - 72-602

The spacecraft orbital parameters and the inertial-to-navigation and navigation-to-spacecraft coordinate transformation matrices are computed. From these, the three platform gimbal angles are determined.

Computer Running Light - 603-552

Sense light four (4) on the 7090 control console is used to simulate the Computer Running Light in the Gemini spacecraft. The condition of this light is controlled by a discrete output (DO 05) from the guidance computer.

START COMP

The START COMP discrete input to the guidance computer, DI 21, may be set on (-) in one of the three following ways:

1. Depress Key 17 on the 7090 control console.
2. Enter the desired time of START COMP through the input variable STCT. When the simulated elapsed time reaches this value, DI 21 will be set (-).
3. By the data insertion technique described below (a type three special data insert).

In the FORTRAN simulation, a non-zero value for a discrete input or output indicates that the discrete has been set (-). The methods of setting DI 21 (-) set it to different values (2047, 4095, and 72191 respectively). Thus it is easy to tell which method was used to set the START COMP discrete.

START COMP (continued)

When LDI 21 is set (-), the quantity TSC is set equal to the simulated time (T). Thus a record is kept of the time at which START COMP was pushed.

Data Insertion

If LMDI ≠ 0, new values will be inserted for selected quantities at preselected times during the simulation. When the time for inserting a new value for a variable is reached, the value to be inserted is taken from the table of type 3 data read in at the start of the simulation. This new value is then used to update the variable in question.

Radar Parameters - 111-763

The line-of-sight distance (radar range) between target and spacecraft is computed using inertial position components. Radar range rate is calculated. The radar azimuth angle is computed based on the position of the target relative to the spacecraft.

The azimuth angle is checked to see if it falls in the range $\pm 25^\circ$. If the azimuth angle does fall in this range, its sine is computed and modified to simulate measurement errors. The elevation angle is computed and tested, and its sine is computed and modified to simulate measurement errors, if the test is passed.

The spacecraft turning rates are checked to see that they are no greater than 1.5° per second. If the turning rates do not exceed 1.5° per second, the radar information can be used accurately in computations.

If the radar angle tests and the turning rate tests are all passed, DI 00 is set (-) to indicate that the radar data is good and can be used in computations. If any of the tests are not passed, the radar data cannot be used and DI 00 is set (+). This means that the guidance computer will not read any information from the radar.

DI 00 can also be set (+) by setting the variable LQT to a non-zero value via a type 3 data insert. Thus loss of radar lock-on can be simulated any time during a run.

Flight Director Indicator Logic - 449-456

This logic determines whether error angles based on the radar angles (LRDFDI -) or error angles based on computer values (LRDFDI +) will be flown.

Relative State Vector Computation - 787

The inertial spacecraft state vector is transformed into an earth-centered rectangular coordinate system with Y axis intersecting the target and X and Y axes lying in the target orbital plane. The elements of the transformed state vector are used to compute the spacecraft state vector in a target-centered curvilinear coordinate system. The resulting relative state vector is included in the output for reference purposes only. It is not used in any other calculations.

Data Quantization - 920-424

If the necessary control variables are set to the proper values, the gimbal angle, accelerometer, and radar data can be quantized before being sent to the guidance computer. This simulates the quantization that would be placed on this data by the actual hardware. The unquantized gimbal angle and radar data is saved for off-line printout.

Control Program

As mentioned in Section II of this report, communication between the guidance computer and the simulated environment is established through a control program (CTRL 1).

The program uses the channel interrupt feature of the 7090 and allows the simulated guidance computer to run continuously. Since the Gemini computer has no fixed computation cycle in the Catch-Up and Rendezvous modes, this simulates the operation of the actual hardware.

When the Environment program calls CTRL 1, keys 21 through 35 on the 7090 console are read. The value set in these keys determines the relation between the operating times of the 7090 and the simulated guidance computer. For example, if the value 30₈ (i.e., 24₁₀) is placed in the keys, 24 milliseconds of 7090 operation will correspond to one time increment of operation of the Gemini computer.

The control program computes the number of words which can be written on a tape during the time interval specified by the setting in the keys. The computer then begins to write zeros on Tape B6. While this is being done, the Executor and Rendezvous subroutines are exercised in the manner described in Part II of this report. When the computed number of words has been written, the operation of the simulated guidance computer is interrupted in the Executor subroutine, and transfer is back to the Environment program.

Error Angle Quantization - 404-419

If the control variable LDB is set to a non-zero value, the attitude error angles will be quantized to either high or low range, depending on the size of the errors.

Output - 406-142

If certain conditions are met, one line of output will be written on A3 and printed on the on-line printer during each cycle through the Environment program. The conditions are:

1. Simulated time (T) is 10 seconds or less and Key 19 is down or
2. The Computer Running Light is ON, Key 19 is down, CTTG = 0, FIN = 0, and at least one of the IVI's is displaying a non-zero value or
3. Radar range (TRI) is no greater than a value specified by ESPR and Key 19 is down or
4. Key 15 is down or
5. IOLP ≠ 0.

The information contained in this one line of output is changed 150 seconds after the nominal time for applying the final vernier correction. Samples of both sets of variables provided are included in Appendix B.

In addition to the single line output, two pages of off-line output are written on Tape A3 at periodic intervals. A sample of each of these pages is included in Appendix B.

The frequency at which the two pages of output are written is governed by the quantity COINT. The actual writing times are biased by the value of the variable DELAY. For example, if

COINT = 50

DELAY = 0

two pages will be written out at

T = 0, 50, 100, 150, etc.

Output - 406-142 (continued)

If GOINT = 100
 DELAY = 20

two pages will be written out at

T = 0, 20, 120, 220, 320, etc.

Every time the two pages of output are produced, the single line of output described above is also produced both on-line and off-line.

In addition to the controls given above, some other console keys can be used to govern both on-line and off-line output. These keys and their functions are listed in Table 6.

Digital Plotting - 123-10007

If LOC does not equal zero, data will be written on Tape A9. This data is then used to plot curves on the off-line plotter. A maximum of 50 quantities may be written out. This data is written out each computer cycle. The quantities to be written out are determined by type 4 data inputs.

Run Termination - 10008-654-336

A simulation run can be terminated in two ways. One method is to put Key 16 on the console DOWN. This will terminate all operation almost immediately. If Key 16 is not used, the run will be terminated when simulated time T becomes greater than the value of the input variable EOP.

When a run is terminated, an indication of the method of termination is written out on-line and off-line. If Key 16 is used, the contents of the computer is written on Tape A7. The run can be completed at a later time by placing the tape from A7 on drive A1 and pressing the CLEAR and LOAD TAPE buttons on the 7090 control console.

If Key 16 is DOWN, operation will terminate at this point. If Key 16 is UP and the control variable IEXIT = 0, transfer will be back to the beginning of the Environment program to begin another run. If IEXIT ≠ 0, there are no more runs to be made, and operation will terminate.

Attitude Computations - 655-706

If radar direction of the Flight Director Indicators is being simulated (LRDFDI -) the radar line-of-sight attitude errors are computed, normalized, and limited. The errors are then transformed into errors about body axes.

If the error angles calculated by the simulated guidance computer are being used, they will be subjected to two magnitude checks. If the roll error is greater than 0.04 radians, the yaw and pitch errors will be neglected. If the yaw error is greater than 0.04 radians, the pitch error will be neglected. The errors are transformed from navigational axes to body axes, and a pitch rate is selected based upon the magnitude of the commanded yaw angle. The three possible pitch rates are specified as input data.

The angular turning rates about the three spacecraft axes are computed and limited. The equations of motion of spacecraft attitude are then solved and integrated to determine the new attitude of the body. The spacecraft axial thrusts are set to zero prior to these computations.

IVI Zeroing - 811-33

The discrete output DO 11 from the guidance computer to the IVI's is checked to see if the channels should be zeroed. If so, the proper terms are set to zero. If the IVI's are being zeroed, no thrusting will be done.

Spacecraft Thrusting - 32-24

Spacecraft thrusting will be simulated only if all of the following conditions are fulfilled:

- (a) The thrust in question is desired. (Indicated by a non-zero value of the proper ITH).
- (b) START COMP has been pressed (LDI 21 (-)).
- (c) Simulated computer time CT is no less than the time to apply the first thrust.
- (d) T is at least 10 seconds greater than the time at which START COMP was pressed.
- (e) LDI 11 is (-), or LDI 11 is (+) and CTTG = 0.

Spacecraft Thrusting - 32-24 (continued)

The spacecraft thrust terms were all set to zero when the new attitude of the spacecraft was being computed. If all of the conditions listed above are fulfilled, the values of the thrust terms may be changed. The changes depend upon the reading of the IVI's. The X thrust term is computed as follows:

(a) If $\Delta V_X = 0$,
X thrust term = 0

(b) When ΔV_X is (+)
If $\Delta V_X > CATXBA - 0.5$
X thrust term = CATXBA

If $\Delta V_X \leq CATXBA - 0.5$
X thrust term = ΔV_{XB}

(c) When ΔV_X is (-)
If $\Delta V_X < CATXFW - 0.5$
X thrust term = CATXFW

If $\Delta V_X \geq CATXFW - 0.5$
X thrust term = ΔV_{XB}

where:

ΔV_X = value on the X channel of the IVI's

ΔV_{XB} = velocity change to be added along the X axis

CATXBA = thrust capability of the Aft X axis thruster

CATXFW = thrust capability of the Forward X axis thruster.

The Y and Z thrust terms are computed in a similar manner except both directions of the Y and Z thrusters have the same thrust capacity.

IVI Discretes - 21-506

The three IVI channels are checked for zero readings. The following discrete signals are generated for the guidance computer as a result of these tests:

	ΔV_X	ΔV_Y	ΔV_Z
Zero	LDI 31 +	LDI 25 +	LDI 26 +
Non-Zero	LDI 31 -	LDI 25 -	LDI 26 -

Thrust Transformation - 509

The spacecraft thrust terms are transformed into the inertial coordinate frame. These terms are then used in the position and velocity integration loop to compute new positions and velocities for the target and the spacecraft.

This completes the detail description of the Dynamic Environment program.

TABLE 1

GUIDANCE COMPUTER OUTPUT VARIABLE NAMES

CA 11 CA 12 CA 13 CA 21 CA 22 CA 23 CA 31 CA 32 CA 33	{ Elements of the navigation axes to body axes coordinate transformation matrix (A 11 - A 33).
CAPTI CATXBI CCABI CCASI	{ See note at end of this table.
CCK 1 CCK 2 CCK 3 CCK 4 CCK 5 CCKF CCKG	{ Clohessy-Wiltshire coefficients (CK 1 - CK 5, CKF, CKG).
CCPSIR	Cosine of second rotation (yaw) in the coordinate transformation from body axes to radar line-of-sight ($\cos \psi_R$).
CCRI CCRSI C0I C21	{ See note at end of this table.
CCTHR	Cosine of first rotation (pitch) in the coordinate transformation from body axes to radar line-of-sight ($\cos \theta_R$).
CDEL	Orbital angle between successive intermediate velocity corrections (Δ).

TABLE 1
(continued)

CDPHSC CDPSSC CDTHSC	} Spacecraft attitude error angles (roll, pitch, yaw). ($\Delta\phi_{SC}$, $\Delta\theta_{SC}$, $\Delta\psi_{SC}$).
CDRRD	Range rate error (reference range rate minus range rate). $\Delta\dot{R}_R$
CDTM	Time interval between successive intermediate velocity corrections (ΔT_M).
CDTW	Logical timer used in gathering of radar data. Also a measure of the lateness of any radar point. Set to -1 if the point is missing (Δt_w).
CDTX	Constant time interval, either 100 or 20 seconds, used to increment T_X (ΔT_X).
CDV	Prior to START COMPUTATION, the total velocity change required for Rendezvous and braking. After START COMPUTATION, the integral part of the velocity change to be processed on the output delay line to a selected incremental velocity meter (ΔV).
CDVF	Estimated velocity change (braking impulse) necessary to match velocities of target and spacecraft at intercept (ΔV_f).
CDVI	Velocity change necessary to match positions of target and spacecraft (ΔV_i).
CDVT	Total velocity change necessary to match positions and velocities of target and spacecraft (Rendezvous). ΔV_T
CDVXB CDVYB CDVZB	} Desired velocity changes along the body X, Y, and Z axes (ΔV_{xb} , ΔV_{yb} , ΔV_{zb}).
CDVXM CDVYM CDVZM	} Negatives of the desired velocity changes along the navigation axes (ΔV_{XM} , ΔV_{YM} , ΔV_{ZM}).

TABLE 1
(continued)

CDVXS CDVYS CDVZS	Velocity changes to be placed on the ΔV meters (ΔV_{XS} , ΔV_{YS} , ΔV_{ZS}).
CDVXZ CDVYZ CDVZZ	Present readings of the ΔV meters (ΔV_{XO} , ΔV_{YO} , ΔV_{ZO}).
CDXD CDYD CDZD	<u>Catch-Up:</u> Velocity changes desired to be made along the spacecraft navigation axes.
	<u>Rendezvous:</u> Velocity changes along the spacecraft navigation axes required for Rendezvous in the desired time ($\Delta \dot{X}$, $\Delta \dot{Y}$, $\Delta \dot{Z}$).
CDXFD CDYFD CDZFD	Estimated velocity changes (braking impulses) along the target axes necessary to match target and spacecraft velocities at intercept ($\Delta \dot{X}_f$, $\Delta \dot{Y}_f$, $\Delta \dot{Z}_f$).
CFX CFY CFZ	Sensed velocity changes along the navigation axes (F_X , F_Y , F_Z).
CM 1 CM 3 CM 4 CM 5 CM 6	Constants used in computing spacecraft position in target coordinates (CM 1, CM 3 - CM 6).
CNS	Updated constant used to determine $\Delta \dot{X}$, $\Delta \dot{Y}$, and $\Delta \dot{Z}$ in the smoothing process (N_S).
COEFF	Quantity used in computing Clohessy-Wiltshire coefficients (COEFF).
COMGS	Spacecraft orbital angular velocity assuming the spacecraft is in a circular orbit with radius equal to the last computed value of r_S (ω_S).
CPHIB CPSIB CTHB	Spacecraft roll, pitch and yaw angles read from the spacecraft platform gimbals (ϕ_b , θ_b , ψ_b).

TABLE 1
(continued)

CPSIBC } CTHBC }	Commanded spacecraft attitude angles (pitch and yaw) computed in a pitch, yaw sequence (Ω_{bc} , ψ_{bc}).
CPSBCP } CTHBCP }	Commanded spacecraft attitude angles (pitch and yaw) computed in a yaw, pitch sequence. Used only for MDIU display to allow use of the attitude ball as back-up for the flight director needles of the attitude display group (ψ'_{bc} , Ω'_{bc}).
CPSIBM } CTHBM }	Computed spacecraft pitch and yaw angles necessary to obtain radar lock-on (ψ_{bm} , Ω_{bm}).
CRA	The average value of five radar ranges for use in the range rate calculations (R_A).
CRLO	MDIU input variable used as a logical choice. Initialized to 0 in RZ 118. If set to any non-zero value, will cause the sines of the radar angles to be set to 0 (RLO).
CRR	<u>In Catch-Up:</u> Value of radar range transmitted via the DAS. This parameter is updated every cycle if a good radar point is taken.
	<u>In Rendezvous:</u> Value of radar range used in the relative position computations. This parameter is transmitted via the DAS and is displayed on the MDIU (R_R).
CRRD	Range rate (\dot{R}_R).
CRRG	The value of radar range the last time a good radar point was taken. This parameter is displayed on the MDIU (R_{RG}).
CRRI	Radar range read from the radar every computer cycle (R_{RI}).
CCRPI	Radar range read from the second sample taken in the two- point comparison routine (R_{RI}').
CRS	Distance from geocenter to the spacecraft (R_S).
CR 1	The average radar range the last time the range rate calculations were performed (R_1).

TABLE 1
(continued)

CSADPI	Sine of the radar elevation angle from the second sample of the two-point comparison routine ($\sin a''_I$).
CSAPG	The compensated value of the sine of the radar elevation angle the last time a good radar point was taken. This parameter is displayed on the MDIU ($\sin a'_G$).
CSAPI	Sine of the radar elevation angle read from the radar and compensated for measurement errors ($\sin a'_I$).
CSAPR	<u>In Catch-Up:</u> Compensated value of the sine of the radar elevation angle transmitted via the DAS. This parameter is updated every cycle if a good radar point is taken. <u>In Rendezvous:</u> Compensated value of the sine of the radar elevation angle used in the relative position computations and transmitted via the DAS ($\sin a'$).
CSPSIR	Sine of the second rotation (yaw) in coordinate transformation from body axes to radar line-of-sight ($\sin \psi_R$).
CSRDP1	Sine of the radar azimuth angle from the second sample of the two-point comparison routine ($\sin r''_I$).
CSRPG	The compensated value of the sine of the radar azimuth angle the last time a good radar point was taken. This parameter is displayed on the MDIU ($\sin r'_G$).
CSRPI	Sine of the radar azimuth angle read from the radar and compensated for measurement errors ($\sin r'_I$).
CSRPR	<u>In Catch-Up:</u> Compensated value of the sine of the radar azimuth angle transmitted via the DAS. This parameter is updated every cycle if a good radar point is taken. <u>In Rendezvous:</u> Compensated value of the sine of the radar azimuth angle used in the relative position computations and transmitted via the DAS ($\sin r'$).
CSRTI	See note at end of this table.

TABLE 1
(continued)

CSTD	Nominal time difference between radar position measurements used in determining the smoothed velocity of the spacecraft (t_d).
CSTDL	Time difference between radar position measurements, corrected for lateness of the radar measurements (t_{dL}).
CSTHR	Sine of the first rotation (pitch) in the coordinate transformation from body axes to radar line-of-sight ($\sin \Theta_R$).
CSTZ	Time constant set 23 seconds greater than the time at which the IVI channels are started driving toward zero. If all three channels of the IVI have not reached zero by the time $t = t_0$, a malfunction will have occurred and the IVI zeroing loop will be terminated (t_0).
CT	Elapsed time since initialization of mode. Read during each cycle through the Executor. However, during execution of the self-test, CT is updated by one second each cycle through the Rendezvous program (t).
CTD	Prior to the first thrust, the time interval between the last relative position computations made prior to START COMPUTATION and the midpoint of the first thrust. After the first thrust, the time interval between the midpoint of a thrust and a predicted spacecraft position after that thrust (T_D).
CTDAS	Elapsed time since initialization of mode. Read during each cycle through Executor. CT and CTDAS are equal <u>except</u> during execution of the self-test. (t_{DAS}).
CTDV	Time at which the first thrust should be applied ($T_{\Delta V}$).
CTLRP	Time of the last relative position computations (t_{LRP}).
CTM	Initially, the time of the first good radar point used in the relative position computations. After START COMPUTATION, the time of the midpoint of the first thrust. Incremented by ΔT_M to give the times of application of the intermediate thrusts (T_M).

TABLE 1
(continued)

CTR R	CTR	Variable used to determine whether or not the range rate calculations should be performed during the present cycle (TRR).
CTR1	CTR1	The time the last range rate calculations were performed (t_{R1}).
CTX	CTX	Time constant incremented by ΔT_X . Used as a logical timer in the gathering of radar data (T_X).
CUDPHS CUDPSS CUDTHS		Unlimited values of spacecraft attitude error angles (roll, pitch, yaw). ($\Delta\phi_{SC}$, $\Delta\theta_{SC}$, $\Delta\psi_{SC}$).
CWSTD	CWSTD	Product of COMGS(ω_S) and CTD(T_D).
CWSTDL	CWSTDL	Orbital angular difference between two radar position measurements, corrected for lateness of the measurements; or orbital angular distance to Rendezvous ($\omega_s t_{dL}$).
CWTTPR	CWTTPR	Orbital angular distance to Rendezvous ($\omega_{T_{PR}}$).
CX CY CZ		Spacecraft position coordinates in a rotating, curvilinear coordinate system centered in the target (X, Y, Z).
CXM CYM CZM		Spacecraft position coordinates at the midpoint of one of the correctional thrusts (X_M , Y_M , Z_M).
CXRD CYRD CZRD		Velocities along the target X, Y, and Z axes required for Rendezvous in the desired time (\dot{X}_R , \dot{Y}_R , \dot{Z}_R).
CXSD CYSD CZSD		Aggregate velocity changes along navigation axes required for Rendezvous. Divided by CNS to give CDXD, CDYD, and CDZD. (\dot{X}_S , \dot{Y}_S , \dot{Z}_S).
CXTD CYTD CZTD		Spacecraft velocities along the target X, Y, and Z axes computed from one pair of position measurements (\dot{X}_t , \dot{Y}_t , \dot{Z}_t).

TABLE 1
(continued)

CXZ }	Values of CX, CY, and CZ extracted from the radar data table used in calculating CXTD, CYTD, and CZTD.
CYZ }	
CZZ }	(X_o , Y_o , Z_o).
FIN }	
FP }	See note at end of this table.
IC	Floating index used to denote the table location for storage of radar data. Ranges from zero to 10 prior to START COMPUTATION, from three to 10 after START COMPUTATION (i).
KC	Subscript index used for extracting data from the radar table for use in the smoothing equations (K).
K2C	Counter denoting the number of points yet to be smoothed. Ranges from zero to seven (K_2).
L	Counter used in the range rate calculations. Ranges from zero to five (L).
LC1	Logical choice serving two purposes: <ol style="list-style-type: none">Initialized (-) to permit zeroing of the ΔV meters when the mode is initialized. Set (+) when all ΔV meters have been zeroed or 23 seconds after the meters are started driving toward zero, whichever occurs first. Always (+) thereafter except for temporary usage in (b).Set (-) at the start of the smoothing sequence. Reset (+) after the first set of Clohessy-Wiltshire constants have been computed (LC 1).
LC2	Logical choice always (+) prior to START COMPUTATION time in Rendezvous. Set (-) after seven computations of relative position have been made following a thrust. Reset (+) when smoothing has been completed prior to the next thrust (LC 2).
LC3	Logical choice always (+) prior to and always (-) after START COMPUTATION time (LC 3).

TABLE 1
(continued)

LC7 Logical choice serving three purposes:

- a) Always (+) until a good radar point is used in the relative position computation. Always (-) thereafter except for temporary usage in (b) and (c).
- b) Set (+) just prior to the computation of predicted radar pointing angles 80 seconds before a thrust. Reset (-) when the computations are completed.
- c) Set (+) after calculating the smoothed spacecraft velocity at the last radar point to allow calculation of the velocity changes required for Rendezvous from the extrapolated thrust midpoint. Reset (-) when the operation is completed (LC 7)..

LC8 Logical choice serving three purposes:

- a) Set (+) to allow initializing IVI outputs to desired velocity changes. Set (-) during the initialization.
- b) Set (-) to allow the same equations to be used for computing CK 4 and CKF, CK 5 and CKG. Set (+) when the computations are completed.
- c) Used to allow prediction of spacecraft position 80 seconds prior to a thrust only once for each thrust. Left in (-) state from use in (a). Set (+) just before prediction equations are solved (LC 8)..

LC10 Logical choice set (+) when it is time to perform the range rate calculations. Set (-) after these calculations are performed (LC10)).

LC4C Logical choice set (+) in all modes except Catch-Up to permit an initializing pass of Catch-Up when switching modes (LC4C).

LC4D Logical choice set (+) in all modes except Rendezvous to permit an initializing pass of Rendezvous when switching modes (LC4D)..

TABLE 1
(continued)

LC1J	Logical choice used to select one channel of the IVI for output processing. Set (-) for X channel, (0) for Y channel, and (+) for Z channel (LC1J).
LCA	Logical choice initialized to zero. If a non-zero value for LCA is inserted via the MDIU only the X channel of the IVI will be updated (LCA).
LCS	See note at end of this table.
LDI00	Discrete input indicating that radar is ready (-) or not ready (+) with valid data for the computer (DI 00).
LDI21	Discrete input indicating that the START COMPUTATION button has (-) or has not (+) been pushed (DI 21).
LDO05	Discrete output to turn Computer Running (START COMPUTATION) Light on (-) and off (+) (DO 05).
M	Control variable used to cause proper branching during the range rate calculations. M is set equal to zero during initialization and whenever range rate and range rate error are flagged to 9999. It remains zero whenever range rate and range rate error are 9999. All other times M equals one (M).
N	Control variable used in the two-point comparison routine. N is set to -1 prior to taking the first point; set to 0 after the first point is taken (N).
RDGD	Indicator set (+) if a good radar sample has been taken. Set (-) if a bad radar sample has been taken (RDGD).
RRDREF	Reference range rate (\dot{R}_{RREF}).
SW } TEST } TPC }	See note at end of this table.
TSC	Time at which START COMP was pressed.

TABLE 1
(continued)

TVX }
TVY }
TVZ }
TYC }

See note at end of this table.

NOTE: These quantities are used only in Module III.

TABLE 2

INPUT DATA SUPPLIED ONLY ONCE FOR EACH SET
OF DYNAMIC SIMULATIONS

(Type 1 Data)

<u>COLUMN</u>	<u>VARIABLE</u>	<u>FUNCTION</u>
---------------	-----------------	-----------------

Card 1 (FORMAT: 12A6)

1- 6	REM (1)	First output variable name
7-12	REM (2)	Second output variable name.
:	:	:
67-72	REM (12)	Twelfth output variable name.

Cards two through 13 are arranged in the same manner and specify the 13th through 165th output variable names.

Card 14 (FORMAT: 12A6)

1- 6	REM (157)	157 th output variable name.
:	:	:
49-54	REM (165)	165 th output variable name.
55-72	Blank	

TABLE 3

INPUT DATA SUPPLIED FOR EACH DYNAMIC SIMULATION
(Type 2 Data)

COLUMN VARIABLE FUNCTION

Card 1 (FORMAT: 1X, I2, 1X, I2, 1X, I2, 10X, A6, A6)

1-11	Blank	
12-13	NDATE1	Month of year.
14	Blank	
15-16	NDATE2	Day of year.
17	Blank	
18-19	NDATE3	Year.
20-29	Blank	
30-35	NRUN1	Run designation.
36-41	NRUN2	

12A6

columns 25-72 printed
as run number

Card 2 (FORMAT: 6E12.8)

1-12	EOP	Time to terminate run (sec.).
13-24	STCT	Time at which START COMP is to be pushed (sec.).
25-36	CTZ	Value to which time in the environment will be initialized (usually zero) (sec.).
37-48	CTE	Elapsed time from lift-off (sec.).
49-60	COINT	Number of simulated seconds between successive two-page outputs.
61-72	DELAY	Amount by which two-page output time will be biased (sec.).

Card 3 (FORMAT: 6E12.8)

1-12	ESPR	Maximum radar range which will cause one line to be written out during each cycle through the environment (ft.).
13-24	DT	Number of simulated seconds per time increment (usually 1.0).
25-36	BINT	Time interval over which reverse integration is to be carried out (sec.).

TABLE 3
(continued)

COLUMN VARIABLE FUNCTION

Card 3 (FORMAT: 6E12.8) (continued)

37-48	CAPT	Target orbital period (sec.).
49-60	COMGT	Target orbital angular velocity, ω_T (rad/sec).
61-72	CSRT	Target orbital radius, r_T (ft.).

Card 4 (FORMAT: 6E12.8)

1-12	XI	Spacecraft initialization parameters. See note at end of this table.
13-24	YI	
25-36	ZI	
37-48	DXI	
49-60	DYI	
61-72	DZI	

Card 5 (FORMAT: 6E12.8)

1-12	XTI	Target initialization parameters. See note at end of this table.
13-24	YTI	
25-36	ZTI	
37-48	DXTI	
49-60	DYTI	
61-72	DZTI	

Card 6 (FORMAT: 6E12.8)

1-12	RJ	Earth oblateness constant.
13-24	CATXBA	Aft.
25-36	CATXFW	Fwd.
37-48	CATYB	Lft. - Rt.
49-60	CATZB	Up-Dn.
61-72	XKRDR	Maximum reliable radar range, K_R (ft.).

Card 7 (FORMAT: 6E12.8)

1-12	CCAB	Radar elevation angle bias constant.
13-24	CCAS	Radar elevation angle slope constant.
25-36	CCRB	Radar azimuth angle bias constant.

TABLE 3
(continued)

COLUMN VARIABLE FUNCTION

Card 7 (FORMAT: 6E12.8) (continued)

37-48	CCRS	Radar azimuth angle slope constant.
49-60	C0	Radar range rate bias constant (ft/sec).
61-72	C2	Radar range rate weighting factor (ft ² /sec).

Card 8 (FORMAT: 6E12.8)

1-12	A 11	Elements of the spacecraft to inertial coordinate transformation matrix.
13-24	A 12	
25-36	A 13	
37-48	A 21	
49-60	A 22	
61-72	A 23	

Card 9 (FORMAT: 6E12.8)

1-12	A 31	Elements of the spacecraft to inertial coordinate transformation matrix.
13-24	A 32	
25-36	A 33	
37-48	AKX 1	
49-60	AKX 2	
61-72	AKX 3	

Platform misalignment and scale factor matrix elements.

Card 10 (FORMAT: 6E12.8)

1-12	AKX 4	X accelerometer bias constant (ft/sec ²).
13-24	AKY 1	Platform misalignment and scale factor matrix elements.
25-36	AKY 2	
37-48	AKY 3	
49-60	AKY 4	
61-72	AKZ 1	

Y accelerometer bias constant (ft/sec²).
Platform misalignment and scale factor matrix element.

TABLE 3
(continued)

<u>COLUMN</u>	<u>VARIABLE</u>	<u>FUNCTION</u>
<u>Card 11 (FORMAT: 6E12.8)</u>		
1-12	AKZ 2	Platform misalignment and scale factor matrix elements.
13-24	AKZ 3	
25-36	AKZ 4	Z accelerometer bias constant (ft/sec ²).
37-48	XKP 1	
49-60	XKP 2	Spacecraft pitch rate gain factors.
61-72	XKP 3	
<u>Card 12 (FORMAT: 6E12.8)</u>		
1-12	XKR	Spacecraft roll rate gain factor.
13-24	XKY	Spacecraft yaw rate gain factor.
25-36	CCR	Radar range tolerance constant (ft.).
37-48	Blank	THRUST THRESHOLD
49-72	Blank	
<u>Card 13 (FORMAT: 10I3, 7I6)</u>		
1- 3	ITH (1)	
4- 6	ITH (2)	
7- 9	ITH (3)	
10-12	ITH (4)	
13-15	ITH (5)	
16-18	ITH (6)	
19-21	ITH (7)	
22-24	ITH (8)	
25-27	ITH (9)	
28-30	ITH (10)	
31-36	MACOP	<p>Variables used to control, in sequence, the thrusting maneuvers executed during a Rendezvous mission. If a particular ITH is equal to zero, the thrust maneuver associated with that ITH will not be made; if the ITH is not equal to zero, the thrust will be made.</p> <p>= 0: Input data gives initial positions and velocities for spacecraft and target in earth centered inertial rectangular coordinates.</p> <p>≠ 0: Input data gives initial position and velocity for target in inertial polar coordinates. Specification of initial position and velocity for spacecraft depends upon MACNTR.</p> <p>< 0: Input data gives initial target position & velocity in rectangular ECI sk in relative coordinates.</p>

TABLE 3
(continued)

<u>COLUMN</u>	<u>VARIABLE</u>	<u>FUNCTION</u>
Card 13 (FORMAT: 10I3, 7I6) (continued)		
37-42	MACNTR	= 0. Input data gives initial position and velocity for spacecraft in inertial polar coordinates. # 0. Input data gives initial spacecraft position and velocity in target centered curvilinear coordinates.
43-48	MACINT	= 0. No effect.
49-54	MODCR	# 0. Reverse integration will be used to derive initial conditions for the Rendezvous problem from the input data. <1. Rendezvous mode selected. = 1. Catch-Up mode selected. >1. Pre-launch mode selected.
55-60	NPF	Additional mode selection must be made with special data inputs. Number of time increments per complete integration cycle (usually 1.0).
61-66	L0C	= 0. No effect.
67-72	LMDI	# 0. Will cause data to be assembled for curve plotting. Type 4 data inputs must be included. = 0. No effect. <0. Simulated inputs for an operational simulation will be read in and inserted at the proper time. >0. Simulated inputs for a FORTRAN simulation will be read in and inserted at the proper time.

TABLE 3
(continued)

COLUMN	VARIABLE	FUNCTION
<u>Card 14 (FORMAT: 12I6)</u>		
1- 6	LFP	= 0. No effect. ≠ 0. Quantize accelerometer data.
7-12	LGANG	= 0. No effect. ≠ 0. Quantize gimbal angle data.
13-18	LRR	= 0. No effect. ≠ 0. Quantize radar range.
19-24	LSRA	= 0. No effect. ≠ 0. Quantize the sines of the radar angles.
25-30	LRM	= 0. No effect. ≠ 0. Limit radar range to a maximum value of 1,510,797 ft.
31-36	LDB	= 0. No effect. ≠ 0. Quantize spacecraft attitude error angles.
37-42	LFDI	= 0. Control the spacecraft to the attitude commanded by the Gemini computer if CRL0 ≠ 0.
43-48	IEXIT	➤ 0. Prior to START COMP control the spacecraft to hold radar line-of-sight to the target. After START COMP control the spacecraft to the attitude commanded by the Gemini computer provided the other necessary conditions are met. = 0. Following the completion of the present run, data cards for another run will be read in. ≠ 0. The present run is the last. The program will stop when the present run is completed. = 0. NO SELF TEST ≠ 0. SELF TEST - LOAD CHECK SUMS

54
49-72

LRST
Blank

55-72

Blank

TABLE 3
(continued)

COLUMN VARIABLE FUNCTION

Card 15 (FORMAT: 012) 3E12.8)

1-12 KEYSET Octal pattern of desired MQ key settings.
Key DOWN = 1, key UP = 0.

13 ~~48~~ Blank Pitch, yaw, roll gimbal biases

NOTE: The spacecraft and target initialization parameters have different meanings, depending upon the values of the environment control variables MACOP and MACNTR..

If MACOP = 0.

XI }		Spacecraft position (ft.).	Earth centered inertial rectangular coordinate frame.	
YI }				
ZI }				
DXI }		Spacecraft velocity (ft/sec).		
DYI }				
DZI }				
XTI }		Target position (ft.).		
YTI }				
ZTI }				
DXTI }		Target velocity (ft/sec).		
DYTI }				
DZTI }				

	If MACOP > 0 and MACNTR = 0.		
XI	Longitude, θ_F (degrees)	Spacecraft	Earth centered inertial polar coordinate fram
YI	Latitude, ϕ_F (degrees)		
ZI	Radius, r_F (ft.)		
DXI	Flight Path Angle, γ_F (degrees)		
DYI	Heading Angle, ψ_F (degrees)		
DZI	Velocity, V_F (ft/sec)		
XTI	Longitude, θ_T (degrees)		
YTI	Latitude, ϕ_T (degrees)		
ZTI	Radius, r_T (ft.)		
DXTI	Flight Path Angle, γ_T (degrees)		
DYTI	Heading Angle, ψ_T (degrees)		
DZTI	Velocity, V_T (ft/sec)		

TABLE 3
(continued)

COLUMN VARIABLE FUNCTION

Card 15 (FORMAT: O12) (continued)

	If MACOP \neq 0 and MACNTR \neq 0.	
XI	XTF	Spacecraft position (ft.).
YI	YTF	
ZI	ZTF	
DXI	XDTF	Spacecraft velocity (ft/sec.).
DYI	YDTF	
DZI	ZDTF	
XTI YTI ZTI DXTI DYTI DZTI		Same as for MACNTR = 0.

If MACOP $<$ 0

XI
YI
ZI
DXI
DYI
DZI

Same as for MACOP > 0 , MACNTR \neq 0

XTI
YTI
ZTI
DXTI
DYTI
DZTI

Same as for MACOP = 0

TABLE 4

INSERTABLE DATA
FOR DYNAMIC OR STATIC SIMULATIONS
(Type 3 Data)

There is one card for each data input prepared as follows:

<u>COLUMN</u>	<u>TABLE</u>	<u>DESCRIPTION</u>
1- 6	S LIST	The SLIST table contains the symbolic name of the data input.
7-21	T LIST	The TLIST table contains the time when the data input shall be inserted into the program.
22-36	D LIST	The DLIST table contains the data to be inserted into the program.
37-40	I LIST	The ILIST table contains the position in the tables of the information associated with the data input.

Following is a tabulation of the SLIST names and the associated ILIST subscripts:

<u>SUBSCRIPT</u>	<u>SYMBOL</u>	<u>SUBSCRIPT</u>	<u>SYMBOL</u>
1	CDVXSP	36	CAPTI
2	CDVYSP	37	CATXBA
3	CDVZSP	38	CATXBI
4	CDPHSC	39	CCAB
5	CDPSSC	40	CCABI
6	CDTHSC	41	CCAS
7	AKX 1	42	CCASI
8	AKX 2	43	CCK 1
9	AKX 3	44	CCK 2
10	AKX 4	45	CCK 3
11	AKY 1	46	CCK 4
12	AKY 2	47	CCK 5
13	AKY 3	48	CCKF
14	AKY 4	49	CCKG
15	AKZ 1	50	CCPHIB
16	AKZ 2	51	CCPSIB
17	AKZ 3	52	CCPSIR
18	AKZ 4	53	CCR
19	ASFY	54	CCRB
20	ASFY	55	CCRBI
21	ASFZ	56	CCRI
22	C 0	57	CCRS
23	C 0I	58	CCRSI
24	C 2	59	CCTHB
25	C 21	60	CCTHR
26	CA 11	61	CCWSTD
27	CA 12	62	CCWTDL
28	CA 13	63	CCZT
29	CA 21	64	CDEL
30	CA 22	65	CDRRD
31	CA 23	66	CDTM
32	CA 31	67	CDTW
33	CA 32	68-78	CDTWT
34	CA 33	79	CDTWX
35	CAPT	80	CDTX

<u>SUBSCRIPT</u>	<u>SYMBOL</u>	<u>SUBSCRIPT</u>	<u>SYMBOL</u>
81	CDV	116	CNYC
82	CDVF	117	COEFF
83	CDVI	118	COINT
84	CDVT	119	COMGS
85	CDVXB	120	CPHIB
86	CDVXM	121	CPHIBC
87	CDVXS	122	CPSBCP
88	CDVXZ	123	CPSIB
89	CDVYB	124	CPSIBC
90	CDVYM	125	CPSIBM
91	CDVYS	126	CR 1
92	CDVYZ	127	CRA
93	CDVZB	128	CRLO
94	CDVZM	129	CRR
95	CDVZS	130	CRRD
96	CDVZZ	131	CRRG
97	CDXD	132	CRRI
98	CDXFD	133	CRRPI
99	CDYD	134	CRS
100	CDYFD	135	CSADPI
101	CDZD	136	CSAPG
102	CDZFD	137	CSAPI
103	CFX	138	CSAPR
104	CFY	139	CSPHIB
105	CFZ	140	CSPSIB
106	CM 1	141	CSPSIR
107	CM 3	142	CSRDPPI
108	CM 4	143	CSRPG
109	CM 5	144	CSRPI
110	CM 6	145	CSRPR
111	CNPC	146	CSRT
112	CNS	147	CSRTI
113	CNVX	148	CSTD
114	CNVY	149	CSTDL
115	CNVZ	150	CSTHB

<u>SUBSCRIPT</u>	<u>SYMBOL</u>	<u>SUBSCRIPT</u>	<u>SYMBOL</u>
151	CSTHR	196	CYSD
152	CSTZ	197-207	CYT
153	CSWSTD	208	CYTD
154	CSWTDL	209	CYZ
155	CT	210	CZ
156	CTD	211	CZM
157	CTDAS	212	CZRD
158	CTDV	213	CZSD
159	CTHB	214-224	CZT
160	CTHBC	225	CZTD
161	CTHBCP	226	CZZ
162	CTHBM	227	DELAY
163	CTLRP	228	DONPRT
164	CTM	229	DT
165	CTR 1	230	DUM 1
166	CTRR	231	DUM 2
167	CTTG	232	DUM 3
168	CTW	233	DUM 4
169	CTX	234	DUM 5
170	CUDPHS	235	DUM 6
171	CUDPSS	236	DUM 7
172	CUDTHS	237	DUM 8
173	CWSTD	238	DUM 9
174	CWSTDL	239	DUM 10
175	CWTTPR	240	DUM 11
176	CX	241	DUM 12
177	CXM	242	DUM 13
178	CXRD	243	DUM 14
179	CXSD	244	DUM 15
180-190	CXT	245	DUM 16
191	CXTD	246	DUM 17
192	CXZ	247	DUM 18
193	CY	248	FIN
194	CYM	249	FP
195	CYRD	250	FXP

<u>SUBSCRIPT</u>	<u>SYMBOL</u>	<u>SUBSCRIPT</u>	<u>SYMBOL</u>
251	FXPP	286	LDI13
252	FYP	287	LDI20
253	FYPP	288	LDI21
254	FZP	289	LDI22
255	FZPP	290	LDI25
256	GC	291	LDI26
257	IC	292	LDI31
258	IEXIT	293	LDO01
259	IOLP	294	LDO05
260	IWRITE	295	LDO11
261	K2C	296	LDO12
262	KC	297	LDO13
263	KWRITE	298	LDO62
264	L	299	LDO63
265	LC1	300	LFDI
266	LC1J	301	LQT
267	LC2	302	M
268	LC3	303	N
269	LC4A	304	PHIB
270	LC4B	305	PINT
271	LC4C	306	PSIB
272	LC4D	307	RDGD
273	LC4E	308	RRDREF
274	LC4F	309	SRAA
275	LC4G	310	SREA
276	LC5	311	SW
277	LC7	312	TEST
278	LC8	313	TFTXV
279	LC10	314	TFTYV
280	LCA	315	TFTZV
281	LCS	316	THETAB
282	LCY	317	TIME
283	LDI00	318	TPC
284	LDI10	319	TRI
285	LDI11	320	TSC

<u>SUBSCRIPT</u>	<u>SYMBOL</u>
321	TVX
322	TVY
323	TVZ
324	TYC
325	XGRT
326	XGRTD
327	XKRDR
328	YGRT
329	YGRTD
330	ZGRT
331	ZGRTD

TABLE 5

INPUTS NECESSARY FOR PLOTTING
(Type 4 Data)

Card 1

<u>COLUMN</u>	<u>QUANTITY AND/OR DESCRIPTION</u>
1- 2	Limit (number of quantities to be written out for plotting).
3-48	Blank.
49-54	*Symbolic name of first quantity to be written out.
55	Blank.
56-58	*Subscript of first quantity to be written out.
59-60	Blank.
61-66	*Symbolic name of second quantity to be written out.
67	Blank.
68-70	*Subscript of second quantity to be written out.
71-72	Blank.

If more than two quantities are desired, data cards of the following format must be read in. For each card after the first, a maximum of six quantities per card is allowed. The quantities are specified using the following format:

<u>COLUMN</u>	<u>QUANTITY AND/OR DESCRIPTION</u>
1- 6	*Symbolic name of third quantity.
7	Blank.
8-10	*Subscript of third quantity.
11-12	Blank.
13-18	*Symbolic name of fourth quantity.
19	Blank.
20-22	*Subscript of fourth quantity.
23-24	Blank.

This format is continued for the remainder of the second card and as many more cards as are necessary to generate the desired plot data.

* Note, the names of the quantities and the associated subscripts are listed in Table 4.

TABLE 6

DEFINITION OF TERMS USED ON DETAIL DYNAMIC ENVIRONMENT FLOW DIAGRAM

BINT	Time interval of reverse integration.
CATXBA CATXFW CATYB CATZB	See Table 3, Card 6.
CFX CFY CFZ	See Table 1.
CO	Base time for printout.
COINT	Number of simulated seconds per two-page printout.
CRLO	RLO. (See Table 1).
CT	See Table 1.
CTDV	$T \Delta V$. (See Table 1).
CTRLI	7090 Control Program.
CTTG	Variable which controls thrusting for Catch-Up. = 0 Thrust to drive IVI to zero. ≠ 0 Don't thrust.
CTX	T_X . (See Table 1).
DELAY	Time shift of printout time.
DONPRT	Quantity used to control output for an operational simulation.
DREA DRAA DROLL	Attitude errors from radar line-of-sight orientation.

TABLE 6
(continued)

DTT	Time step used in integration scheme.
EOP	Time to terminate problem.
ESPR	Maximum radar range to initiate printout each computer cycle.
FIN	See note at the end of this table.
ICC	Subscript for selecting proper ITH thrust indicator.
IEXIT	See Table 3, Card 14.
ILIST (IPL)	Subscript of the simulated data inserts (Type 3 data).
INITIAL } INPASS }	Equal to zero for first pass through program. Non-zero thereafter.
IOLP	One line of output each cycle if IOLP \neq 0.
IPL	Counter used for Type 3 data inputs.
ITH (ICC)	One of the ITH thrust indicators dependent upon the value of ICC. See Table 3, Card 13.
IWRITE	= 0 No effect. \neq 0 Two pages of output every cycle.
JUMP	Used to aid in determining which thrust is being simulated.
KEY 14	Will generate two pages of output every computation cycle when depressed.
KEY 15	Over-ride key for on-line printing. Will cause one line to be printed on-line every computer cycle whenever pressed down.
KEY 16	Will cause the run to be terminated when pressed down.
KEY 17	Start Computation button. If KEY 17 is not used, start computation (LDI 21) will be set automatically when T = STCT.

TABLE 6
(continued)

KEY 19

Indicates desire for on-line output. When KEY 19 is down, one line will be printed on-line every computer cycle if one of the following conditions is true:

1. T is not greater than 10.
2. The START COMP light is ON, CTTG = 0, FIN = 0 and at least one of the following is true:
 $\Delta V_X \neq 0, \Delta V_Y \neq 0, \Delta V_Z \neq 0.$
3. Radar range is less than the value of ESPR.

KEY 20

Will cause two pages of off-line output to be produced at intervals determined by COINT when pressed down.

KEYSET

See Table 3, Card 15.

KOMBO

Variable set equal to octal contents of MQ key. Must equal KEYSET before program will be executed.

KPLOT

Counter used in plotting routine.

LC 2

See Table 1.

LDB

See Table 3, Card 14.

LDI 00

Discrete input which signals radar ready (-) or not ready (+) with valid data for the computer.

LDI 10
LDI 11
LDI 13 }

Discrete inputs which indicate which computer mode has been selected.

LDI 21

Discrete input which indicates that the START COMP button has (-) or has not (+) been pushed.

LDI 25
LDI 26
LDI 31 }

Discrete inputs which indicate a zero (+) or non-zero (-) reading on the ΔV_Y , ΔV_Z , and ΔV_X meters respectively.

LDO 05

Discrete output used to turn the Computer Running (START COMP) Light on (-) or off (+).

TABLE 6
(continued)

LDO 11	Discrete output used to drive the ΔV meters to zero when set (-).
LDO 12 } LDO 13 }	Discrete outputs used to select one of the ΔV meters.
LDO 62	Discrete output used to reset the START COMP discrete to ignore the pushing of the START COMP button if sufficient time for the gathering of data has not elapsed.
LFDI } LFP } LGANG }	See Table 3, Card 14.
LIMIT	Number of quantities to be written out for plotting.
LMDI } LOC } LRM } LRR } LSRA }	See Table 3, Cards 13 and 14.
LQT	= 0 No effect. ≠ 0 Sets LDI 00 (+) indicating that the radar is not ready with valid data for the computer.
LRDFDI	- Control the spacecraft to hold radar line-of-sight to the target. + Control of the spacecraft to the attitude commanded by the Gemini computer.
MM	Control variable used in the attitude integration loop.
MACINT } MACNTR } MACOP } MODCR }	See Table 3, Card 13.
MUD 5	Control variable used to select one of two formats for on-line output.

TABLE 6
(continued)

RAA	Radar azimuth angle.
REA	Radar elevation angle.
STCT	Start computation time.
T	Environment time.
TEST	See note at end of this table.
T_E	Elapsed time from lift-off.
T_M	See CTM in Table 1.
TRI	Radar range.
TRIDOT	Radar range rate.
TSC	Time at which START COMP was pressed.
Δv_x Δv_y Δv_z	IVI readings.
w_{xv} w_{yv} w_{zv}	Turning rates about body axes.
XLIMIT	Maximum acceptable spacecraft turning rate.
$W_T^t PR$	See CWTTPR in Table 1.
ϕ_b	See CPHIB in Table 1.
Q_b	See CTHB in Table 1.
ψ_b	See CPSIB in Table 1.

TABLE 6
(continued)

$\Delta\phi_{SC}$

See CDPHSC in Table 1.

$\Delta\theta_{SC}$

See CDTHSC in Table 1.

$\Delta\psi_{SC}$


See CDPSSC in Table 1.

ψ_{bc}

See CPSIBC in Table 1.

NOTE:

These quantities are used only in Module III.



5	6	3	2	1
REVISIONS				
SYNTHESIS NOTICE		DESCRIPTION		DATE
				CHE APPROVED
RELEASE				

52

96
BITAL
ARGET
CRAFT

>
0

995
REVERSE
IN FOR BOTH
ID SPACECRAFT

990
QUATIONS OF
RGET AND
ER ONE TIME STEP

992
+
989
REVERSE INTEGRATION → A3

RETARGET SPACECRAFT
OF RENDEZVOUS PROBLEM

+
/

IZATION PROCESS

+
PRELAUNCH
TCH-UP
555

101
MOTION
CRAFT
EP

52
COMPUTE THRUST COMPONENTS
IN NAVIGATION COORDINATES

71
COMPUTE TOTAL AVAPPLIED
IN SPACECRAFT COORDINATES

72
COMPUTE SPACECRAFT
ORBITAL PARAMETERS

COMPUTE INERTIAL TO
NAVIGATION COORDINATE
TRANSFORMATION MATRIX

COMPUTE NAVIGATION TO BODY
COORDINATE TRANSFORMATION MATRIX

COMPUTE PLATFORM
GIMBAL ANGLES θ_b, θ_d

15NO 15
601 COMPUTE ψ_b USING
 $\cos \theta_b$ → 602
COMPUTE ψ_b USING
 $\sin \theta_b$

-0 15NO 15
603
551 TURN ON COMPUTER
RUNNING LIGHT
(SENSE LIGHT 4)

552 TURN OFF COMPUTER
RUNNING LIGHT
(SENSE LIGHT 4)

- LDI 21
428 DOWN → 427
KEY 17
UP
7300
TSTC
I/O
LDI 21-
(2047)
TSC-T
LDI 22-
(4095)
TSC-T

556
TO 114

LIST OF MATERIAL OR PARTS LIST

ITEM NO.	DESCRIPTION	PART OR IDENTIFYING NO.	SPECIFICATION	MATERIAL OR NOTES	SIZE	TECH
INTERNATIONAL BUSINESS MACHINES CORP. FEDERAL SYSTEMS DIVISION 500 MADISON AVE., NEW YORK, N.Y.						
TITLE: ENVIRONMENTAL SYSTEM FOR GEMINI RENDEZVOUS						
03640	F	65-554-0032				
SCALE NONE	WT	SHEET 1 OF 3				

LIST OF MATERIAL OR PARTS LIST

ITEM NO.	DESCRIPTION	PART OR IDENTIFYING NO.	SPECIFICATION	MATERIAL OR NOTES	SIZE	TECH
INTERNATIONAL BUSINESS MACHINES CORP. FEDERAL SYSTEMS DIVISION 500 MADISON AVE., NEW YORK, N.Y.						
TITLE: ENVIRONMENTAL SYSTEM FOR GEMINI RENDEZVOUS						
03640	F	65-554-0032				
SCALE NONE	WT	SHEET 1 OF 3				

ONLY THE ITEM(S) LISTED ON THIS DRAWING ARE IDENTIFIED BY ITEM NUMBER, NAME, AND PART NUMBER(S). ALL OTHER PARTS AND TOLERANCES ARE FOR INFORMATION ONLY TO THIS DRAWING.

ITEM(S) LISTED ON THIS DRAWING HAVE BEEN TESTED AND APPROVED BY IBM FOR USE IN ().



ITEM(S) LISTED ON THIS DRAWING SHALL NOT BE REPRODUCED WITHOUT PRIOR APPROVAL FROM IBM.

TESTING AND APPROVAL


COMMERCIAL SOURCE PART
BE EQUAL TO AND COMPETE
INTERCHANGEABLE WITH (SEE SOURCE OF SUPPLY)

SPEC NUMBER **NAME** **ITEM NO.** **APPLIES TO**

REPPLICABLE IBM SPEC **CHECK BLOCK** **IF APPLICABLE**



REV	CHG NOTICE	DESCRIPTION	DATE	ENCL	APPENDIX
RELEASE					



REFERENCE DRAWING

QTY REQD	INV. NO.	REINFORCEMENT OR DESIGNATION ON DRAWING	PART OR IDENTIFICATION NO.	SPECIFICATION	MATERIAL OR NOTES	CIRC. SHEET NUMBER OR NO.
LIST OF MATERIAL OR PARTS LIST						
INTERNATIONAL BUSINESS MACHINES CORP. <small>FEDERAL SYSTEMS DIVISION</small> <small>599 MADISON AVE.</small> <small>NEW YORK, N.Y.</small> ENVIRONMENTAL SYSTEM FOR GEMINI RENDEZVOUS						
ITEM NO. OF SVN: V-VENDOR CODE SEE SPEC OR SOURCE LIST ONE REF QTY	DESIGNED <i>J. Reiner</i>	DATE <i>10/10/68</i>				
ALL DIMENSIONS AND TOLERANCES ARE IN INCHES UNLESS OTHERWISE SPECIFIED TOLERANCE ON DECIMALS ANGLES	DRAWN BY <i>J. Reiner</i>	REVISIONS <i>1</i>				
PRINTED MATERIAL	BRAKING CHECK <i>J. Reiner</i>	REVIEWED <i>J. Reiner</i>				
CONTRACT NO.	DESIGN APPROVAL <i>E.H. Wink</i>	APPROVED <i>E.H. Wink</i>				
SPEC NUMBER	CODE IDENT. NO.	SIZE	DRAWING NO.			
APPLICABLE IBM SPEC	03640	F	65-554-0032			
ITEM NO.	CHECK BLOCK	IF APPLICABLE				
APPLICABLE IBM SPEC						

<input type="checkbox"/> ONLY THE ITEM(S) LISTED ON THIS DRAWING AND IDENTIFIED BY VENDOR NUMBER, ITEM NUMBER, AND PART NUMBER ARE TO BE PURCHASED TESTED AND APPROVED BY IBM FOR USE IN 1. ALL SUBSTITUTE ITEM SHALL NOT BE APPROVED PRIOR TO TESTING AND APPROVAL BY IBM	
<input type="checkbox"/> COMMERCIAL PRODUCT MAY BE USED TO AND IS COMPATIBLE WITH (SEE SOURCE OF SUPPLY)	
SPEC NUMBER	ITEM NO.
APPLICABLE IBM SPEC	APPLICABLE IBM SPEC
APPLICABLE IBM SPEC	APPLICABLE IBM SPEC

5
14
13
12
11
10
9
8
7
6
5
4
3
2
1

767
E POSITION OF
CURVILINEAR
COORDINATES

920
RADAR DATA
BAL ANGLES

P
=0

N6
=0

R
=0
400

402
=0

M
=0

423

0+

97
424

408

RL1

214


426


Z-

L ANGLES
DATA



159

STO 120





SPEC NUMBER	ITEM NO.	APPLIES TO	CONTACT NO.	BOMENCLATURE OR DESCRIPTION		PART NO IDENTIFYING NO.	SPECIFICATION	MATERIAL OR NOTES	DRAWING SHEET NO.
				QTY	SIZE				
LIST OF MATERIAL OR PARTS LIST									
<p><input type="checkbox"/> ONLY THE ITEM(S) LISTED ON THIS DRAWING ARE IDENTIFIED BY VENDOR NAME(S), ADDRESS(Es), AND PART NUMBER(S). ALL OTHER ITEMS ARE APPROVED BY IBM FOR USE IN THIS SYSTEM.</p> <p><input type="checkbox"/> ALL SUBSTITUTE ITEM SHALL NOT BE USED WITHOUT PRIOR TESTING AND APPROVAL BY IBM.</p> <p><input type="checkbox"/> COMMERCIAL PRODUCT WHICH IS EQUAL TO AND COMPLETELY INTERCHANGEABLE WITH (SEE SOURCE OF SUPPLY).</p>				<p>DESIGNED <i>J. Klemmer</i></p> <p>DATE</p> <p>REDESIGN CHECK <i>[Signature]</i></p> <p>ALL DIMENSIONS AND TOLERANCES APPLY TO FINISHED PART</p> <p>ALL DIMENSIONS ARE IN INCHES. TOLERANCE G.O. 2 PLACES DECIMALS 3 PLACES ANGLES</p> <p>DETAILED DRAWINGS ARE IN SEPARATE SHEETS</p> <p>DETAILED DRAWINGS ARE IN SEPARATE SHEETS</p>		<p>INTERNATIONAL BUSINESS MACHINES CORP. FEDERAL SYSTEMS DIVISION 550 MADISON AVE. NEW YORK, N.Y.</p> <p>TITLE ENVIRONMENTAL SYSTEM FOR GEMINI RENDEZVOUS</p>			
				<p>DESIGNED <i>LIG</i></p> <p>DATE <i>1/65</i></p> <p>BORING CHECK <i>J. Palmer</i></p> <p>DETAILED DRAWINGS ARE IN SEPARATE SHEETS</p>		<p>CODE IDENT NO. SIZE DRAWING NO.</p> <p>03640 F 65-554-0032</p> <p>SCALE NONE WT SHEET 3</p>			
<p>APPLICABLE IBM SPEC</p>				<p>CHECK BLOCK <input checked="" type="checkbox"/> IF APPLICABLE</p>					




- 55 -

REVISORS		DESCRIPTION	BATCH	CHART	REVISION
STN	CHG/NOTICE				
	RELEASE				


42

>





I

>




IS

5


D EULER
ITION(MAR)PUTE MATRIX
THOGONALITY

QTY REQD	SPN NO.	DESIGNATION OR DESCRIPTION	PART NO. IDENTIFICATION NO.	SPECIFICATION	MATERIAL OR NOTES	DRW NO.	TYPE NO.
LIST OF MATERIAL OR PARTS LIST							
UNLESS NOTED BREAK CORNERS OUTSIDE DRAWING RIN							
ALL DIMENSIONS AND TOLERANCES APPLY TO FINISHED PART							
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES AND TOLERANCES IN THOUSANDS OF AN INCHES 2 PLACE DECIMALS DEGREES ANGLES							
DRAWN BY LTS							
DRAWING CHECK F. Lerner							
APPROVED Z. H. Metz							
CODE AGENT NO. DATE 03640 F 65-554-0032							
SCALE NONE WT SHEET SHEET 4							



-56-

REVISIONS	
REV. NUMBER	DESCRIPTION
	RELEASE



REFERENCE DRAWING

QTY REQD	SYS. SOL.	DISCUSSION OR DESCRIPTION	PART OR IDENTIFYING NO.	SPECIFICATION	MATERIAL OR NOTES	SHIPS ITEM NO.
LIST OF MATERIAL OR PARTS LIST						
UNLESS NOTED BREAK CORNERS OUTSIDE MIN MAX INSIDE MIN MAX ALL DIMENSIONS AND TOLERANCES APPLY TO FINISHED PART DESIGNER: <i>J. Reiter</i> DESIGN CHECKED: <i>J. Reiter</i> DRAWN: <i>LIG</i> DRAWING CHECKED: <i>J. Reiter</i> DESIGN APPROVAL: <i>E.H. Hartley</i>		DATE: <i>10/10/65</i> INTERNATIONAL BUSINESS MACHINES CORP. FEDERAL SYSTEMS DIVISION 500 MADISON AVE., NEW YORK 22, N.Y. TITLE: ENVIRONMENTAL SYSTEM FOR GEMINI RENDEZVOUS CODE AGENT NO.: 03640 F DATE: 65-554-0032 SCALE: NONE WT: SHEET 5				
UNLESS NOTED BREAK CORNERS OUTSIDE MIN MAX INSIDE MIN MAX ALL DIMENSIONS AND TOLERANCES APPLY TO FINISHED PART DESIGNER: <i>J. Reiter</i> DESIGN CHECKED: <i>J. Reiter</i> DRAWN: <i>LIG</i> DRAWING CHECKED: <i>J. Reiter</i> DESIGN APPROVAL: <i>E.H. Hartley</i>						
UNLESS NOTED BREAK CORNERS OUTSIDE MIN MAX INSIDE MIN MAX ALL DIMENSIONS AND TOLERANCES APPLY TO FINISHED PART DESIGNER: <i>J. Reiter</i> DESIGN CHECKED: <i>J. Reiter</i> DRAWN: <i>LIG</i> DRAWING CHECKED: <i>J. Reiter</i> DESIGN APPROVAL: <i>E.H. Hartley</i>						

APPENDIX A

**Listings of the FORTRAN/ FAP programs
comprising the Catch-Up and Rendezvous Dynamic and
Static Simulation Programs.**

```

DIMENSION CXT(11),CYT(11),CZT(11),CDTWT(11),VLIST(1),DLIST(100),
*ILIST(100),SLIST(100),TLIST(100)
DIMENSION REM(165),ITH(10),SC(14),TARG(14),TABLE1(50,20),
*PSLST(50),IPLST(50),RKK(50)
COMMON CDVXSP,CDVYSP,CDVZSP,CDPHSC,CDPSSC,CDTHSC,AKX1 ,AKX2 ,
1AKX3 ,AKX4 ,AKY1 ,AKY2 ,AKY3 ,AKY4 ,AKZ1 ,AKZ2 ,AKZ3 ,
2AKZ4 ,ASFX ,ASFY ,ASFZ ,CO ,COI ,C2 ,C2I ,CA11 ,
3CA12 ,CA13 ,CA21 ,CA22 ,CA23 ,CA31 ,CA32 ,CA33 ,CAPT ,
4CAPTI ,CATXBA,CATXBI,CCAB ,CCABI ,CCAS ,CCASI ,CCK1 ,CCK2 ,
5CCK3 ,CCK4 ,CCK5 ,CCKF ,CCKG ,CCPHIB,CCPSIB,CCPSIR,CCR ,
6CCRB ,CCRB1 ,CCRI ,CCRS ,CCRSI ,CCTHB ,CCTHR ,CCWSTD,CCWTDL,
7CCZT ,CDEL ,CDRRD ,CDTM ,CDTW ,CDTWT ,CDTX ,CDV ,
8CDVF ,CDVI ,CDVT ,CDVXB ,CDVXM ,CDVXS ,CDVXZ ,CDVYB ,CDVYM ,
9CDVYS ,CDVYZ ,CDVZB ,CDVZM ,CDVZS ,CDVZZ ,CDXD ,CDXF D ,CDYD
COMMON CDYFD ,CDZD ,CDZFD ,CFX ,CFY ,CFZ ,CM1 ,CM3 ,
1CM4 ,CM5 ,CM6 ,CNPC ,CNS ,CNVX ,CNVY ,CNVZ ,CNYC ,
2COEFF ,COINT ,COMGS ,CPHIB ,CPHIBC,CPSBCP,CPSIB ,CPSIBC,CPSIBM,
3CR1 ,CRA ,CRLO ,CRR ,CRRD ,CRRG ,CRRI ,CRRPI ,CRS ,
4CSADPI ,CSAPG ,CSAPI ,CSAPR ,CSPHIB,CSPSIB,CSPSIR,CSRDP I,CSRPG ,
5CSRPI ,CSRPR ,CSRT ,CSRTI ,CSTD ,CSTD L ,CSTHB ,CSTHR ,CSTZ ,
6CSWSTD,CSWTDL,CT ,CTD ,CTDAS ,CTDV ,CTHB ,CTHBC ,CTHBCP,
7CTHBM ,CTLRP ,CTM ,CTR1 ,CTR2 ,CTTG ,CTW ,CTX ,CUDPHS,
8CUDPSS,CUDTHS,CWSTD ,CWSTD L ,CWTPR,CX ,CX M ,CXRD ,CXSD ,
9CXT ,CXTD ,CXZ ,CY ,CYM ,CYRD ,CYSD ,CYT ,CYTD
COMMON CYZ ,CZ ,CZM ,CZRD ,CZSD ,CZT ,CZTD ,CZZ ,
1DELAY ,DONPRT,DT ,DUM1 ,DUM2 ,DUM3 ,DUM4 ,DUM5 ,DUM6 ,
2DUM7 ,DUM8 ,DUM9 ,DUM10 ,DUM11 ,DUM12 ,DUM13 ,DUM14 ,DUM15 ,
3DUM16 ,DUM17 ,DUM18 ,FIN ,FP ,FXPA ,FXPP ,FYP ,FYPP ,
4FZP ,FZPP ,GC ,IC ,IEXIT ,IOLP ,IWRITE,K2C ,KC ,
5KWRITE,L ,LC1 ,LC1J ,LC2 ,LC3 ,LC4A ,LC4B ,LC4C ,
6LC4D ,LC4E ,LC4F ,LC4G ,LC5 ,LC7 ,LC8 ,LC10 ,LCA ,
7LCS ,LCY ,LDI00 ,LDI10 ,LDI11 ,LDI13 ,LDI20 ,LDI21 ,LDI22 ,
8LDI25 ,LDI26 ,LDI31 ,LD001 ,LD005 ,LD011 ,LD012 ,LD013 ,LD062 ,
9LD063 ,LFDI ,LQT ,M ,N ,PHIB ,PINT ,PSIB ,RDGD
COMMON RRDREF,SRAA ,SREA ,SW ,TEST ,TFTXV ,FTYV ,FTZV ,
1THETAB,TIME ,TPC ,TRI ,TSC ,TVX ,TVY ,TVZ ,TYC ,
2XGRT ,XGR TD ,XKRDR ,YGR TD ,YGR TD ,ZGR TD ,ZGR TD
EQUIVALENCE (DELVX,CDVXSP),(DELVY,CDVYSP),(DELVZ,CDVZSP),(CDPHSC,
*DPHIB),(CDPSSC,DPSIB),(CDTHSC,DTHB),(VLIST,CDVXSP)
EQUIVALENCE (XI ,SC( 1)),(YI ,SC( 2)),(ZI ,SC( 3)),
1(TI ,SC( 4)),(DXI ,SC( 5)),(DYI ,SC( 6)),(DZI ,SC( 7)),
2(SCVM,SC( 8)),(RJJ ,SC( 9)),(DTT ,SC(10)),(Q37 ,SC(11)),
3(Q38 ,SC(12)),(Q39 ,SC(13))
EQUIVALENCE (XTI ,TARG( 1)),(YTI ,TARG( 2)),(ZTI ,TARG( 3)),
1(TTI ,TARG( 4)),(DXTI ,TARG( 5)),(DYTI ,TARG( 6)),(DZTI ,TARG( 7)),
2(TVM ,TARG( 8)),(RJJ ,TARG( 9)),(DTTP,TARG(10))
EQUIVALENCE (A11 ,RKK(50)),(A12 ,RKK(49)),(A13 ,RKK(48)),
1(A21 ,RKK(47)),(A22 ,RKK(46)),(A23 ,RKK(45)),(A31 ,RKK(44)),
2(A32 ,RKK(43)),(A33 ,RKK(42)),(DA11,RKK(41)),(DA12,RKK(40)),
3(DA13,RKK(39)),(DA21,RKK(38)),(DA22,RKK(37)),(DA23,RKK(36)),
4(DA31,RKK(35)),(DA32,RKK(34)),(DA33,RKK(33))
Z1=CLOCKF(XX)
CALL HDA7
CALL SELFLD
KT1= 5

```

```

KT2= 9
KT3=14
CALL LDB6
READ INPUT TAPE KT1,1032,(REM(I),I=1,165)
330 ZZ2=CLOCKF(XX)
DO 331 I= 1, 20
DO 331 J=1,50
331 TABLE1(J,I)=0.
DO 332 I= 1, 50
332 RKK(I)=0.
DO 333 I= 1,14
SC(I)=0.
333 TARG(I)=0.
DO 334 I= 1,331
334 VLIST(I)=0.
READ INPUT TAPE KT1,1010,NDATE1,NDATE2,NDATE3,NRUN1,NRUN2
READ INPUT TAPE KT1,1002, EOP ,STCT ,CTZ ,CTE ,COINT ,
1DELAY ,ESPR ,DT ,BINT ,CAPT ,COMGT ,CSRT ,XI ,YI ,
2ZI ,DXI ,DYI ,DZI ,XTI ,YTI ,ZTI ,DXTI ,DYTI ,
3DZTI ,RJ ,CATXBA,CATXFW,CATYB ,CATZB ,XKRDR ,CCAB ,CCAS ,
4CCRB ,CCRS ,CO ,C2 ,A11 ,A12 ,A13 ,A21 ,A22 ,
5A23 ,A31 ,A32 ,A33 ,AKX1 ,AKX2 ,AKX3 ,AKX4 ,AKY1 ,
6AKY2 ,AKY3 ,AKY4 ,AKZ1 ,AKZ2 ,AKZ3 ,AKZ4 ,XKP1 ,XKP2 ,
7XKP3 ,XKR ,XKY ,CCR
READ INPUT TAPE KT1,1001,(ITH(I),I=1,10) ,MACOP ,MACNTR,MACINT,
1MODCR ,NPF ,LOC ,LMDI
READ INPUT TAPE KT1,1012, LFP ,LGANG ,LRR ,LSRA
1LRM ,LDB ,LFDI ,IEXIT
READ INPUT TAPE KT1,1005,KEYSET
57 CALL KEYCN (KOMBO)
IF (KEYSET-KOMBO) 58,59,58
58 PRINT 1017,KEYSET
PAUSE
GO TO 57
59 WRITE OUTPUT TAPE KT2,1037, EOP ,STCT ,CTZ ,CTE ,COINT ,
1DELAY ,ESPR ,DT ,BINT ,CAPT ,COMGT ,CSRT ,XI ,YI ,
2ZI ,DXI ,DYI ,DZI ,XTI ,YTI ,ZTI ,DXTI ,DYTI ,
3DZTI ,RJ ,CATXBA,CATXFW,CATYB ,CATZB ,XKRDR ,
WRITE OUTPUT TAPE KT2,1038, CCAB ,CCAS ,CCRB ,CCRS ,CO ,
1C2 ,A11 ,A12 ,A13 ,A21 ,A22 ,A23 ,A31 ,A32 ,
2A33 ,AKX1 ,AKX2 ,AKX3 ,AKX4 ,AKY1 ,AKY2 ,AKY3 ,AKY4 ,
3AKZ1 ,AKZ2 ,AKZ3 ,AKZ4 ,XKP1 ,XKP2 ,XKP3
WRITE OUTPUT TAPE KT2,1039, XKR ,XKY ,CCR
WRITE OUTPUT TAPE KT2,1040,(ITH(I),I=1,10) ,MACOP ,MACNTR,MACINT,
1MODCR ,NPF ,LOC ,LMDI ,LFP ,LGANG ,LRR ,LSRA ,LRM
2LDB ,LFDI ,IEXIT
WRITE OUTPUT TAPE KT2,1011,NDATE1,NDATE2,NDATE3,NRUN1,NRUN2
PRINT 1013,NDATE1,NDATE2,NDATE3,NRUN1,NRUN2
IF ((LMDI) 115,125,115
115 IPL=0
108 IPL=IPL+1
IF (IPL-100) 116,116,109
116 READ INPUT TAPE KT1,1050,SLIST(IPL),TLIST(IPL),DLIST(IPL),ILIST(IP
*L)
IF (ILIST(IPL)) 108,109,108
109 JK=IPL

```

```

        WRITE OUTPUT TAPE KT2,1051
DO 113 I=1,JK
113 WRITE OUTPUT TAPE KT2,1052,SLIST(I),TLIST(I),DLIST(I),ILIST(I)
125 IF (LOC) 252,94,252
252 READ INPUT TAPE KT1,1014,LIMIT,(PSLST(LPL),IPLST(LPL),LPL=1,2)
IF (LIMIT-2) 903,903,251
251 READ INPUT TAPE KT1,1015,(PSLST(LPL),IPLST(LPL),LPL=3,LIMIT)
903 WRITE OUTPUT TAPE KT2,1016,(PSLST(LPL),IPLST(LPL),LPL=1,LIMIT)
CALL HDA9
94 IF(MACOP) 95,96,95
95 RT= ZTI
RAD=.01745329
THT=XTI*RAD
PHT=YTI*RAD
GAT=DXTI*RAD
PST=DYTI*RAD
CTHT=COSF(THT)
STHT=SINF(THT)
CPHT=COSF(PHT)
SPHT=SINF(PHT)
XTI=RT*CTHT*CPHT
YTI=RT*STHT*CPHT
ZTI=RT*SPHT
CGAT=COSF(GAT)
SGAT=SINF(GAT)
CPST=COSF(PST)
SPST=SINF(PST)
DXTI=DZTI*(CTHT*(CPHT*SGAT-SPHT*CPST*CGAT)-STHT*SPST*CGAT)
DYTI=DZTI*(STHT*(CPHT*SGAT-SPHT*CPST*CGAT)+CTHT*SPST*CGAT)
DZTI=DZTI*(SPHT*SGAT+CPHT*CPST*CGAT)
RDT=(XTI*DXTI+YTI*DYTI+ZTI*DZTI)/RT
IF(MACNTR)98,97,98
98 RF=YI+RT
AZTF=ATN1F(ZI,RT)
AXTF=XI/RT
SINX=SINF(AXTF)
COSX=COSF(AXTF)
SINZ=SINF(AZTF)
COSZ=COSF(AZTF)
PHX=ARSINF(COSX*SPHT-SINX*CPHT*CPST)
SPHX=SINF(PHX)
CPHX=COSF(PHX)
DTHX=ARSINF(SINX*SPST/CPHX)
THX=THT-DTHX
PSX1=COSF(DTHX)*CPST
PSX2=SINF(DTHX)*SPST*SPHT
IF(XI) 28,28,29
29 PSX=ARCOSF(PSX1+PSX2)
GO TO 30
28 PSX=ARCOSF(-PSX1+PSX2)
30 PHF=ARSINF(COSZ*SPHX+SINZ*CPHX*SINF(PSX))
DTHF=ARSINF(SINZ*COSF(PSX)/COSF(PHF))
THF=THX-DTHF
U233=PHF/RAD
U234=THF/RAD
ZI=RF*SINF(PHF)

```

```

XI=RF*COSF(PHF)*COSF(THF)
YI=RF*COSF(PHF)*SINF(THF)
SF=VTI*DZTI-ZTI*DVTI
SG=ZTI*DXTI-XTI*DZTI
SH=XTI*DVTI-VTI*DXTI
SJ=SQRTF(SF**2+SG**2+SH**2)
HT=SJ/RT
BOB1=ZTI*SG-VTI*SH
BOB2=XTI*SH-ZTI*SF
BOB3=VTI*SF-XTI*SG
BOBL= SQRTF(BOB1**2+BOB2**2+BOB3**2)
P= BOB3*YI-BOB2*ZI
Q= BOB1*ZI-BOB3*XI
S= BOB2*XI-BOB1*YI
BIGD=2.E-8*(-SJ*RF**2/RT)*(DXI-RDT*AXTF-HT)
BIGE=2.E-8*RF*(DYI+RDT)
BIGF=2.E-8*RF*BOBL*DZI
BIGA=2.E-8*SG*ZI-2.E-8*SH*YI
BIGB=2.E-8*SH*XI-2.E-8*SF*ZI
BIGC=2.E-8*SF*YI-2.E-8*SG*XI
DEL= BIGA*YI*(4.E-16*S) + BIGB*ZI*(4.E-16*P) + BIGC*XI*(4.E-16*Q)
* - BIGC*YI*(4.E-16*P) - BIGB*XI*(4.E-16*S) - BIGA*ZI*(4.E-16*Q)
C11= YI*(4.E-16*S) - ZI*(4.E-16*Q)
C21= BIGB*(2.E-8*S) - BIGC*(2.E-8*Q)
C22= BIGA*(2.E-8*S) - BIGC*(2.E-8*P)
C31= 2.E-8*(BIGB*ZI-BIGC*YI)
C12= XI*(4.E-16*S) - ZI*(4.E-16*P)
C32= 2.E-8*(BIGA*ZI-BIGC*XI)
C13= XI*(4.E-16*Q) - YI*(4.E-16*P)
C23= BIGA*(2.E-8*Q) - BIGB*(2.E-8*P)
C33= 2.E-8*(BIGA*YI-BIGB*XI)
DELD=BIGD/DEL
DELE=BIGE/DEL
DELF=BIGF/DEL
DZI=C13*DELD-C23*DELE+C33*DELF
DYI=-C12*DELD+C22*DELE-C32*DELF
DXI=C11*DELD-C21*DELE+C31*DELF
GO TO 96
97 CTHF=COSF(XI-*RAD)
STHF=SINF(XI-*RAD)
CPHF=COSF(YI-*RAD)
SPHF=SINF(YI-*RAD)
XI=ZI*CTHF+CPHF
YI=ZI*STHF+CPHF
ZI=ZI*SPHF
CGAF=COSF(DXI-*RAD)
SGAF=SINF(DXI-*RAD)
CPSF=COSF(DYI-*RAD)
SPSF=SINF(DYI-*RAD)
DXI=DZI+*(CTHF*(CPHF)+SGAF+SPHF*CPSF*CGAF)-STHF*SPSF*CGAF)
DYI=DZI+*(STHF*(CPHF+SGAF-SPHF*CPSF*CGAF)+CTHF*SPSF*CGAF)
DZI=DZI+*(SPHF+*SGAF+CPHF+*CPSF*CGAF)
96 TI=SQRTF(XI**2+YI**2+ZI**2)
TTI=SQRTF(XT**2+YT**2+ZT**2)
RJJ=RJ
IF ((MACINT) 995,996,995

```

995 DXI==DXI
DYI==DYI
DZI==DZI
DXTI==DXTI
DYTI==DYTI
DZTI==DZTI
DTT=10.*DT
DTTP=DTT
990 CALL STATE (SC)
CALL STATE (TARG)
T=T+DTT
992 IF (T-BINT) = 990,989,989
989 WRITE OUTPUT TAPE KT2,642,T,NDATE1,NDATE2,NDATE3,NRUN1,NRUN2
WRITE OUTPUT TAPE KT2,643,XI,YI,ZI
WRITE OUTPUT TAPE KT2,644,DXI,DYI,DZI
WRITE OUTPUT TAPE KT2,645,XTI,YTI,ZTI
WRITE OUTPUT TAPE KT2,644,DXTI,DYTI,DZTI
DXI==DXI
DYI==DYI
DZI==DZI
DXTI==DXTI
DYTI==DYTI
DZTI==DZTI
996 T=CTZ
KPLOT=0
MUD5=0
851 ZZ=CLOCKF(XX)
PRINT 1004
CO=CTZ
XLIMIT=.20
GC=1.407654E+16
RE=2.0925874E+07
ICC=1
JUMP=0
LDI22=0
MM=0
IPL=1
ITAG=0
INPASS=0
INITAL=0
TRIDOT=0.
553 IF (MODCR-1) 554,555,102
554 LDI10=0
LDI11=4095
LDI13=0
GO TO 102
555 LDI10=4095
LDI11=0
LDI13=4095
GO TO 102
101 DTT=DT
DTTP=DTT
CALL STATE (SC)
CALL STATE (TARG)
T=T+DTT
102 TIME =T

```

IF (ITH(ICC)) 71,72,71
71 DXPFO=P11*Q37+P21*Q38+P31*Q39
DYPFO=P12*Q37+P22*Q38+P32*Q39
DZPFO=P13*Q37+P23*Q38+P33*Q39
FXP=FXP+DXPFO*DT
FYP=FYP+DYPFO*DT
FZP=FZP+DZPFO*DT
FXP1=FXP
FYP1=FYP
FZP1=FZP
TFTXV=TFTXV+ABSF(FTXV)*DT
TFTYV=TFTYV+ABSF(FTYV)*DT
TFTZV=TFTZV+ABSF(FTZV)*DT
72 OMEGA=ATN1F((DZI*YI-DYI*ZI),(DZI*XI-DXI*ZI))
Q30=SINF(OMEGA)
Q31=COSF(OMEGA)
OIOTA=ARCOSF((DYI*XI-DXI*YI)/(TI*SCVM))
OMU=ARCOSF((XI*Q31+YI*Q30)/TI)
IF (ZI) 700,704,704
700 OMU=-OMU
704 Q32=SINF(OMU)
Q33=COSF(OMU)
Q34=SINF(OIOTA)
Q35=COSF(OIOTA)
P11=-Q32*Q31-Q33*Q30*Q35
P12=-Q33*Q31+Q32*Q30*Q35
P13=Q34*Q30
P21=Q33*Q31*Q35-Q32*Q30
P22=-Q33*Q30-Q32*Q31*Q35
P23=-Q31*Q34
P31=Q33*Q34
P32=-Q32*Q34
P33=Q35
PB11=A11*P11+A21*P21+A31*P31
PB12=A11*P12+A21*P22+A31*P32
PB13=A11*P13+A21*P23+A31*P33
PB21=A12*P11+A22*P21+A32*P31
PB22=A12*P12+A22*P22+A32*P32
PB23=A12*P13+A22*P23+A32*P33
PB31=A13*P11+A23*P21+A33*P31
PB32=A13*P12+A23*P22+A33*P32
PB33=A13*P13+A23*P23+A33*P33
PHIB=ATN1F(PB33,-PB23)
THETAB=ATN1F(-PB12,PB11)
Q82=ABSF(SINF(PHIB))
IF(Q82-.4) 601,601,602
601 PSIB=ATN1F(-PB13,-PB23/COSF(PHIB))
GO TO 603
602 PSIB=ATN1F(-PB13,PB33/SINF(PHIB))
603 CONTINUE
IF (LD005) 551,552,551
551 SENSE LIGHT 4
GO TO 556
552 IF(SENSE LIGHT 4) 556,556
556 IF(LDI 21) 114,428,114
428 CALL KEYS (17,KEY17)

```

```

    IF (KEY17) 427,300,427
427 LDI21=2047
    TSC=T
    GO TO 114
300 IF (T-STCT) 114,110,110
110 LDI21=4095
    TSC=T
114 IF(LMDI) 104,111,104
104 IF(T-TLIST(IPL))111,105,105
105 K=ILIST(IPL)
    IF(LMDI) 107,106,106
106 VLIST(K)=DLIST(IPL)
    GO TO 117
107 CALL INSERT (ILIST(IPL),DLIST(IPL),SLIST(IPL))
117 IPL=IPL+1
118 IF(K=288) 104,119,104
119 IF(LDI21) 122,104,122
122 TSC=T
    GO TO 104
111 XRI=XTI-XI
    YRI=YTI-YI
    ZRI=ZTI-ZI
    TRI=SQRTF (XRI**2+YRI**2+ZRI**2)
126 IF(INPASS) 127,128,127
127 TRIDOT=(TRI-TRI1)/DT
128 TRI1=TRI
767 XRV=A11*XRI+A21*YRI+A31*ZRI
    YRV=A12*XRI+A22*YRI+A32*ZRI
    ZRV=A13*XRI+A23*YRI+A33*ZRI
    RAA=6.28318530-ATN1F(YRV,SQRTF(XRV**2+ZRV**2))
    IF (RAA=25./57.2957795) 761,761,762
762 IF (RAA=335./57.2957795) 763,761,761
761 SRAA=(SINF(RAA)-CCRB)/(1.+CCRS)
    REAPR=SQRTF(XRV**2+YRV**2)
    REA=ATN1F(ZRV,SIGNF(REAPR,XRV))
    IF (REA=25./57.2957795) 764,764,765
765 IF ((REA=335./57.2957795)) 763,764,764
764 SREA=(SINF(REA)-CCAB)/(1.+CCAS)
197 IF (ABSF(WXV )-.02618) 768,768,763
768 IF (ABSF(WYV )-.02618) 769,769,763
769 IF (ABSF(WZV )-.02618) 766,766,763
766 IF(LQT) 763,448,763
448 LDI00=4095
    GO TO 449
763 LDI00=0
449 IF(LFDI) 450,455,450
    450 IF(LDI21) 451,454,451
    451 IF(CTX-200.) 456,452,452
    452 IF(LD005) 453,456,453
    455 IF(CRLO) 450,456,450
    453 IF(LDI00) 454,456,454
    454 LRDFDI=4095
    GO TO 787
456 LRDFDI=0
787 RADTD=(XTI*DXTI+YTI*DVTI+ZTI*DZTI)/TTI
    GAMT=ARSINF(RADTD/TVM)

```

```

THET=ATN1F(YTI,XTI)
PHIT=ARSINF(ZTI/TTI)
PSIT=ATN1F((XTI*DYT1-YTI*DXT1),(TTI*DZTI-ZTI*RADTD))
STHET=SINF(THET)
CTHET=COSF(THET)
SPHIT=SINF(PHIT)
CPHIT=COSF(PHIT)
SPSIT=SINF(PSIT)
CPSIT=COSF(PSIT)
T11=STHET*SPSIT+CTHET*CPSIT*SPHIT
T12=CPHIT*CTHET
T13=STHET*CPSIT-CTHET*SPSIT*SPHIT
T21=-CTHET*SPSIT+STHET*CPSIT*SPHIT
T22=CPHIT*STHET
T23=-CTHET*CPSIT-STHET*SPSIT*SPHIT
T31=-CPHIT*CPSIT
T32=SPHIT
T33=CPHIT*SPSIT
XP=T11*XI+T21*YI+T31*ZI
YP=T12*XI+T22*YI+T32*ZI
ZP=T13*XI+T23*YI+T33*ZI
XPD=T11*DXI+T21*DYE+T31*DZI
YPD=T12*DXI+T22*DYE+T32*DZI
ZPD=T13*DXI+T23*DYE+T33*DZI
TEMP=ATN1F(XP,YP)
IF(TEMP=3.14159265) 772,772,771
771 TEMP=TEMP-6.28318530
772 XGRT=TTI *TEMP
TEMP2=XP**2+YP**2
TEMP1=SQRTF(TEMP2)
YGRD=TEMP1-TTI
ZGRD=ZP
CGAMT=COSF(GAMT)
XGRD=TTI *(YP*XPD-XP*YPD)/TEMP2+RADTD*TEMP+TVM *CGAMT
YGRD=-RADTD+(XP*XPD+YP*YPD)/TEMP1
ZGRD=ZPD
920 CONTINUE
PHIBS =PHIB
THBS =THETAB
PSIBS =PSIB
TRIS =TRI
SRAAS =SRAA
SREAS =SREA
IF(LFPI) 421,420,421
421 FXP =FXP +FXPSV
FYP =FYP +FYPSV
FZP =FZP +FZPSV
FXPS=FXP
FYPS=FYP
FZPS=FZP
CALL QUANT (FXP,.11)
CALL QUANT (FYP,.11)
CALL QUANT (FZP,.11)
FXPSP=FXP
FYPSP=FYP
FZPSP=FZP

```

FXPSV=FXPS-FXP
FYPSV=FYPS-FYP
FZPSV=FZPS-FZP
420 IF (LGANG) 401,400,401
401 CALL QUANT (PHIB ,.036/57.2957795)
CALL QUANT (THETAB ,.036/57.2957795)
CALL QUANT (PSIB ,.036/57.2957795)
400 IF (LRR) 403,402,403
403 CALL QUANT (TRI ,.49.178)
402 IF (LSRA) 405,422,405
405 CALL QUANT (SRAA ,.42594791*.1953125E-2)
407 CALL QUANT (SREA ,.42594791*.1953125E-2)
422 IF (LRM) 423,408,423
423 IF (TRI-1510797.) 408,424,424
424 TRI=1510797.
408 CALL CTRL1
640 CONTINUE
IF (LD062) 426,901,426
901 LDI21=0
426 LD062=4095
PHIB =PHIBS
THETAB=THBS
PSIB =PSIBS
TRI =TRIS
SRAA =SRAAS
SREA =SREAS
404 IF (LDB) 409,406,409
409 IF (ABSF(DPHIB)-3./57.2957795) 410,410,411
410 ARG2=.66666667E-1/57.2957795
GO TO 412
411 ARG2=.66666667E-1*6./57.2957795
412 CALL QUANT (DPHIB,ARG2)
IF (ABSF(DPSIB)-3./57.2957795) 413,413,415
413 ARG2=.66666667E-1/57.2957795
GO TO 416
415 ARG2=.66666667E-1*6./57.2957795
416 CALL QUANT (DPSIB,ARG2)
IF (ABSF(DTHB)-3./57.2957795) 417,417,418
417 ARG2=.66666667E-1/57.2957795
GO TO 419
418 ARG2=.66666667E-1*6./57.2957795
419 CALL QUANT (DTHB,ARG2)
406 IF (INPASS) 202,200,202
202 IF(IWRITE) 200,7001,200
7001 IF(T-CO-DELAY+1.) 201,7000,201
7000 DONPRT=4095.
201 IF(T-CO-DELAY) 121,641,641
121 IF (KEY 14) 414,120,414
120 IF (T-10.) 159,159,150
150 IF (LD0 05) 154,155,154
154 IF (CTTG) 155,157,155
157 IF (FIN) 155,151,155
151 IF (DELVX) 159,152,159
152 IF (DELVY) 159,153,159
153 IF (DELVZ) 159,155,159
155 IF (TRI- ESPR) 159,159,158

158 CALL KEYS (15,KEY15)
IF(KEY15) 112,156,112
159 CALL KEYS (19,KEY19)
IF(KEY19) 112,156,112
156 IF(LIOLP) 112,10006,112
641 CO=CO+COINT
200 CALL KEYS (20,KEY20)
IF (KEY20) 414,120,414
414 WRITE OUTPUT TAPE KT2,642,T,NDATE1,NDATE2,NDATE3,NRUN1,NRUN2
WRITE OUTPUT TAPE KT2,643,XI,YI,ZI
WRITE OUTPUT TAPE KT2,1007,XRV,YRV,ZRV
WRITE OUTPUT TAPE KT2,644,DXI,DYI,DZI
WRITE OUTPUT TAPE KT2,92,TTI
WRITE OUTPUT TAPE KT2,645,XTI,YTI,ZTI
WRITE OUTPUT TAPE KT2,644,DXTI,DYTI,DZTI
WRITE OUTPUT TAPE KT2,92,TTI
WRITE OUTPUT TAPE KT2,82,XGRT,YGRT,ZGRT
WRITE OUTPUT TAPE KT2,83,XGRTD,YGRTD,ZGRTD
WRITE OUTPUT TAPE KT2,15,A11,A12,A13
WRITE OUTPUT TAPE KT2,16,A21,A22,A23
WRITE OUTPUT TAPE KT2,16,A31,A32,A33
WRITE OUTPUT TAPE KT2,19,T11,T12,T13
WRITE OUTPUT TAPE KT2,16,T21,T22,T23
WRITE OUTPUT TAPE KT2,16,T31,T32,T33
WRITE OUTPUT TAPE KT2,17,P11,P12,P13
WRITE OUTPUT TAPE KT2,16,P21,P22,P23
WRITE OUTPUT TAPE KT2,16,P31,P32,P33
WRITE OUTPUT TAPE KT2,18,P811,PB12,PB13
WRITE OUTPUT TAPE KT2,16,PB21,PB22,PB23
WRITE OUTPUT TAPE KT2,16,PB31,PB32,PB33
WRITE OUTPUT TAPE KT2,646,TRI,RAA,REA
WRITE OUTPUT TAPE KT2,659,TRIDOT,SRAA,SREA
WRITE OUTPUT TAPE KT2,647,THETAB,PSIB,PHIB
WRITE OUTPUT TAPE KT2,648,FXP1,FYP1,FZP1,FXPSP,FYPSP,FZPSP
WRITE OUTPUT TAPE KT2,649,DELVX,DELVY,DELVZ
WRITE OUTPUT TAPE KT2,650,FTXV,FTYV,FTZV
WRITE OUTPUT TAPE KT2,651,TFTXV,TFTYV,TFTZV
IF(LRDFDI) 187,830,187
187 WRITE OUTPUT TAPE KT2,652,DREA,DRAA,DROLL
GO TO 188
830 WRITE OUTPUT TAPE KT2,652,DTHB,DPSIB,DPHIB
188 WRITE OUTPUT TAPE KT2,1008
WRITE OUTPUT TAPE KT2,653,WYV,WZV,WXV
WRITE OUTPUT TAPE KT2,27,OMU,OMEGA,OIOTA
999 WRITE OUTPUT TAPE KT2,1029,TIME,NDATE1,NDATE2,NDATE3,NRUN1,NRUN2
WRITE OUTPUT TAPE KT2,1034
WRITE OUTPUT TAPE KT2,1030, REM(-1),CT ,REM(-2),CA11
IREM(-3),CA12 ,REM(-4),CA13 ,REM(-5),CDVT ,REM(-6),CWTPR
2REM(-7),CA21 ,REM(-8),CA22 ,REM(-9),CA23 ,REM(-10),CDVI
3REM(-11),CDEL ,REM(-12),CA31 ,REM(-13),CA32 ,REM(-14),CA33
4REM(-15),CDVF ,REM(-16),CTM ,REM(-17),CSPSIR,REM(-18),CFX
5REM(-19),CX ,REM(-20),CDVXB ,REM(-21),CDTM ,REM(-22),CCPSIR
6REM(-23),CFY ,REM(-24),CY ,REM(-25),CDVYB ,REM(-26),CTDV
7REM(-27),CSTHR ,REM(-28),CFZ ,REM(-29),CZ ,REM(-30),CDVZB
8REM(-31),TSC ,REM(-32),CCTHR ,REM(-33),CDVXS ,REM(-34),CXM
9REM(-35),CDVXM

WRITE OUTPUT TAPE KT2,1030, REM(36),CTDAS ,REM(37),CM1
 1REM(38),CDVYS ,REM(39),CYM ,REM(40),CDVYM ,REM(41),CRLO
 2REM(42),CM3 ,REM(43),CDVZS ,REM(44),CZM ,REM(45),CDVZM
 3REM(46),CPHIB ,REM(47),CM4 ,REM(48),CDV ,REM(49),CXZ
 4REM(50),CDXD ,REM(51),CPSIB ,REM(52),CM5 ,REM(53),CSTZ
 5REM(54),CYZ ,REM(55),CDYD ,REM(56),CTHB ,REM(57),CM6
 6REM(58),CTD ,REM(59),CZZ ,REM(60),CDZD ,REM(61),CUDPHS
 7REM(62),COEFF ,REM(63),CSTD ,REM(64),CCRI ,REM(65),CXTD
 8REM(66),CUDPSS,REM(67),CCK1 ,REM(68),CSTDL ,REM(69),COI
 9REM(70),CYTD
 WRITE OUTPUT TAPE KT2,1030, REM(71),CUDTHS,REM(72),CCK2
 1REM(73),CWSTD ,REM(74),C2I ,REM(75),CZTD ,REM(76),CDPHSC
 2REM(77),CCK3 ,REM(78),CWSTDL,REM(79),CCABI ,REM(80),CXRD
 3REM(81),CDPSSC,REM(82),CCK4 ,REM(83),CNS ,REM(84),CCASI
 4REM(85),CYRD ,REM(86),CDTHSC,REM(87),CCK5 ,REM(88),CTX
 5REM(89),CCRBI ,REM(90),CZRD ,REM(91),CPSIBC,REM(92),CCKF
 6REM(93),CDTX ,REM(94),CCRSI ,REM(95),CDXFD ,REM(96),CTHBC
 7REM(97),CCKG ,REM(98),CRA ,REM(99),CATXBI,REM(100),CDYFD
 8REM(101),CPSBCP,REM(102),TEST ,REM(103),CR1 ,REM(104),CAPTI
 9REM(105),CDZFD
 WRITE OUTPUT TAPE KT2,1030, REM(106),CTHBCP,REM(107),FIN
 1REM(108),CDRRD ,REM(109),CSRTI ,REM(110),CXSD ,REM(111),CPSIBM
 2REM(112),FP ,REM(113),RRDREF,REM(114),CRS ,REM(115),CYSD
 3REM(116),CTHBM ,REM(117),SW ,REM(118),CRRD ,REM(119),COMGS
 4REM(120),CZSD ,REM(121),CRRI ,REM(122),CRRPI ,REM(123),CRRG
 5REM(124),CRR ,REM(125),CDVXZ ,REM(126),CSAPI ,REM(127),CSADPI
 6REM(128),CSAPG ,REM(129),CSAPR ,REM(130),CDVYZ ,REM(131),CSRPI
 7REM(132),CSRDPi,REM(133),CSRPG ,REM(134),CSRPR ,REM(135),CDVZZ
 8REM(136),RDGD ,REM(137),CTR ,REM(138),CTR1 ,REM(139),CTLRP
 9REM(140),CDTW
 WRITE OUTPUT TAPE KT2,1030, REM(141),TVX ,REM(142),TVY
 1REM(143),TVZ ,REM(144),TYC ,REM(145),TPC
 WRITE OUTPUT TAPE KT2,1019, REM(141),TVX ,REM(142),TVY
 1REM(143),TVZ ,REM(144),TYC ,REM(145),TPC
 WRITE OUTPUT TAPE KT2,1036, REM(146),LC1 ,REM(147),LC4C
 1REM(148),LC10 ,REM(149),LD100 ,REM(150),IC ,REM(151),LC1J
 2REM(152),LC4D ,REM(153),LCA ,REM(154),LDI2I ,REM(155),KC
 3REM(156),LC2 ,REM(157),LC7 ,REM(158),LCS ,REM(159),LD005
 4REM(160),K2C ,REM(161),LC3 ,REM(162),LC8 ,REM(163),N
 5REM(164),M ,REM(165),L
 WRITE OUTPUT TAPE KT2,1031,(CXT(I),CYT(I),CZT(I),CDTWT(I),I=1,11)
 GO TO 159
 112 IF (3.14159265/6.+.05-CWTPR) 10001,10001,10009
 10009 IF (LC3) 10002,10001,10002
 10002 IF (CT-(CTM+150.)) 10001,146,146
 146 IF (TEST) 10001,10005,10001
 10005 CALL KEYS (19,KEY19)
 IF (KEY19) 140,141,140
 140 IF (MUD5) 10004,10003,10004
 10003 MUD5=4095
 PRINT 1006
 10004 PRINT 1009,T,XGRT,YGRT,ZGRT,XGRD,YGRD,ZGRD,TRI,TRIDOT,LDI00
 141 CALL KEYS (20,KEY20)
 IF (KEY20) 142,10006,142
 142 WRITE OUTPUT TAPE KT2,1006
 WRITE OUTPUT TAPE KT2,1009,T,XGRT,YGRT,ZGRT,XGRD,YGRD,ZGRD,TRI,

```

*TRIDOT,LDI00*
GO TO 10006
10001 CALL KEYS (19,KEY19)
IF(KEY19) 143,144,143
143 PRINT 1003,T,XGRT,YGRT,ZGRT,CDVXSP,CDVYSP,CDVZSP,LDI2I,LRDFDI
144 CALL KEYS (20,KEY20)
IF(KEY20) 145,10006,145
145 WRITE OUTPUT TAPE KT2,1004
WRITE OUTPUT TAPE KT2,1003,T,XGRT,YGRT,ZGRT,CDVXSP,CDVYSP,CDVZSP,
*LDI2I,LRDFDI
10006 CALL KEYS (14,KEY14)
IF(KEY 14) 7002,124,7002
124 IF(IWRITE) 7002,123,7002
7002 DONPRT=4095.
123 IF ((LOC) 253,10007,253
253 KPLOT=KPLOT+1
DUM 1=XI
DUM 2=YI
DUM 3=ZI
DUM 4=DXI
DUM 5=DYI
DUM 6=DZI
DUM 7=XTI
DUM 8=VTI
DUM 9=ZTI
DUM10=DXTI
DUM11=DVTI
DUM12=DZTI
DUM13=LC1
DUM14=LC2
DUM15=LC3
DUM16=LC5
DUM17=LC7
DUM18=LC8
DO 904 JP=1,LIMIT
IPSUB=IPLST(JP)
904 TABLE1(JP,KPLOT)=VLIST(IPSUB)
IF ((KPLOT=20) 10007,255,255
255 WRITE TAPE KT3,((TABLE1(LP1,LP2),LP1=1,LIMIT),LP2=1,20)
KPLOT=0
10007 CTE=CTE+DT
CFX=0.
CFY=0.
CFZ=0.
10008 CALL KEYS (16,KEY16)
IF ((KEY16) 840,841,840
840 CALL HDA7
CALL SELFLD
ZZ3=CLOCKF(XX)
ZZ3=ZZ3-ZZ2
CALL KEYS (16,KEY16)
IF ((KEY16) 844,841,844
844 PRINT 1301,NRUN1,NRUN2,ZZ3
WRITE OUTPUT TAPE KT2,1301,NRUN1,NRUN2,ZZ3
846 IF ((LOC) 198,199,198
198 WRITE OUTPUT TAPE KT2,1298,(TABLE1(JK,20),JK=1,LIMIT)

```

PRINT 1298, (TABLE1(JK,20),JK=1,LIMIT)
END FILE KT3
199 CALL KEYS (16, KEY16)
IF (KEY16) 336,335,336
335 IF (IEXIT) 336,330,336
336 ZZ4=CLOCKF(XX)
ZZ4=ZZ4-ZZ1
PRINT 1302,ZZ4
WRITE OUTPUT TAPE KT2,1302,ZZ4
CALL EXIT
841 IF (INPASS1654,660,654
660 INPASS=4095
GO TO 101
654 IF (T-EOP) 655,655,656
655 IF (LRDFD1) 171,831,171
171 DRAA=RAA
DREA=REA
DROLL=0.
IF (ABSF(DRAA)=3.14159265) 172,173,173
173 IF (DRAA) 189,190,190
189 DRAA=DRAA+6.28318530
GO TO 172
190 DRAA=DRAA-6.28318530
172 IF (ABSF(DREA)=3.14159265) 174,191,191
191 IF (DREA) 192,193,193
192 DREA=DREA+6.28318530
GO TO 174
193 DREA=DREA-6.28318530
174 IF (ABSF(DRAA)=-.34906585) 176,176,177
177 IF (DRAA) 178,176,179
178 DRAA=-.34906585
GO TO 176
179 DRAA= -.34906585
176 IF (ABSF(DREA)=-.34906585) 180,180,181
181 IF (DREA) 182,180,183
182 DREA=-.34906585
GO TO 180
183 DREA= .34906585
180 EXV=0.
EZV=-DRAA
EYV=-DREA
XKP=XKP1
GO TO 785
831 EXP=-DPHIB
EYP=-OPSIB
EZP=DTHB
770 IF (ABSF(EXP)=.04) 60,60,61
61 EYP=0.
GO TO 362
60 IF (ABSF(EYP)=.04) 130,130,362
362 EZP=0.
130 EXV=EXP
EYV=-EZP
EZV=EYP
131 IF (CPSIBC=3.14159265/2.) 132,132,133
132 SIBC=CPSIBC

GO TO 134
133 SIBC=2.*3.14159265-CPSIBC
134 IF(SIBC-1.) 135,135,136
135 XKP=XKP1
GO TO 785
136 IF(SIBC-1.5) 137,137,138
137 XKP=XKP2
GO TO 785
138 XKP=XKP3
785 WXV=XKR*EXV
WYV=XKP*EYV
WZV=XXY*EZV
IF(ABSF(WXV)=XLIMIT)748,748,749
749 IF(WXV)789,789,790
789 WXV=-XLIMIT
GO TO 748
790 WXV=XLIMIT
748 IF(ABSF(WYV)=XLIMIT)791,791,792
792 IF(WYV)793,793,794
793 WYV=-XLIMIT
GO TO 791
794 WYV=XLIMIT
791 IF(ABSF(WZV)=XLIMIT)795,795,796
796 IF(WZV)797,797,798
797 WZV=-XLIMIT
GO TO 795
798 WZV=XLIMIT
795 FTXV=0.
FTYV=0.
FTZV=0.
703 IF(INITAL)702,701,702
702 CALL PRT
701 INITAL=1
CALL MAR (9,DT/8.,RKKI 50), 25,8,MM)
GO TO (705,811),MM
705 DA11=WZV*A12-WYV*A13
DA12=WXV*A13-WZV*A11
DA13=WYV*A11-WXV*A12
DA21=WZV*A22-WYV*A23
DA22=WXV*A23-WZV*A21
DA23=WYV*A21-WXV*A22
DA31=WZV*A32-WYV*A33
DA32=WXV*A33-WZV*A31
DA33=WYV*A31-WXV*A32
CALL DEV
811 IF(LD011) 31,32,31
31 LD011=0
33 DELVX=0.
DELVY=0.
DELVZ=0.
GO TO 21
32 IF(LC2) 281,280,281
280 JUMP=0
GO TO 288
281 IF(JUMP) 288,282,288
282 ICC=ICC+1

JUMP=4095

288 IF (ITH(ICC)) 70, 21, 70
 70 IF (LDI21) 53, 21, 53
 53 IF (CT-CTDV) 21, 747, 747
 747 IF (T-(TSC + 10.)) 21, 55, 55
 55 IF (LDI 11) 54, 56, 54
 56 IF (CTTG) 21, 54, 21
 54 IF (DELVX) 1, 2, 4
 1 IF (DELVX+(CATXFW-0.5)) 5, 3, 3
 4 IF (DELVX-(CATXBA-0.5)) 3, 3, 6
 3 FTXV=CDVXB
 GO TO 2
 5 FTXV=-CATXFW
 GO TO 2
 6 FTXV= CATXBA
 2 IF (DELVY) 8, 9, 8
 8 IF (ABSF(DELVY)-(CATYB-.5)) 7, 7, 11
 7 FTYY=CDVYB
 GO TO 9
 11 IF (DELVY) 12, 9, 13
 12 FTYY=-CATYB
 GO TO 9
 13 FTYY=CATYB
 9 IF (DELVZ) 20, 21, 20
 20 IF (ABSF(DELVZ)-(CATZB-.5)) 10, 10, 23
 10 FTZV=CDVZB
 GO TO 21
 23 IF (DELVZ) 24, 21, 25
 24 FTZV=-CATZB
 GO TO 21
 25 FTZV=CATZB
 21 IF (DELVX) 501, 502, 501
 502 LDI31=0
 GO TO 507
 501 LDI31=4095
 507 IF (DELVY) 503, 504, 503
 504 LDI25=0
 GO TO 508
 503 LDI25=4095
 508 IF (DELVZ) 505, 506, 505
 506 LDI26=0
 GO TO 509
 505 LDI26=4095
 509 Q37=FTXV*A11+FTYY*A12+FTZV*A13
 Q38=FTXV*A21+FTYY*A22+FTZV*A23
 Q39=FTXV*A31+FTYY*A32+FTZV*A33
 GO TO 101
 656 ZZ3=CLOCKF(XX)
 ZZ3=ZZ3-ZZ2
 PRINT 1300, NRUN1, NRUN2, ZZ3
 WRITE OUTPUT TAPE KT2, 1300, NRUN1, NRUN2, ZZ3
 GO TO 846
 14 FORMAT(1H ,17X, 8HVELOCITY, 32X, 3E20.8)
 15 FORMAT(1H0/1H ,5X, 6HMATRIX, 6X, 21HINERTIAL - SPACECRAFT, 19X, 3E20.8)
 16 FORMAT(1H ,57X, 3E20.8)
 17 FORMAT(1H0/1H ,5X, 6HMATRIX, 6X, 21HINERTIAL - NAVIGATION, 19X, 3E20.8)

18 FORMAT(1H0/1H ,5X,6HMATRIX,6X,23H SPACECRAFT - NAVIGATION,17X,
*3E20.8)
19 FORMAT(1H0/1H ,5X,6HMATRIX,6X,17HTARGET - INERTIAL,23X,3E20.8)
27 FORMAT(1H0/1H ,5X,37H ORBITAL PARAMETERS MU - OMEGA - IOTA,15X,3E2
*0.8)
82 FORMAT(1H ,17X,40HS/C IN TARG. CYLINDRICAL X-Y-Z POSITION,3E20.8)
83 FORMAT(1H ,43X,14HX-Y-Z VELOCITY,3E20.8)
92 FORMAT(1H ,17X,16H VECTOR MAGNITUDE,24X,E20.8)
642 FORMAT (1H1,5X,4HTIME,8X,18H FROM PROBLEM START,22X,E20.8,6X,
*5HDATE ,I2,1H/,I2,1H/,I2,7X,4HRUN ,A6,A6)
643 FORMAT (1H0/1H ,5X,6HGEMINI ,6X,19H POSITION - INERTIAL,21X,3E20.8)
644 FORMAT (1H ,17X,19H VELOCITY - INERTIAL,21X,3E20.8)
645 FORMAT (1H ,5X,6HTARGET,6X,19H POSITION - INERTIAL,21X,3E20.8)
646 FORMAT (1H0/1H ,5X,5HRADAR,7X,35HRANGE - AZIMUTH (R) - ELEVATION (
*A),5X,3E20.8)
647 FORMAT (1H0,5X,13HGIMBAL ANGLES,19H THETA - PSI - PHI,20X,3E20
.8)
648 FORMAT (1H0,5X,47H INTEGRATING ACCELEROMETER OUTPUTS - BEFORE COMP,
*5X,3E20.8/1H ,39X,12H- AFTER COMP,6X,3E20.8)
649 FORMAT(1H0,5X,12H DELTA V ,14H METER READINGS,26X,3E20.8)
650 FORMAT(1H0/1H ,5X,12H THRUSTER ,12H ACCELERATION,28X,3E20.8)
651 FORMAT(1H0,5X,12H DELTA V ,13H TOTAL APPLIED,27X,3E20.8)
652 FORMAT(1H0/1H ,5X,12H ERROR ANGLES,40X,3E20.8)
653 FORMAT (1H ,5X,13H TURNING RATES,39X,3E20.8)
659 FORMAT (1H ,17X,28H RATE - SINE R - SINE A,12X,3E20.8)
1000 FORMAT (1H1,(1H0,8E15.6))
1001 FORMAT (10I3,7I6)
1002 FORMAT (6E12.8)
1003 FORMAT (1H ,5X,F9.1,3F16.1,3F10.0,2I10)
1004 FORMAT (1H0,4X,10H TIME (SEC),3X,13H TRAILING (FT),3X,13H VERTICAL (F
*T),4X,12H OUT-OF-PLANE,3X,7H X-METER,3X,7H Y-METER,3X,7H Z-METER,5X,5H
*LDI21,4X,6H LRDFDI)
1005 FORMAT (0I2)
1006 FORMAT (1H0,6X,4HTIME,15X,22H RELATIVE POSITION (FT),14X,23H RELATIV
*E VELOCITY (FPS),6X,22H RADAR RANGE RANGE RATE,2X,5H LD100/4X,
*9H (SECONDS),6X,8H TRAILING,6X,8H VERTICAL,2X,12H OUT-OF-PLANE,3X,8H TR
*AILING,3X,8H VERTICAL,2X,9H OUT-PLANE,7X,4H(FT),8X,5H(FPS))
1007 FORMAT (1H ,26X,24H- TARGET IN GEMINI FRAME,7X,3E20.8)
1008 FORMAT (1H ,67X,5H PITCH,16X,3H YAW,17X,4H ROLL)
1009 FORMAT (1H ,3X,F9.1,3F14.1,3F11.2,F14.1,F11.2,I7)
1010 FORMAT (1I1,X12,I2,1X,I2,1X,I2,10X,A6,A6)
1011 FORMAT (1H0,5H DATE ,I2,1H/,I2,1H/,I2//1H ,4HRUN ,A6,A6)
1012 FORMAT (12I6)
1013 FORMAT (1H1,5H DATE ,I2,1H/,I2,1H/,I2//1H ,4HRUN ,A6,A6)
1014 FORMAT (I2,46X,2(A6,1X,I3,2X))
1015 FORMAT (6(A6,1X,I3,2X))
1016 FORMAT (1H0,5H PLOT,6X,4H SUB-/1H ,6H SYMBOL,4X,6H SCRIPT//
*(1H ,A6,5X,I3))
1017 FORMAT (1H0,43H OPERATOR ERROR - CHECK MQ KEYS - PUSH START/1H ,17H
*PROGRAM EXPECTS ,012 ,15H TO BE ENTERED///)
1019 FORMAT (5(1H ,A6,014,3X))
1029 FORMAT (1H1,7H TIME = ,E15.8,9H SECONDS.,52X,5H DATE ,I2,1H/,I2,1H/,
*I2,7X,4HRUN ,A6,A6/)
1030 FORMAT (5(1H ,A6,E15.8,2X))
1031 FORMAT (1H0,36H 11 VALUES EACH OF X,Y,Z, AND DELTA T//(1H ,4E20.8))
1032 FORMAT (12A6)

1034 FORMAT(1H:,40HSIMULATED COMPUTER OUTPUTS ON THIS PAGE//)

1036 FORMAT(5(1H:,A6,1X,15,11X))

1037 FORMAT(1H1,6HEOP ,E15.8,3X,6HSTCT ,E15.8,3X,6HCTZ ,E15.8,3X,
16HCTE ,E15.8,3X,6HCOINT ,E15.8/1H ,6HDELAY ,E15.8,3X,
26HESPR ,E15.8,3X,6HDOT ,E15.8,3X,6HBINT ,E15.8,3X,
36HCAPT ,E15.8/1H ,6HCOMGT ,E15.8,3X,6HCSR ,E15.8,3X,
46HXI ,E15.8,3X,6HYI ,E15.8,3X,6HZI ,E15.8/1H ,
56HDXI ,E15.8,3X,6HDYI ,E15.8,3X,6HDZI ,E15.8,3X,
66HXTI ,E15.8,3X,6HYTI ,E15.8/1H ,6HZTI ,E15.8,3X,
76HDXTI ,E15.8,3X,6HDYTI ,E15.8,3X,6HDZTI ,E15.8,3X,
86HRJ ,E15.8/1H ,6HCATXBA,E15.8,3X,6HCATXFW,E15.8,3X,
96HCATYB ,E15.8,3X,6HCATZB ,E15.8,3X,6HXKRDR ,E15.8)

1038 FORMAT(1H ,6HCCAB ,E15.8,3X,6HCCAS ,E15.8,3X,6HCCR ,E15.8,3X,
16HCCRS ,E15.8,3X,6HCO ,E15.8/1H ,6HC2 ,E15.8,3X,
26HA11 ,E15.8,3X,6HA12 ,E15.8,3X,6HA13 ,E15.8,3X,
36HA21 ,E15.8/1H ,6HA22 ,E15.8,3X,6HA23 ,E15.8,3X,
46HA31 ,E15.8,3X,6HA32 ,E15.8,3X,6HA33 ,E15.8/1H ,
56HAKX1 ,E15.8,3X,6HAKX2 ,E15.8,3X,6HAKX3 ,E15.8,3X,
66HAKX4 ,E15.8,3X,6HAKY1 ,E15.8/1H ,6HAKY2 ,E15.8,3X,
76HAKY3 ,E15.8,3X,6HAKY4 ,E15.8,3X,6HAKZ1 ,E15.8,3X,
86HAKZ2 ,E15.8/1H ,6HAKZ3 ,E15.8,3X,6HAKZ4 ,E15.8,3X,
96HXKP1 ,E15.8,3X,6HXKP2 ,E15.8,3X,6HXKP3 ,E15.8)

1039 FORMAT(1H ,6HXKR ,E15.8,3X,6HXKY ,E15.8,3X,6HCCR ,E15.8)

1040 FORMAT(1H ,7HITH(1),15,3X,7HITH(2),15,3X,7HITH(3),15,3X,7HITH(4),15,3X,7HITH(5),15/1H ,7HITH(6),15,3X,7HITH(7),15,3X,7HITH(28),15,3X,7HITH(9),15,3X,7HITH(10),15/1H ,6HMACOP ,I6,3X,
36HMACNTR ,I6,3X,6HMACINT ,I6,3X,6HMODCR ,I6,3X,6HNPF ,I6/1H ,
46HLLOC ,I6,3X,6HLMDI ,I6,3X,6HLFP ,I6,3X,6HLGANG ,I6,3X,
56HLRR ,I6/1H ,6HLSRA ,I6,3X,6HLRM ,I6,3X,6HLDB ,I6,3X,
66HLFDI ,I6,3X,6HIEXIT ,I6)

1050 FORMAT(A6,2E15.8,I4)

1051 FORMAT(1H0,6HSYMBOL,8X,4HTIME,14X,4HDATA,10X,9HSUBSCRIPT//)

1052 FORMAT(1H ,A6,2E18.8,I6)

1298 FORMAT(1H ,6E16.8)

1300 FORMAT(5H RUN ,A6,A6,24H TERMINATED BY EOP AFTER,-2PF9.2,
*9H MINUTES.)

1301 FORMAT(5H RUN ,A6,A6,27H TERMINATED BY KEY 16 AFTER,-2PF9.2,
*9H MINUTES.)

1302 FORMAT(17H THIS PROGRAM RAN,-2PF9.2,9H MINUTES.)
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0,0)

MAIN7 ENVIRONMENT - FERNEYHOUGH IBM OMEGO, N.Y.

18

STORAGE NOT USED BY PROGRAM

DEC OCT
7961 17431

DEC OCT
32230 76746

STORAGE LOCATIONS FOR VARIABLES APPEARING IN COMMON STATEMENTS

AKX1 32555 77453	AKX2 32554 77452	AKX3 32553 77451	AKX4 32552 77450	AKY1 32551 77447
AKY2 32550 77446	AKY3 32549 77445	AKY4 32548 77444	AKZ1 32547 77443	AKZ2 32546 77442
AKZ3 32545 77441	AKZ4 32544 77440	ASFX 32543 77437	ASF1 32542 77436	ASF2 32541 77435
CO1 32539 77433	CO 32540 77434	C2I 32537 77431	C2 32538 77432	CA11 32536 77430
CA12 32535 77427	CA13 32534 77426	CA21 32533 77425	CA22 32532 77424	CA23 32531 77423
CA31 32530 77422	CA32 32529 77421	CA33 32528 77420	CAPTI 32526 77416	CAPT 32527 77417
CATXBA 32525 77415	CATXBI 32524 77414	CCABI 32522 77412	CCAB 32523 77413	CCASI 32520 77410
CCAS 32521 77411	CCK1 32519 77407	CCK2 32518 77406	CCK3 32517 77405	CCK4 32516 77404
CCK5 32515 77403	CCKF 32514 77402	CCKG 32513 77401	CCPHIB 32512 77400	CCPSIB 32511 77377
CCPSIR 32510 77376	CCRBI 32507 77373	CCR8 32508 77374	CCR1 32506 77372	CCR 32509 77375
CCRS1 32504 77370	CCRS 32505 77371	CCTHB 32503 77367	CCTR 32502 77366	CCWSTD 32501 77365
CCWSTD 32500 77364	CCZT 32499 77363	COEL 32498 77362	CDPHSC 32558 77456	CDPSSC 32557 77455
CDRRD 32497 77361	CDTHSC 32556 77454	CDTM 32496 77360	CDTW 32495 77357	CDTWT 32494 77356
CDTXW 32483 77343	CDTX 32482 77342	CDVF 32480 77340	CDV1 32479 77337	CDV 32481 77341
CDVT 32478 77336	CDVXB 32477 77335	CDVXH 32476 77334	CDVXSP 32561 77461	CDVXS 32475 77333
CDVXZ 32474 77332	CDVYB 32473 77331	CDVYM 32472 77330	CDVYSP 32560 77460	CDVYS 32471 77327
CDVYZ 32470 77326	CDVZB 32469 77325	CDVZM 32468 77324	CDVZSP 32559 77457	CDVZS 32467 77323
CDVZZ 32466 77322	CDXD 32465 77321	CDXFD 32464 77320	CDYD 32463 77317	CDYFD 32462 77316
CDZD 32461 77315	CDZFD 32460 77314	CFX 32459 77313	CFY 32458 77312	CFZ 32457 77311
CM1 32456 77310	CM3 32455 77307	CM4 32454 77306	CM5 32453 77305	CM6 32452 77304
CNPC 32451 77303	CNS 32450 77302	CNVX 32449 77301	CNVY 32448 77300	CNVZ 32447 77277
CNYC 32446 77276	COEFF 32445 77275	COINT 32444 77274	COMGS 32443 77273	CPHIBC 32441 77271
CPHIB 32442 77272	CPSBCP 32440 77270	CPSIBC 32438 77266	CPSIBM 32437 77265	CPSIB 32439 77267
CR1 32436 77264	CRA 32435 77263	CRLO 32434 77262	CRRD 32432 77260	CRRG 32431 77257
CRRI 32430 77256	CRRPI 32429 77255	CCR 32433 77261	CRS 32428 77254	CSADPI 32427 77253
CSAPG 32426 77252	CSAPI 32425 77251	CSAPR 32424 77250	CSPHIB 32423 77247	CSPSIB 32422 77246
CSPSIR 32421 77245	CSRPOI 32420 77244	CSRPG 32419 77243	CSRPI 32418 77242	CSRPR 32417 77241
CSRTI 32415 77237	CSRT 32416 77240	CSTD 32413 77235	CSTD 32414 77236	CSTHB 32412 77234
CSTHR 32411 77233	CSTZ 32410 77232	CSWSTD 32409 77231	CSWTDL 32408 77230	CTDAS 32405 77225
CTD 32406 77226	CTDV 32404 77224	CTHBCP 32401 77221	CTHBC 32402 77222	CTHBM 32400 77220
CTHB 32403 77223	CTLRP 32399 77217	CTM 32398 77216	CTR1 32397 77215	CTR2 32396 77214
CT 32407 77227	CTTG 32395 77213	CTW 32394 77212	CTX 32393 77211	CUDPHS 32392 77210
CUDPHS 32391 77207	CUDTHS 32390 77206	CWSTD 32388 77204	CWSTD 32389 77205	CWTTPR 32387 77203
CXM 32385 77201	CXRD 32384 77200	CX 32386 77202	CXSD 32383 77177	CXTD 32371 77163
CXT 32382 77176	CXZ 32370 77162	CYM 32368 77160	CYRD 32367 77157	CY 32369 77161
CYSO 32366 77156	CYTD 32354 77142	CYT 32365 77155	CYZ 32353 77141	CZM 32351 77137
CZRD 32350 77136	CZ 32352 77140	CZSD 32349 77135	CZID 32337 77121	CZT 32348 77134
CZ 32336 77120	DELAY 32335 77117	DELVX 32561 77461	DELVY 32560 77460	DELVZ 32559 77457
DONPRT 32334 77116	DPHIB 32558 77456	DPSIB 32557 77455	DTHB 32556 77454	DT 32333 77115
DUM10 32323 77103	DUM11 32322 77102	DUM12 32321 77101	DUM13 32320 77100	DUM14 32319 77077
DUM15 32318 77076	DUM16 32317 77075	DUM17 32316 77074	DUM18 32315 77073	DUM1 32332 77114
DUM2 32331 77113	DUM3 32330 77112	DUM4 32329 77111	DUM5 32328 77110	DUM6 32327 77107
DUM7 32326 77106	DUM8 32325 77105	DUM9 32324 77104	FIN 32314 77072	FP 32313 77071
FXPP 32311 77067	FXP 32312 77070	FYPP 32309 77065	FYP 32310 77066	FZPP 32307 77063
FZP 32308 77064	GC 32306 77062	IC 32305 77061	IEXT 32304 77060	IOLP 32303 77057
IWRITE 32302 77056	K2C 32301 77055	KC 32300 77054	KWRIT 32299 77053	LC10 32283 77033
LC1J 32296 77050	LC1 32297 77051	LC2 32295 77047	LC3 32294 77046	LC4A 32293 77045
LC4B 32292 77044	LC4C 32291 77043	LC4D 32290 77042	LC4E 32289 77041	LC4F 32288 77040

MAIN7 ENVIRONMENT - FERNEYHOUGH IBM OMEGO, N.Y.

LC4G 32287 77037	LC5 32286 77036	LC7 32285 77035	LC8 32284 77034	LCA 32282 77032
LCS 32281 77031	LCY 32280 77030	LDI00 32279 77027	LDI10 32278 77026	LDI11 32277 77025
LDI13 32276 77024	LDI20 32275 77023	LDI21 32274 77022	LDI22 32273 77021	LDI25 32272 77020
LDI26 32271 77017	LDI31 32270 77016	LD001 32269 77015	LD005 32268 77014	LD011 32267 77013
LD012 32266 77012	LD013 32265 77011	LD062 32264 77010	LD063 32263 77007	LF01 32262 77006
LQT 32261 77005	L 32298 77052	M 32260 77004	N 32259 77003	PHIB 32258 77002
PINT 32257 77001	PSIB 32256 77000	RDGD 32255 76777	RRDREF 32254 76776	SRAA 32253 76775
SREA 32252 76774	SW 32251 76773	TEST 32250 76772	TFTXV 32249 76771	TFTYV 32248 76770
TFTZV 32247 76767	THETAB 32246 76766	TIME 32245 76765	TPC 32244 76764	TRI 32243 76763
TSC 32242 76762	TVX 32241 76761	TVY 32240 76760	TVZ 32239 76757	TYC 32238 76756
VLIST 32561 77461	XGRTD 32236 76754	XGRT 32237 76755	XKRDR 32235 76753	YGRTD 32233 76751
YGRT 32234 76752	ZGRTD 32231 76747	ZGRT 32232 76750		

STORAGE LOCATIONS FOR VARIABLES APPEARING IN DIMENSION AND EQUIVALENCE STATEMENTS

	DEC OCT		DEC OCT		DEC OCT		DEC OCT		
A11	7883 17313	A12	7884 17314	A13	7885 17315	A21	7886 17316	A22	7887 17317
A23	7888 17320	A31	7889 17321	A32	7890 17322	A33	7891 17323	DA11	7892 17324
DA12	7893 17325	DA13	7894 17326	DA21	7895 17327	DA22	7896 17330	DA23	7897 17331
DA31	7898 17332	DA32	7899 17333	DA33	7900 17334	DLIST	7898 17312	DTTP	7937 17401
DTT	7951 17417	DXI	7956 17424	DXTI	7942 17406	DYI	7955 17423	DYTI	7941 17405
DZI	7954 17422	DZTI	7940 17404	I LIST	7782 17146	IPLST	7257 16131	ITH	7317 16225
PSLST	7307 16213	Q37	7950 17416	Q38	7949 17415	Q39	7948 17414	REM	7482 16472
RJU	7938 17402	RJ	7952 17420	RKK	7932 17374	SG	7960 17430	SGVM	7953 17421
SLIST	7682 17002	TABLE1	7207 16047	TARG	7946 17412	TI	7957 17425	TLIST	7582 16636
TTI	7943 17407	FVM	7939 17403	XI	7960 17430	XTI	7946 17412	VI	7959 17427
VTI	7945 17411	ZI	7958 17426	ZTI	7944 17410				

STORAGE LOCATIONS FOR VARIABLES NOT APPEARING IN COMMON, DIMENSION, OR EQUIVALENCE STATEMENT

ARG2	6207 14077	AXTF	6206 14076	AZTF	6205 14075	BIGA	6204 14074	BIGB	6203 14073
BIGC	6202 14072	BIGD	6201 14071	BIGE	6200 14070	BIGF	6199 14067	BINT	6198 14066
B081	6197 14065	B082	6196 14064	B083	6195 14063	B08L	6194 14062	C11	6193 14061
C12	6192 14060	C13	6191 14057	C21	6190 14056	C22	6189 14055	C23	6188 14054
C31	6187 14053	C32	6186 14052	C33	6185 14051	CATXFB	6184 14050	CATYB	6183 14047
CATZB	6182 14046	CGAF	6181 14045	CGAMT	6180 14044	CGAT	6179 14043	COMGT	6178 14042
CO	6177 14041	COSX	6176 14040	COSZ	6175 14037	CPHF	6174 14036	CPHIT	6173 14035
CPHT	6172 14034	CPHX	6171 14033	CPSF	6170 14032	CPSIT	6169 14031	CPST	6168 14030
CIE	6167 14027	CTHET	6166 14026	CTHF	6165 14025	CTHT	6164 14024	CTZ	6163 14023
DELD	6162 14022	DELE	6161 14021	DELF	6160 14020	DEL	6159 14017	DRAA	6158 14016
DREA	6157 14015	DROLL	6156 14014	DTHF	6155 14013	DTHX	6154 14012	DXPFD	6153 14011
DYPFO	6152 14010	DZPFO	6151 14007	EOP	6150 14006	ESPR	6149 14005	EXP	6148 14004
EVX	6147 14003	EYP	6146 14002	EYV	6145 14001	EZP	6144 14000	EZV	6143 13777
FTXV	6142 13776	FTYY	6141 13775	FTZV	6140 13774	FXP1	6139 13773	FXPSP	6138 13772
FXPS	6137 13771	FXPSV	6136 13770	FYP1	6135 13767	FYPSP	6134 13766	FYPS	6133 13765
FYPSV	6132 13764	FZPI	6131 13763	FZPSP	6130 13762	FZPS	6129 13761	FZPSV	6128 13760
GAMT	6127 13757	GAT	6126 13756	HT	6125 13755	ICC	6124 13754	INITAL	6123 13753
INPASS	6122 13752	IPL	6121 13751	IPSUB	6120 13750	ITAG	6119 13747	JK	6118 13746
JUMP	6117 13745	KEY14	6116 13744	KEY15	6115 13743	KEY16	6114 13742	KEY17	6113 13741
KEY19	6112 13740	KEY20	6111 13737	KEYSET	6110 13736	KOMBO	6109 13735	KPLOT	6108 13734
K	6107 13733	KT1	6106 13732	KT2	6105 13731	KT3	6104 13730	LDB	6103 13727
LFP	6102 13726	LGANG	6101 13725	LIMIT	6100 13724	LMDI	6099 13723	LOC	6098 13722
LRDFDI	6097 13721	LRM	6096 13720	LRR	6095 13717	LSRA	6094 13716	MACINT	6093 13715
HACNTR	6092 13714	HACOP	6091 13713	MM	6090 13712	MODCR	6089 13711	MUDS	6088 13710
NDATE1	6087 13707	NDATE2	6086 13706	NDATE3	6085 13705	NPF	6084 13704	NRUN1	6083 13703

MAINT ENVIRONMENT - FERNEYHOUGH IBM OMEGO, N.Y.

20

NRUNZ	6082 13702	OIOTA	6081 13701	OMEGA	6080 13700	ONU	6079 13677	P11	6078 13676
P12	6077 13675	P13	6076 13674	P21	6075 13673	P22	6074 13672	P23	6073 13671
P31	6072 13670	P32	6071 13667	P33	6070 13666	PB11	6069 13665	PB12	6068 13664
P813	6067 13663	P821	6066 13662	PB22	6065 13661	PB23	6064 13660	PB31	6063 13657
P832	6062 13656	P833	6061 13655	PHF	6060 13654	PHIBS	6059 13653	PHIT	6058 13652
PHT	6057 13651	PHX	6056 13650	P	6055 13647	PSIBS	6054 13646	PSIT	6053 13645
PST	6052 13644	PSX1	6051 13643	PSX2	6050 13642	PSX	6049 13641	Q30	6048 13640
Q31	6047 13637	Q32	6046 13636	Q33	6045 13635	Q34	6044 13634	Q35	6043 13633
Q82	6042 13632	Q	6041 13631	RAA	6040 13630	RAD	6039 13627	RADTD	6038 13626
RDT	6037 13625	REAPR	6036 13624	REA	6035 13623	RE	6034 13622	RF	6033 13621
RT	6032 13620	SF	6031 13617	SGAF	6030 13616	SGAT	6029 13615	SG	6028 13614
SH	6027 13613	SIBC	6026 13612	SINK	6025 13611	SINZ	6024 13610	SJ	6023 13607
SPHF	6022 13606	SPHIT	6021 13605	SPHT	6020 13604	SPHX	6019 13603	SPSF	6018 13602
SPSIT	6017 13601	SPST	6016 13600	SRAAS	6015 13577	SREAS	6014 13576	S	6013 13575
STCT	6012 13574	STHET	6011 13573	STHF	6010 13572	STHT	6009 13571	T11	6008 13570
T12	6007 13567	T13	6006 13566	T21	6005 13565	T22	6004 13564	T23	6003 13563
T31	6002 13562	T32	6001 13561	T33	6000 13560	TEMP1	5999 13557	TEMP2	5998 13556
TEMP	5997 13555	THBS	5996 13554	THET	5995 13553	THF	5994 13552	THT	5993 13551
THX	5992 13550	TRII1	5991 13547	TRIDOT	5990 13546	TRIS	5989 13545	T	5988 13544
U233	5987 13543	U234	5986 13542	WVX	5985 13541	WVY	5984 13540	WZV	5983 13537
XKP1	5982 13536	XKP2	5981 13535	XKP3	5980 13534	XKP	5979 13533	XKR	5978 13532
XKY	5977 13531	XLIMIT	5976 13530	XPD	5975 13527	XP	5974 13526	XRI	5973 13525
XRV	5972 13524	XX	5971 13523	YPD	5970 13522	YP	5969 13521	YRI	5968 13520
YRV	5967 13517	ZPD	5966 13516	ZP	5965 13515	ZRI	5964 13514	ZRV	5963 13513
ZZ1	5962 13512	ZZ2	5961 13511	ZZ3	5960 13510	ZZ4	5959 13507	ZZ	5958 13506

SYMBOLS AND LOCATIONS FOR SOURCE PROGRAM FORMAT STATEMENTS

E1E	14 13467	E1F	15 13461	E1G	16 13447	E1H	17 13446	E1I	18 13432
E1J	19 13416	E1R	27 13404	E12I	82 13371	E12J	83 13357	E12S	92 13351
E1K2	642 13342	E1K3	643 13321	E1K4	644 13307	E1K5	645 13277	E1K6	646 13265
E1K7	647 13250	E1K8	648 13235	E1K9	649 13213	E1KA	650 13202	E1KB	651 13170
E1KC	652 13157	E1KD	653 13150	E1KJ	659 13141	E1V8	1000 13130	E1V9	1001 13124
E1VA	1002 13122	E1VB	1003 13120	E1VC	1004 13112	E1VD	1005 13062	E1VE	1006 13061
E1VF	1007 13007	E1VG	1008 12777	E1VH	1009 12770	E1VI	1010 12760	E1VJ	1011 12752
E1VK	1012 12741	E1VL	1013 12737	E1VM	1014 12726	E1VN	1015 12722	E1VO	1016 12717
E1VP	1017 12702	E1VR	1019 12660	E1105	1029 12654	E1106	1030 12636	E1107	1031 12632
E1108	1032 12620	E110A	1034 12616	E110C	1036 12605	E110D	1037 12601	E110E	1038 12426
E110F	1039 12253	E110G	1040 12241	E110Q	1050 12133	E110R	1051 12130	E110S	1052 12117
E118I	1298 12113	E118K	1300 12110	E118L	1301 12074	E118M	1302 12060		

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

DEC	OCT	DEC	OCT	DEC	OCT	DEC	OCT
11	5944 13470	21	5101 11755	31	5120 12000	41	32767 77777
C1G1	5953 13501	C1G3	5954 13502	C1G4	5955 13503	C1G7	5956 13504
D117D	4914 11462	D120P	605 01135	D121H	1666 03202	D1225	2097 04061
D1422	2079 04037	D1429	2127 04117	D145A	4456 10550	D1522	2078 04036
E125	2096 04060	E127	2120 04110	E129	2129 04121	E1529	2126 04116

LOCATIONS OF NAMES IN TRANSFER VECTOR

MAIN7 ENVIRONMENT - FERNEYHOUGH IBM ONEWOO, N.Y.

ARCOS	DEC 16	OCT 00020	ARSIN	DEC 15	OCT 00017	ATN1	DEC 14	OCT 00016	CLOCK	DEC 1	OCT 00001	COS	DEC 12	OCT 00014
CTRL1	22	00026	DEV	29	00035	EXIT	26	00032	HDA7	2	00002	HDA9	11	00013
INSERT	20	00024	KEYCN	7	00007	KEYS	19	00023	LDB6	4	00004	MAR	28	00034
PRT	27	00033	QUANT	21	00025	SELFLD	3	00003	SIN	13	00015	SQRT	17	00021
STATE	18	00022	(LEFT)	25	00031	(FIL)	9	00011	(FPT)	0	00000	(RTN)	6	00006
(SPH)	8	00010	(STB)	23	00027	(STH)	10	00012	(TSH)	5	00005	(HLR)	24	00030

ENTRY POINTS TO SUBROUTINES NOT OUTPUT FROM LIBRARY

ARCOS	ARSIN	ATN1	CLOCK	COS	CTRL1	DEV	EXIT	HDA7	HDA9
INSERT	KEYCN	KEYS	LDB6	MAR	PRT	QUANT	SELFLD	SIN	SQRT
STATE	(LEFT)	(FIL)	(FPT)	(RTN)	(SPH)	(STB)	(STH)	(TSH)	(HLR)

EXTERNAL FORMULA NUMBERS WITH CORRESPONDING INTERNAL FORMULA NUMBERS AND OCTAL LOCATIONS

EFN 330	IFN 00071	LOC 83	EFN 331	IFN 00077	LOC 86	EFN 332	IFN 00104	LOC 88	EFN 333	IFN 00113	LOC 91	EFN 334	IFN 00120	LOC 93
57	107	00451	58	109	00460	59	113	00473	115	129	01037	108	130	01042
116	132	01053	109	135	01077	113	138	01112	125	140	01136	252	141	01140
251	148	01166	903	153	01207	94	159	01231	95	160	01233	98	182	01444
29	197	01571	28	199	01600	30	200	01606	97	243	02466	96	257	02651
995	261	02711	990	269	02732	992	272	02743	989	273	02750	996	289	03100
851	292	03106	553	307	03160	554	308	03164	555	312	03173	101	316	03203
102	321	03220	71	323	03225	72	335	03332	700	341	03426	704	342	03430
601	368	03736	602	370	03757	603	371	03775	551	373	03777	552	375	04001
556	376	04003	428	377	04007	427	379	04016	300	382	04023	110	383	04030
114	385	04034	104	386	04040	105	387	04045	106	389	04055	107	391	04062
117	393	04077	118	394	04103	119	395	04111	122	396	04113	111	398	04122
126	402	04151	127	403	04153	128	404	04157	767	405	04161	762	410	04254
761	411	04264	765	415	04332	764	416	04342	197	417	04354	768	418	04361
769	419	04366	766	420	04373	448	421	04377	763	423	04402	449	424	04404
450	425	04406	451	426	04410	452	427	04415	455	428	04421	453	429	04425
454	430	04427	456	432	04432	787	433	04434	771	461	04760	772	462	04763
920	471	05052	421	479	05070	420	494	05141	401	495	05143	400	498	05173
403	499	05175	402	500	05202	405	501	05204	407	502	05214	422	503	05224
423	504	05226	424	505	05233	408	506	05235	640	507	05240	901	509	05244
426	510	05246	404	517	05264	409	518	05266	410	519	05276	411	521	05302
412	522	05306	413	524	05323	415	526	05327	416	527	05333	417	529	05350
418	531	05354	419	532	05360	406	533	05365	202	534	05367	7001	535	05373
7000	536	05402	201	537	05404	121	538	05411	120	539	05415	150	540	05422
154	541	05424	157	542	05430	151	543	05434	152	544	05440	153	545	05444
155	546	05450	158	547	05455	159	549	05466	156	551	05477	641	552	05503
200	553	05506	414	555	05515	187	614	06351	830	617	06370	188	619	06406
999	624	06450	112	647	10066	10009	648	10076	10002	649	10100	146	650	10107
10005	651	10113	140	653	10122	10003	654	10126	10004	656	10135	141	658	10170
142	660	10177	10001	664	10242	143	666	10251	144	668	10302	145	670	10311
10006	673	10351	124	675	10362	7002	676	10364	123	677	10366	253	678	10370
904	699	10501	255	701	10513	10007	710	10551	10008	714	10562	840	716	10571
844	722	10614	846	726	10647	198	727	10651	199	738	10710	335	740	10721
336	741	10723	841	748	10757	660	749	10763	654	751	10766	655	752	10772
171	753	10774	173	757	11010	189	758	11013	190	760	11017	172	761	11022
191	762	11030	192	763	11033	193	765	11037	174	766	11042	177	767	11050
178	768	11053	179	770	11056	176	771	11060	181	772	11066	182	773	11071
183	775	11074	180	776	11076	831	781	11107	770	784	11115	61	785	11123

MAIN7 ENVIRONMENT - FERNEYHOUGH IBM DWEGD, N.Y.

22

60	787	11126	362	788	11134	130	789	11136	131	792	11144	132	793	11153
133	795	11156	134	796	11162	135	797	11166	136	799	11171	137	800	11175
138	802	11200	785	803	11202	749	807	11221	789	808	11224	790	810	11227
748	811	11231	792	812	11237	793	813	11242	794	815	11245	791	816	11247
796	817	11255	797	818	11260	798	820	11263	795	821	11265	703	824	11273
702	825	11275	701	826	11300	705	829	11322	811	839	11424	31	840	11426
33	841	11430	32	845	11437	280	846	11443	281	848	11446	282	849	11452
288	851	11463	70	852	11465	53	853	11467	747	854	11474	55	855	11503
56	856	11507	54	857	11513	1	858	11516	4	859	11524	3	860	11532
5	862	11535	6	864	11540	2	865	11542	6	866	11544	7	867	11554
11	869	11557	12	870	11562	13	872	11565	9	873	11567	20	874	11571
10	875	11601	23	877	11604	24	878	11607	25	880	11612	21	881	11614
502	882	11620	501	884	11623	507	885	11625	504	886	11631	503	888	11634
508	889	11636	506	890	11642	505	892	11645	509	893	11647	656	897	11711

```

SUBROUTINE GEXEC
DIMENSION CXT(11),CYT(11),CZT(11),CDTWT(11)
COMMON CDVXSP,CDVYSP,CDVZSP,CDPHSC,CDPSSC,CDTHSC,AKX1 ,AKX2 ,
1AKX3 ,AKX4 ,AKY1 ,AKY2 ,AKY3 ,AKY4 ,AKZ1 ,AKZ2 ,AKZ3 ,
2AKZ4 ,ASFX ,ASFY ,ASFZ ,CO ,COI ,C2 ,C2I ,CA11 ,
3CA12 ,CA13 ,CA21 ,CA22 ,CA23 ,CA31 ,CA32 ,CA33 ,CAPT ,
4CAPTI ,CATXBA,CATXBI,CCAB ,CCABI ,CCAS ,CCASI ,CCK1 ,CCK2 ,
5CCK3 ,CCK4 ,CCK5 ,CCKF ,CCKG ,CCPHIB,CCPSIB,CCPSIR,CCR ,
6CCRB ,CCRB1 ,CCRI ,CCRS ,CCRSI ,CCTHB ,CCTHR ,CCWSTD,CCWTDL ,
7CCZT ,CDEL ,CDRRD ,CDTM ,CDTW ,CDTWT ,CDTDX ,CDTX ,
8CDVFB ,CDVI ,CDVT ,CDVXB ,CDVXM ,CDVXS ,CDVXZ ,CDVYB ,CDVYM ,
9CDVYS ,CDVYZ ,CDVZB ,CDVZM ,CDVZS ,CDVZZ ,CDXD ,CDXF D ,CDYD ,
COMMON CDYFD ,CDZD ,CDZFD ,CFX ,CFY ,CFZ ,CM1 ,CM3 ,
1CM4 ,CM5 ,CM6 ,CNPC ,CNS ,CNVX ,CNVY ,CNVZ ,CNYC ,
2CDEFF ,COINT ,COMGS ,CPHIB ,CPHIBC,CPSBCP,CPSIB ,CPSIBC,CPSIBM ,
3CR1 ,CRA ,CRLO ,CRR ,CRRD ,CRRG ,CRRI ,CRRPI ,CRS ,
4CSADPI ,CSAPG ,CSAPI ,CSAPR ,CPHIB,CSPSIB,CSPSIR,CSRDP I ,CSRP G ,
5CSRPI ,CSRPR ,CSRT ,CSRTI ,CSTD ,CSTD L ,CSTHB ,CSTHR ,CSTZ ,
6CSWSTD,CSWTDL ,CT ,CTD ,CTDAS ,CTDV ,CTHB ,CTHBC ,CTHBCP ,
7CTHBM ,CTLRP ,CTM ,CTRL ,CTRR ,CTTG ,CTW ,CTX ,CUDPHS ,
8CUDPSS,CUDTHS,CWSTD ,CWSTD L ,CWTTPR ,CX ,CX M ,CXRD ,CXSD ,
9CXT ,CXTD ,CXZ ,CY ,CYM ,CYRD ,CYSD ,CYT ,CYTD ,
COMMON CYZ ,CZ ,CZM ,CZRD ,CZSD ,CZT ,CZTD ,CZZ ,
1DELAY ,DONPRT ,DT ,DUM1 ,DUM2 ,DUM3 ,DUM4 ,DUM5 ,DUM6 ,
2DUM7 ,DUM8 ,DUM9 ,DUM10 ,DUM11 ,DUM12 ,DUM13 ,DUM14 ,DUM15 ,
3DUM16 ,DUM17 ,DUM18 ,FIN ,FP ,FXP ,FXPP ,FYP ,FYPP ,
4FZP ,FZPP ,GC ,IC ,IEXIT ,IOLP ,IWRITE,K2C ,KC ,
5KWRITE ,L ,LC1 ,LC1J ,LC2 ,LC3 ,LC4A ,LC4B ,LC4C ,
6LC4D ,LC4E ,LC4F ,LC4G ,LC5 ,LC7 ,LC8 ,LC10 ,LCA ,
7LC S ,LCY ,LDI00 ,LDI10 ,LDI11 ,LDI13 ,LDI120 ,LDI21 ,LDI22 ,
8LDI125 ,LDI126 ,LDI31 ,L0001 ,LD005 ,LD011 ,LD012 ,LD013 ,LD062 ,
9LD063 ,LFDI ,LQT ,M ,N ,PHIB ,PINT ,PSIB ,RDGD ,
COMMON RRDREF ,SRAA ,SREA ,SW ,TEST ,TFTXV ,TFTYV ,TFTZV ,
1THETAB ,TIME ,TPC ,TRI ,TSC ,TVX ,TVY ,TVZ ,TYC ,
2XGRT ,XGR TD ,XKRDR ,YGRT ,YGR TD ,ZGRT ,ZGR TD ,
EQUIVALENCE (DELVX,CDVXSP),(DELVY,CDVYSP),(DELVZ,CDVZSP),(CDPHSC,
*DPHIB),(CDPSSC,DPSIB),(CDTHSC,DTHB),(VLIST,CDVXSP)

MUD1=0
IF (MUD1) 2,3,2
3 CALL ENB (INTDD)
IF ((LCX) 18,101,8
101 LC4A=0
LC4B=0
LC4C=0
LC4D=0
LC4E=0
LC4G=0
LCY=0
LCX=4095
8 IF ((LCY) 105,102,105
102 LD062=0
LD005=0
CTDAS=0
TIMEP=TIME
LCY=4095

```

105 CALL GONOGO
CALL DSB
106 CTDAS=TIME-TIMEP
CT=CTDAS
107 IF : (LDI20) 108,109,108
108 CALL AGE
109 IF(LDI11)115,110,115
110 IF ((LDI10) 113,112,113
112 LC4A=4095
LC4B=0
LC4C=0
LC4D=0
LC4E=0
LC4G=0
LCY=0
GO TO 3
113 IF : (LDI13) 7,6,7
6 CALL ASCENT (LC4A,LC4B,LC4C,LC4D,LC4E,LC4G,LCY)
GO TO 3
7 CALL RNDZ
115 IF(LDI10)9,111,9
9 CALL TDPRED (LC4A,LC4B,LC4C,LC4D,LC4E,LC4G,LCY)
GO TO 3
111 IF : (LDI13) 5,4,5
4 CALL RNDZ
5 CALL REENT (LC4A,LC4B,LC4C,LC4D,LC4E,LC4G,LCY)
GO TO 3
2 RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0)

GEXEC7 EXECUTOR FOR MATH FLOW 7 RENDEZVOUS DYNAMIC SIMULATION

25

STORAGE NOT USED BY PROGRAM

DEC OCT
148 00224DEC OCT
32230 76746

STORAGE LOCATIONS FOR VARIABLES APPEARING IN COMMON STATEMENTS

	DEC	OCT		DEC	OCT		DEC	OCT		DEC	OCT		DEC	OCT	
AKX1	32555	77453		AKX2	32554	77452	AKX3	32553	77451	AKX4	32552	77450	AKY1	32551	77447
AKY2	32550	77446		AKY3	32549	77445	AKY4	32548	77444	AKZ1	32547	77443	AKZ2	32546	77442
AKZ3	32545	77441		AKZ4	32544	77440	ASFX	32543	77437	ASFY	32542	77436	ASFZ	32541	77435
COI	32539	77433		CO	32540	77434	C21	32537	77431	C2	32538	77432	CA11	32536	77430
CA12	32535	77427		CA13	32534	77426	CA21	32533	77425	CA22	32532	77424	CA23	32531	77423
CA31	32530	77422		CA32	32529	77421	CA33	32528	77420	CAPTI	32526	77416	CAPT	32527	77417
CATXBA	32525	77415		CATXBI	32524	77414	CCABI	32522	77412	CCAB	32523	77413	CCASI	32520	77410
CCAS	32521	77411		CCK1	32519	77407	CCK2	32518	77406	CCK3	32517	77405	CCK4	32516	77404
CCK5	32515	77403		CCKF	32514	77402	CCKG	32513	77401	CCPHIB	32512	77400	CCPSIB	32511	77377
CCPSIR	32510	77376		CCRBI	32507	77373	CCR8	32508	77374	CCR1	32506	77372	CCR	32509	77375
CCRSI	32504	77370		CCRS	32505	77371	CCTHB	32503	77367	CCTHR	32502	77366	CCWSTD	32501	77365
CCWTDL	32500	77364		CCZT	32499	77363	CDEL	32498	77362	COPHSC	32558	77456	COPSSC	32557	77455
CDRRD	32497	77361		CDTHSC	32556	77454	CDTM	32496	77360	CDTW	32495	77357	CDTHWT	32494	77356
CDTHX	32483	77343		CDTX	32482	77342	CDVF	32480	77340	CDVI	32479	77337	CDV	32481	77341
CDVT	32478	77336		CDVXB	32477	77335	CDVXM	32476	77334	CDVXSP	32561	77461	CDVXS	32475	77333
CDVXZ	32474	77332		CDVYB	32473	77331	CDVY	32472	77330	CDVYSP	32560	77460	CDVYS	32471	77327
CDVYZ	32470	77326		CDVZB	32469	77325	CDVZM	32468	77324	CDVZSP	32559	77457	CDVZS	32467	77323
CDVZZ	32466	77322		CDXD	32465	77321	CDXFD	32464	77320	CDYD	32463	77317	CDYFD	32462	77316
CDZD	32461	77315		CDZFD	32460	77314	CFX	32459	77313	CFY	32458	77312	CFZ	32457	77311
CM1	32456	77310		CM3	32455	77307	CM4	32454	77306	CM5	32453	77305	CM6	32452	77304
CNPC	32451	77303		CNS	32450	77302	CNVK	32449	77301	CNVY	32448	77300	CNVZ	32447	77277
CNYC	32446	77276		COEFF	32445	77275	COINT	32444	77274	COMGS	32443	77273	COPHIB	32441	77271
COPHIB	32442	77272		CPSBCP	32440	77270	CPSIBC	32438	77266	CPSIBM	32437	77265	CPSIB	32439	77267
CR1	32436	77264		CRA	32435	77263	CRLO	32434	77262	CRRD	32432	77260	CRRG	32431	77257
CRRI	32430	77256		CRRPI	32429	77255	CRR	32433	77261	CRS	32428	77254	CSADPI	32427	77253
CSAPG	32426	77252		CSAPI	32425	77251	CSAPR	32424	77250	CSPHIB	32423	77247	CSPSIB	32422	77246
CSPSIR	32421	77245		CSRDP	32420	77244	CSRPG	32419	77243	CSRPI	32418	77242	CSRPR	32417	77241
CSRTI	32415	77237		CSRT	32416	77240	CSTD	32413	77235	CSTD	32414	77236	CSTHB	32412	77234
CSTRH	32411	77233		CSTZ	32410	77232	CSWSTD	32409	77231	CSWTDL	32408	77230	CTDAS	32405	77225
CTD	32406	77226		CTDV	32404	77224	CTHBCP	32401	77221	CTHBC	32402	77222	CTHBM	32400	77220
CTHB	32403	77223		CTLRP	32399	77217	CTM	32398	77216	CTR1	32397	77215	CTR	32396	77214
CT	32407	77227		CTTG	32395	77213	CTW	32394	77212	CTX	32393	77211	CUDPHS	32392	77210
CUDPSS	32391	77207		CUDTHS	32390	77206	CWSTD	32388	77204	CWSTD	32389	77205	CWTPR	32387	77203
CXM	32385	77201		CXRD	32384	77200	CX	32386	77202	CXSD	32383	77177	CY	32369	77161
CXT	32382	77176		CXZ	32370	77162	CYM	32368	77160	CYRD	32367	77157	CZM	32351	77137
CYSD	32366	77156		CYT	32354	77142	CYT	32365	77155	CYZ	32353	77141	CZT	32348	77134
CZRD	32350	77136		CZ	32352	77140	CZSD	32349	77135	CZTD	32337	77121	DELVZ	32559	77457
CZZ	32336	77120		DELAY	32335	77117	DELVX	32561	77461	DELVY	32560	77460	DT	32333	77115
DONPRT	32334	77116		DPHIB	32558	77456	DPSIB	32557	77455	DTHB	32556	77454	DUM14	32319	77077
DUM10	32323	77103		DUM11	32322	77102	DUM12	32321	77101	DUM13	32320	77100	DUM1	32332	77114
DUM15	32318	77076		DUM16	32317	77075	DUM17	32316	77074	DUM18	32315	77073	DUM6	32327	77107
DUM2	32331	77113		DUM3	32330	77112	DUM4	32329	77111	DUM5	32328	77110	FP	32313	77071
DUM7	32326	77106		DUM8	32325	77105	DUM9	32324	77104	FIN	32314	77072	FZPP	32307	77063
FXPP	32311	77067		FXP	32312	77070	FYPP	32309	77065	FYP	32310	77066	IOLP	32303	77057
FZP	32308	77064		GC	32306	77062	IC	32305	77061	IEXIT	32304	77060	LC10	32283	77033
IWRITE	32302	77056		K2C	32301	77055	KC	32300	77054	KWRIT	32299	77053	LC4A	32293	77045
LC1J	32296	77050		LC1	32297	77051	LC2	32295	77047	LC3	32294	77046	LC4F	32288	77040
LC4B	32292	77044		LC4C	32291	77043	LC4D	32290	77042						

GEXEC7 EXECUTOR FOR MATH FLOW 7 RENDEZVOUS DYNAMIC SIMULATION

LC46 32287 77037	LC5 32286 77036	LC7 32285 77035	LC8 32284 77034	LCA 32282 77032
LCS 32281 77031	LCY 32280 77030	LDI00 32279 77027	LDI10 32278 77026	LDI11 32277 77025
LDI13 32276 77024	LDI20 32275 77023	LDI21 32274 77022	LDI22 32273 77021	LDI25 32272 77020
LDI26 32271 77017	LDI31 32270 77016	LD001 32269 77015	LD005 32268 77014	LD011 32267 77013
LD012 32266 77012	LD013 32265 77011	LD002 32264 77010	LD003 32263 77007	LFDI 32262 77006
LQT 32261 77005	L 32298 77052	M 32260 77004	N 32259 77003	PHIB 32258 77002
PINT 32257 77001	PSIB 32256 77000	RDGD 32255 76777	RRDREF 32254 76776	SRAA 32253 76775
SREA 32252 76774	SW 32251 76773	TEST 32250 76772	TFTXV 32249 76771	TFTYV 32248 76770
TFIZV 32247 76767	THETAB 32246 76766	TIME 32245 76765	TPC 32244 76764	TRI 32243 76763
TSC 32242 76762	TVX 32241 76761	TVY 32240 76760	TVZ 32239 76757	TYC 32238 76756
VLIST 32561 77461	XGRTD 32236 76754	XGRT 32237 76755	XKRDR 32235 76753	YGRTD 32233 76751
YGRT 32234 76752	ZGRTD 32231 76747	ZGRT 32232 76750		

STORAGE LOCATIONS FOR VARIABLES NOT APPEARING IN COMMON, DIMENSION, OR EQUIVALENCE STATEMENT

DEC	OCT	DEC	OCT	DEC	OCT	DEC	OCT	DEC	OCT
INTDD	147 00223	LCX	146 00222	MUD1	145 00221	TIMEP	144 00220		

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

DEC	OCT	DEC	OCT	DEC	OCT	DEC	OCT	DEC	OCT
2)	135 00207	3)	137 00211	6)	138 00212				

LOCATIONS OF NAMES IN TRANSFER VECTOR

DEC	OCT	DEC	OCT	DEC	OCT	DEC	OCT	DEC	OCT
AGE	3 00003	ASCENT	4 00004	DSB	2 00002	ENB	0 00000	GONO GO	1 00001
REENT	7 00007	RNDZ	5 00005	TOPRED	6 00006				

ENTRY POINTS TO SUBROUTINES NOT OUTPUT FROM LIBRARY

AGE	ASCENT	DSB	ENB	GONO GO	REENT	RNDZ	TOPRED
-----	--------	-----	-----	---------	-------	------	--------

EXTERNAL FORMULA NUMBERS WITH CORRESPONDING INTERNAL FORMULA NUMBERS AND OCTAL LOCATIONS

EFN	IFN	LOC									
3	11	00027	101	13	00035	8	21	00055	102	22	00061
106	29	00075	107	31	00102	108	32	00104	109	33	00105
112	35	00115	113	43	00134	6	44	00140	7	46	00151
9	48	00154	111	50	00165	4	51	00171	5	52	00172
									2	54	00203

SUBROUTINE RNDZ
 DIMENSION CXT(11),CYT(11),CZT(11),CDTWT(11)
 COMMON CDVXSP,CDVYSP,CDVZSP,CDPHSC,COPSSC,CDTHSC,AKX1,AKX2,
 1AKX3,AKX4,AKY1,AKY2,AKY3,AKY4,AKZ1,AKZ2,AKZ3,
 2AKZ4,ASFX,ASFY,ASFZ,CO,COI,C2,C2I,CA11,
 3CA12,CA13,CA21,CA22,CA23,CA31,CA32,CA33,CAPT,
 4CAPTE,CATXBA,CATXBI,CCAB,CCABI,CCAS,CCASI,CCK1,CCK2,
 5CCK3,CCK4,CCK5,CCKF,CCKG,CCPHIB,CCPSIB,CCPSIR,CCR,
 6CCRB,CCRBI,CCR1,CCRS,CCRSI,CCTHB,CCTHR,CCWSTD,CCWTDL,
 7CCZT,CDEL,CDRRD,CDTM,CDTW,CDTWT,CDTDX,CDV,
 8CDVF,CDVI,CDVT,CDVXB,CDVXM,CDVXS,CDVXZ,CDVYB,CDVYM,
 9CDVYS,CDVYZ,CDVZB,CDVZM,CDVZS,CDVZZ,CDXD,CDXF,DYD,
 COMMON CDYFD,CDZD,CDZFD,CFX,CFY,CFZ,CM1,CM3,
 1CM4,CM5,CM6,CNPC,CNS,CNVX,CNVY,CNVZ,CNYC,
 2CDEFF,COINT,COMGS,CPHIB,CPHIBC,CPSBCP,CPSIB,CPSIBC,CPSIBM,
 3CR1,CRA,CRLO,CRR,CRRD,CRRG,CRRPI,CRS,
 4CSADPI,CSAPG,CSAPI,CSAPR,CSPHIB,CSPSIB,CSPSIR,CSRDP1,CSRPG,
 5CSRPI,CSRPR,CSRT,CSRTI,CSTD,CSTDL,CSTHB,CSTHR,CSTZ,
 6CSWSTD,CSWTDL,CT,CTD,CTDAS,CTDV,CTHB,CTHBC,CTHBCP,
 7CTHBM,CTLRP,CTM,CTR1,CTR2,CTTG,CTW,CTX,CUDPHS,
 8CUDPSS,CUDTHS,CWSTD,CWSTDL,CWTPR,CX,CXM,CXRD,CXSD,
 9CXT,CXTD,CXZ,CY,CYM,CYRD,CYSD,CYT,CYTD,
 COMMON CYZ,CZ,CZM,CZRD,CZSD,CZT,CZTD,CZZ,
 1DELAY,DONPRT,DT,DUM1,DUM2,DUM3,DUM4,DUM5,DUM6,
 2DUM7,DUM8,DUM9,DUM10,DUM11,DUM12,DUM13,DUM14,DUM15,
 3DUM16,DUM17,DUM18,FIN,FP,FXP,FXPP,FYP,FYPP,
 4FZP,FZPP,GC,IC,IEXIT,IOLP,IWRITE,K2C,KC,
 5KWRITE,L,LC1,LC1J,LC2,LC3,LC4A,LC4B,LC4C,
 6LC4D,LC4E,LC4F,LC4G,LC5,LC7,LC8,LC10,LCA,
 7LC9,LCY,LDI00,LDI10,LDI11,LDI13,LDI20,LDI21,LDI22,
 8LDI25,LDI26,LDI31,LD001,LD005,LD011,LD012,LD013,LD062,
 9LD063,LFDI,LQT,M,N,PHIB,PINT,PSIB,RDGD,
 COMMON RRDREF,SRAA,SREA,SW,TEST,TFTXV,TFTYV,TFTZV,
 1THETAB,TIME,TPC,TRI,TSC,TVX,TVY,TVZ,TYC,
 2XGRT,XGRD,XKDRD,YGRT,YGRTD,ZGRT,ZGRTD
 EQUIVALENCE (DELVX,CDVXSP),(DELVY,CDVYSP),(DELVZ,CDVZSP),(CDPHSC,
 *DPHIB),(CDPSSC,DPSIB),(CDTHSC,DTHB),(VLIST,CDVXSP)

```

1 IF(LDI11) 101,109,101
101 IF(LC4D) 113,102,113
102 LC4D=4095
  LC4C=0
103 CWTTPR=3.*3.14159265/2.
  CDEL=3.14159265/3.
  LC4A=0
  LC4B=0
  LC4E=0
  LC4F=0
  LC4G=0
  LC24=4095
  LC24A=4095
  LC29=4095
  CRLO=0.
  DAS=CUREND
104 LC1=4095
  LC2=0

```

LC3=0
LC5=0
LC7=0
LC8=0
IC=0
K2C=0
CTX=0.
M=0
LCA=0
CTR1=-20.
CTW=100.
CDTX=100.
CPSIBC=0.
CTHBC=0.
LCY=0
105 IF(IC=10) 106,106,108
106 CDTWT(IC+1)=-1.
107 IC=IC+1
GO TO 105
108 IC=0
2 CALL GEXEC
109 IF(LC4C) 113,110,113
110 LC4C=4095
LC4D=0
GO TO 103
113 CTRR=CT-CTR1-20.
IF(CTR) 114,114,114
114 IF(CTR=1.) 116,115,115
115 CRRD=9999.
M=0
CDRRD=9999.
116 LC10=0
L=0
CRA=0.
124 CALL GANG (CTHB,CPHIB,CPSIB,THETAB,PHIB,PSIB,CUDTHS,CUDPSS,CUDPHS,
*CTHBC,CPSIBC)
126 CALL ERRANG (CUDPHS,CUDPSS,CUDTHS,CDPHSC,CDPSSC,CDTHSC)
128 CDTM=CAPT *CDEL/6.28318530
129 CSPHIB=SINF(CPHIB)
CSPSIB=SINF(CPSIB)
CSTHB=SINF(CTHB)
CCPHIB=COSF(CPHIB)
CCPSIB=COSF(CPSIB)
CCTHB=COSF(CTHB)
130 CA11=CCPSIB*CSTHB
CA12=-CCPSIB*CSTHB
CA13=-CSPSIB
CA21=CSTHB*CSPHIB-CCTHB*CSPSIB*CCPHIB
CA22=CCTHB*CSPHIB+CSTHB*CSPSIB*CCPHIB
CA23=-CCPSIB*CCPHIB
CA31=CSTHB*CCPHIB+CCTHB*CSPSIB*CSPHIB
CA32=CCTHB*CCPHIB-CSTHB*CSPSIB*CSPHIB
CA33=CCPSIB*CSPHIB
132 IF(LC4B) 516,131,516
131 N=-1
133 LD063=0

134 LD001=4095
135 CALL WAITS
136 IF(LDI00) 137,218,137
137 IF(N) 139,202,202
139 CRRRI=TRI
CSAPI=SREA
CSRPI=SRAA
140 CSAPI=CSAPI+CCAB +CCAS *CSAPI
CSRPI=CSRPI+CCR8 +CCRS *CSRPI
141 IF(CRL0) 142,143,142
142 CSAPI=0.
CSRPI=0.
GO TO 145
143 IF(ABSF(CSRPI)=.406736643) 144,218,218
144 IF(ABSF(CSAPI)=.406736643) 145,218,218
145 IF(CRRRI-XKRDR) 146,218,218
146 N=0
GO TO 133
202 CRRPI=TRI
CSADPI=SREA
CSRDPPI=SRAA
203 IF(ABSF(CRRPI-CRRI)=CCR) 204,218,218
204 RDGD=0.
CRRG =CRRI
CSAPG=CSAPI
CSRPG=CSRPI
205 IF(LC10) 219,206,219
206 L=L+1
207 CRA=CRA+CRRG
208 IF(L=5) 131,209,209
209 CRA=CRA/5.
210 IF(M) 212,211,212
211 M=1
GO TO 216
212 CRRD=(CRA-CR1)/(CT-CTR1)
213 RRDREF=C0 +C2 *SQRTF(CRRG)
214 CDRRD =RRDREF-CRRD
216 CR1=CRA
CTR1=CT
217 LC10=4095
GO TO 2
218 RDGD=4095.
219 IF(K2C) 415,220,415
220 IF((3.14159265/6.+.05=CWTPR) 227,221,221
221 IF((CT-(CTM+150.)) 227,222,222
222 IF(LC3) 223,227,223
223 LD005=0
265 CDTW=0.
GO TO 243
227 IF(LC1) 240,228,240
228 IF(LC40) 230,245,230
230 IF(LC7) 232,231,232
231 CTM=CT
232 IF(LC3) 247,233,247
233 IF((CTX= 750.) 234,235,235
234 LD0062=0

GO TO 238
 235 IF (LDI21) 333,238,333
 238 CDTW=CT-(CTM+CTX)
 IF (CDTW) 239,241,241
 239 IF (CDTW+50.) 2,240,240
 240 CALL IVISZS (LDI22,LC5,CSTZ,CT,LD011,LD012,LD013,CDVXZ,CDVYZ,
 *CDVZZ,LDI25,LDI26,LDI31,LC1,LC1J)
 GO TO 2
 241 IF(CDTW=CTW) 243,242,242
 242 CDTW=-1.
 GO TO 246
 243 IF(RDGD) 2,244, 2
 244 LC7=4095
 245 CTLRP=CT
 CRR=CRRG
 CSAPR=CSAPG
 CSRPR=CSRPG
 229 IF(LC4D) 246,509,246
 246 CTX=CTX+CDTX
 GO TO 301
 247 CTW=20.
 CDTX=20.
 248 IF (LC2) 259,249,259
 249 IF(CT-(CTM+150.)) 250,251,251
 250 IF (CT-CTDV) 512,510,510
 251 IF(CTX-150.) 252,253,253
 252 CTD=200.
 GO TO 331
 253 IF (CTX-330.) 254,255,255
 254 CTHBC=CTHBM
 CPSIBC=CPSIBM
 GO TO 238
 255 LC2=4095
 256 LD005=0
 257 CPSIBC=0.
 CTHBC=0.
 258 CX=CXM
 CY=CYM
 CZ=CZM
 GO TO 2
 259 CDTW=CT-(CTM+CDTM)
 IF (CDTW) 260,241,241
 260 IF(CDTW+80.) 240,261,261
 261 IF(LC8) 262,263,262
 262 CTO=CDTM-80.
 LC8=0
 GO TO 331
 263 LD005=4095
 GO TO 2
 301 CSPSIR=-CSRPR
 CTHR=(CSAPR)/SQRTF(1.-CSRPR**2)
 302 CCPSIR=SQRTF(1.-CSPSIR**2)
 CCTHR=SQRTF(1.-CTHR**2)
 303 CM1=CCPSIR*CTHR
 304 CM3=(CM1*CA11)+(CSPSIR*CA21)+(CSAPR*CA31)
 CM4=-(CM1*CA13)-(CSPSIR*CA23)-(CSAPR*CA33)

$CM5 = (CM1*CA12) + (CSPSIR*CA22) + (CSAPR*CA32)$
 $CM6 = CRR * (1. - CM5**2) / (2.*CSRT -)$
 305 CX=CRR*CM3
 $CY = CRR * (CM5 - CM6)$
 $CZ=CRR*CM4$
 306 IF (CDTW) 311,307,307
 307 CTHBM=6.28318530-ATN1F(CY,CX)
 $CPSBCP=6.28318530-ATN1F(-CZ,CX)$
 $CPSIBM=6.28318530-ATN1F(-CZ,SQRTF(CX**2+CY**2))$
 $CTHBCP=6.28318530-ATN1F(CY,SQRTF(CX**2+CZ**2))$
 308 IF (CTHBCP=3.14159265) 311,309,309
 309 CTHBCP=CTHBCP-6.28318530
 311 IF (3.14159265/6.+.05-CWTPR) 313,312,312
 312 IF (LC3) 315,313,315
 313 IF (LC7) 316,314,316
 314 LC7=4095
 315 CTHBC=CTHBM
 $CPSIBC=CPSIBM$
 GO TO 2
 316 IF (IC) 318,317,318
 317 IC=10
 GO TO 319
 318 IC=IC-1
 319 CXT(IC+1)=CX
 $CYT(IC+1)=CY$
 $CZT(IC+1)=CZ$
 $CDTWT(IC+1)=CDTW$
 $CDTWX=CDTW$
 320 CRS=CSRT +CY
 $COMGS=SQRTF(1.407654E+16/CRS**3)$
 321 IF (LC2) 322,325,322
 322 CWTPR=CWTPR-CDEL
 323 IF (CDTW) 444,324,324
 324 KC=0
 $CSTD=CDTM-200.$
 GO TO 401
 325 IF (LC3) 2,326,2
 326 IF (CTX-.750.) 2,327,327
 327 CSTD=1000.
 328 IF (CDTWX) 2,329,329
 329 KC=IC
 GO TO 401
 330 CTD=250.
 331 CWSTD=COMGS*CTD
 $CSWSTD=SINF(CWSTD)$
 $CCWSTD=COSF(CWSTD)$
 332 CH27=1./COMGS
 $CH28=2./COMGS$
 $CH29=4./COMGS$
 $CX=CX+CH28*CYRD-3.* (CXRD-2.*COMGS*CY)*CTD+(CH29*CXRD-6.*CY)*CSWSTD$
 $*-CH28*CYRD*CCWSTD$
 $CY=4.*CY-CH28*CXRD+(CH28*CXRD-3.*CY)*CCWSTD+CH27*CYRD*CSWSTD$
 $CZ=CZ*CCWSTD+CH27*CZRD*CSWSTD$
 GO TO 334
 333 LC7=0
 $LC3=4095$

334 CSTD=1000+CTD
335 IF (CTX=150.) 336,337,337
336 CTX=200.
GO TO 338
337 IF (LC2) 338,328,338
338 LC7=0
GO TO 307
401 LC1=4095
CWSTDL=CWTTPR
CXM=CX
CYM=CY
CZM=CZ
402 CSWTDL=SINF(CWSTDL)
CCWTDL=COSF(CWSTDL)
COEFF=COMGS/(3.*CWSTDL*CSWTDL-8.*(1.-CCWTDL))
403 CCK1=COEFF*CSWTDL
CCK3=COEFF*2.*(1.-CCWTDL)
CCK2=2.*COMGS+CCK3
404 CCKF=COEFF*(4.*CSWTDL-3.*CWSTDL*CCWTDL)
CCKG=COMGS*CCWTDL/CSWTDL
405 IF (LC8) 408,406,408
406 LC8=4095
407 CCK4=CCKF
CCK5=CCKG
CCWTDL=1.
GO TO 404
408 LC8=0
409 IF (LC1) 410,421,410
410 LC1=0
411 CDXF0=CCK1*CX+CCK3*CY
CDYFD=-CCK3*CX+CCKF*CY
CDZFD=-CCKG*CZ
CDVF=SQRTF(CDXFD**2+CDYFD**2+CDZFD**2)
412 CXSD=0.
CYSD=0.
CZSD=0.
CNS=0.
413 KC0=7
414 CXRD=CCK1*CX+CCK2*CY
CYRD=CCK3*CX+CCK4*CY
CZRD=-CCK5*CZ
415 IF (KC) 417,416,417
416 KC=10
GO TO 418
417 KC=KC-1
418 CXZ=XT(KC+1)
CYZ=YT(KC+1)
CZZ=ZT(KC+1)
419 IF (CDTWT(KC+1)) 424,420,420
420 CSTD=CSTD-(CDTWT(KC+1)-CDTWX)
CWSTDL=CSTD*COMGS
GO TO 402
421 CXTD=(CXZ-CX)*CCK1+CYZ*CCK3+CY*CCK2
CYTD=(CX-CXZ)*CCK3+CYZ*CCKF-CY*CCK4
CZTD=CZ*CCK5-CZZ*CCKG
422 CXSD=CXSD+CXTD-CXRD

CYSD=CYSD+CYTD-CYRD
CZSD=CZSD+CZRD-CZTD
CNS=CNS+1.
423 CDXD=CXSD/CNS
CDYD=CYSD/CNS
CDZD=CZSD/CNS
424 K2C=K2C-1
IF (K2C) 425,427,425
425 CSTD=CSTD-CDTX
GO TO 2
427 IF (LC2) 443,428,443
428 IF (CNS) 430,429,430
429 CDVT=0.
GO TO 435
430 CDVI=SQRTF(CDXD**2+CDYD**2+CDZD**2)
431 CDVT =CDVI+CDVF
433 IF (CDVT-999.) 435,434,434
434 CDV=999.
GO TO 436
435 CDV=INTF(CDVT)
436 IF (LC7) 437,439,437
437 LC7=0
438 CXRD=CXRD+CDXD
CYRD=CYRD+CDYD
CZRD=CZRD-CDZD
GO TO 330
439 LC7=4095
440 IF (LC3) 501,441,501
441 CDVXSP=CDV
442 CDVXZ=CDV
GO TO 2
443 IF (CNS) 445,444,445
444 CDXD=0.
CDYD=0.
CDZD=0.
445 LC2=0
446 IC=0
447 CTM=CTM+CDTM
448 IF (3.14159265/2.+.05-CWTPR) 449,2,2
449 CDZD=0.
GO TO 2
501 IC=0
502 CTM=CTLRP+CTD
503 CTDV=CTM-CDVI/(2.*CATXBA)
504 CPSIBC=6.28318530-ATN1F(CDZD,SQRTF(CDXD**2+CDYD**2))
CPSBCP=6.28318530-ATN1F(CDZD,CDXD)
505 CTHBC=6.28318530-ATN1F(CDYD,CDXD)
CTHBCP=6.28318530-ATN1F(CDYD,SQRTF(CDXD**2+CDZD**2))
506 IF (CTHBCP-3.14159265) 508,507,507
507 CTHBCP=CTHBCP-6.28318530
508 IF (LC4B) 124,2,124
509 IF (LDI21) 510,504,510
510 LD005=4095
512 CALL ALIGNP (CFX,CFY,CFZ,FXP,FYP,FZP,AKX1,AKX2,AKX3,AKX4,AKY1,
*AKY2,AKY3,AKY4,AKZ1,AKZ2,AKZ3,AKZ4,DT)
513 CDVXM=CDVXM+CFX

CDVYM=CDVYM+CFY
CDVZM=CDVZM+CFZ
514 IF (LC8)=517,515,517
515 LC8=4095
516 CDVXM==CDXD
CDVYM==CDYD
CDVZM==CDZD
517 CDVXB== (CA11*CDVXM+CA12*CDVYM+CA13*CDVZM)
CDVYB== (CA21*CDVXM+CA22*CDVYM+CA23*CDVZM)
CDVZB== (CA31*CDVXM+CA32*CDVYM+CA33*CDVZM)
519 IF(LCA)=520,521,520
520 LC1J=-4095
521 CTX=100.
522 CALL IVIDS (CDVXS,CDVXB,CDVXZ,CDVYS,CDVYB,CDVYZ,CDVZS,CDVZB,
*CDVZZ,LDI22,LC1J,LDO12,LDO13,CDV,CDVXSP,CDVYSP,CDVZSP)
GO TO 2
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0)

RZ7M5 RENDEZVOUS FOR MODULE 5 OF MATH FLOW 7 FERNEYHOUGH, REINER

35

STORAGE NOT USED BY PROGRAM

DEC OCT
1465 02671DEC OCT
32230 76746

STORAGE LOCATIONS FOR VARIABLES APPEARING IN COMMON STATEMENTS

DEC	OCT	DEC	OCT	DEC	OCT	DEC	OCT	DEC	OCT	DEC	OCT
AKX1	32555	77453	AKX2	32554	77452	AKX3	32553	77451	AKX4	32552	77450
AKY2	32550	77446	AKY3	32549	77445	AKY4	32548	77444	AKZ1	32547	77443
AKZ3	32545	77441	AKZ4	32544	77440	ASFX	32543	77437	ASFY	32542	77436
CO1	32539	77433	CO	32540	77434	C21	32537	77431	C2	32538	77432
CA12	32535	77427	CA13	32534	77426	CA21	32533	77425	CA22	32532	77424
CA31	32530	77422	CA32	32529	77421	CA33	32528	77420	CAPTI	32526	77416
CATXBA	32525	77415	CATXB1	32524	77414	CCABI	32522	77412	CCAB	32523	77413
CCAS	32521	77411	CCK1	32519	77407	CCK2	32518	77406	CCK3	32517	77405
CCK5	32515	77403	CCKF	32514	77402	CCKG	32513	77401	CCPHB1	32512	77400
CCPSIR	32510	77376	CCRBI	32507	77373	CCR8	32508	77374	CCR1	32506	77372
CCRSI	32504	77370	CCRS	32505	77371	CCTHB	32503	77367	CCTHR	32502	77366
CCWTDL	32500	77364	CCZT	32499	77363	CDEL	32498	77362	CDPHSC	32558	77456
CDRRD	32497	77361	CDTHSC	32556	77454	CDTM	32496	77360	CDTW	32495	77357
CDTHX	32483	77343	CDTX	32482	77342	CDVF	32480	77340	CDVI	32479	77337
CDVT	32478	77336	CDVXB	32477	77335	CDVXM	32476	77334	CDVXSP	32561	77461
CDVXZ	32474	77332	CDVYB	32473	77331	CDVYM	32472	77330	CDVYSP	32560	77460
CDVYZ	32470	77326	CDVZB	32469	77325	CDVZM	32468	77324	CDVZSP	32559	77457
CDVZZ	32466	77322	CDXD	32465	77321	CDXFID	32464	77320	CDYD	32463	77317
COZO	32461	77315	COZFD	32460	77314	CFX	32459	77313	CFY	32458	77312
CMI	32456	77310	CM3	32455	77307	CM4	32454	77306	CM5	32453	77305
CNPC	32451	77303	CNS	32450	77302	CNVX	32449	77301	CNVY	32448	77300
CNYC	32446	77276	COEFF	32445	77275	COINT	32444	77274	COMGS	32443	77273
CPHIB	32442	77272	CPSBCP	32440	77270	CPSIBC	32438	77266	CPSIBM	32437	77265
CR1	32436	77264	CRA	32435	77263	CRLO	32434	77262	CRRD	32432	77260
CRRI	32430	77256	CRPPI	32429	77255	CRR	32433	77261	CRS	32428	77254
CSAPG	32426	77252	CSAPI	32425	77251	CSAPR	32424	77250	CSPHIB	32423	77247
CSPSIR	32421	77245	CSRDP1	32420	77244	CSRPG	32419	77243	CSRPI	32418	77242
CS-TI	32415	77237	CSRT	32416	77240	CSTD	32413	77235	CSTD	32414	77236
CSTHR	32411	77233	CSTZ	32410	77232	CSTWSTD	32409	77231	CSTWDL	32408	77230
CTD	32406	77226	CTDV	32404	77224	CTHBCP	32401	77221	CTHBC	32402	77222
CTH8	32403	77223	CTLRP	32399	77217	CTM	32398	77216	CTRI	32397	77215
CT	32407	77227	CTTG	32395	77213	CTW	32394	77212	CTX	32393	77211
CUDPSS	32391	77207	CUDTHS	32390	77206	CWSTD	32388	77204	CWSTD	32389	77205
CXM	32385	77201	CXRD	32384	77200	CX	32386	77202	CXSD	32383	77177
CTX	32382	77176	CXZ	32370	77162	CYM	32368	77160	CYRD	32367	77157
CYSD	32366	77156	CYT	32354	77142	CYT	32365	77155	CYZ	32353	77141
CZRD	32350	77136	CZ	32352	77140	CZSD	32349	77135	CZTD	32337	77121
CZZ	32336	77120	DELAY	32335	77117	DELVX	32561	77461	DELVY	32560	77460
DONPRT	32334	77116	DPHIB	32558	77456	DPSIB	32557	77455	DTHB	32556	77454
DUM10	32323	77103	DUM11	32322	77102	DUM12	32321	77101	DUM13	32320	77100
DUM15	32318	77076	DUM16	32317	77075	DUM17	32316	77074	DUM18	32315	77073
DUM2	32331	77113	DUM3	32330	77112	DUM4	32329	77111	DUM5	32328	77110
DUM7	32326	77106	DUM8	32325	77105	DUM9	32324	77104	FIN	32314	77072
FXPP	32311	77067	FXP	32312	77070	FYPP	32309	77065	FYP	32310	77066
FZP	32308	77064	GC	32306	77062	IC	32305	77061	IEXIT	32304	77060
IWRITE	32302	77056	K2C	32301	77055	KC	32300	77054	KWRIT	32299	77053
LC1J	32296	77050	LC1	32297	77051	LC2	32295	77047	LC3	32294	77046
LC4B	32292	77044	LC4C	32291	77043	LC4D	32290	77042	LC4E	32289	77041

R27M5 RENDEZVOUS FOR MODULE 5 OF MATH FLOW 7 FERNEYHOUGH, REINER

36

LC46 32287 77037	LC5 32286 77036	LC7 32285 77035	LC8 32284 77034	LCA 32282 77032
LCS 32281 77031	LCY 32280 77030	LDI00 32279 77027	LDI10 32278 77026	LDI11 32277 77025
LDI13 32276 77024	LDI20 32275 77023	LDI21 32274 77022	LDI22 32273 77021	LDI25 32272 77020
LDI26 32271 77017	LDI31 32270 77016	LDI001 32269 77015	LDI005 32268 77014	LDI11 32267 77013
LD012 32266 77012	LD013 32265 77011	LD062 32264 77010	LD063 32263 77007	LFDI 32262 77006
LQT 32261 77005	L 32298 77052	M 32260 77004	N 32259 77003	PHIB 32258 77002
PINT 32257 77001	PSIB 32256 77000	RDG0 32255 76777	RRDREF 32254 76776	SRAA 32253 76775
SSEA 32252 76774	SW 32251 76773	TEST 32250 76772	TFTXV 32249 76771	TFTYV 32248 76770
TFTZV 32247 76767	THETAB 32246 76766	TIME 32245 76765	TPC 32244 76764	TRI 32243 76763
TSC 32242 76762	TVX 32241 76761	TVY 32240 76760	TVZ 32239 76757	TYC 32238 76756
VLIST 32561 77461	XGRTD 32236 76754	XGRT 32237 76755	XKRDR 32235 76753	YGRTD 32233 76751
YGRT 32234 76752	ZGRD 32231 76747	ZGRT 32232 76750		

STORAGE LOCATIONS FOR VARIABLES NOT APPEARING IN COMMON, DIMENSION, OR EQUIVALENCE STATEMENT

	DEC	OCT		DEC	OCT		DEC	OCT		DEC	OCT			
CH27	1464	02670		CH28	1463	02667		CH29	1462	02666		CUREND	1461	02665
LC24A	1459	02663		LC24	1458	02662		LC29	1457	02661		DAS	1460	02664

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

1)	1448 02650	2)	1408 02600	3)	1416 02610	6)	1442 02642	C160	1455 02657
C1G1	1456 02660	D1403	34 00042	D143M	1206 02266	E1D	142 00216	E1J	261 00405
E1P	314 00472	E1J3	393 00611	E116	405 00625	E130	961 01701	E134	1040 02020
E138	1068 02054	E13C	1141 02165	E130	1228 02314	E144	1386 02552	E110F	248 00370
E139	1127 02147	E13M	1205 02265	E120E	150 00226				

LOCATIONS OF NAMES IN TRANSFER VECTOR

	DEC	OCT		DEC	OCT		DEC	OCT		DEC	OCT
ALIGNP	9 00011	ATN1	8 00010	COS	4 00004	ERRANG	2 00002	GANG	1 00001		
GEXEC	0 00000	IVIDS	10 00012	IVISZS	7 00007	SIN	3 00003	SQRT	6 00006		
WAITS	5 00005										

ENTRY POINTS TO SUBROUTINES NOT OUTPUT FROM LIBRARY

ALIGNP	ATN1	COS	ERRANG	GANG	GEXEC	IVIDS	IVISZS	SIN	SQRT		
WAITS											

EXTERNAL FORMULA NUMBERS WITH CORRESPONDING INTERNAL FORMULA NUMBERS AND OCTAL LOCATIONS

EFN	IFN	LOC	EFN	IFN	LOC	EFN	IFN	LOC	EFN	IFN	LOC
1	9 00030	101	10 00032	102	11 00036	103	13 00043	104	25 00076		
105	42 00142	106	43 00146	107	44 00150	108	46 00155	109	47 00160		
109	48 00161	110	49 00165	113	52 00172	114	54 00202	115	55 00207		
116	58 00217	124	61 00227	126	62 00243	128	63 00252	129	64 00256		
130	70 00300	132	79 00364	131	80 00371	133	81 00373	134	82 00375		
135	83 00377	136	84 00400	137	85 00402	139	86 00406	140	89 00414		
141	91 00426	142	92 00430	143	95 00435	144	96 00442	145	97 00447		
146	98 00453	202	100 00456	203	103 00464	204	104 00473	205	108 00503		
206	109 00507	207	110 00512	208	111 00515	209	112 00522	210	113 00525		
211	114 00531	212	116 00534	213	117 00543	214	118 00552	216	119 00555		
217	121 00561	218	123 00564	219	124 00566	220	125 00572	221	126 00602		
222	127 00612	223	128 00614	265	129 00616	227	131 00621	228	132 00626		

RZ7M5 RENDEZVOUS FOR MODULE 5 OF MATH FLOW 7 FERNEYHOUGH, REINER

37

230	133 00630	231	134 00634	232	135 00636	233	136 00642	234	137 00646
235	139 00651	238	140 00655	239	142 00665	240	143 00672	241	145 00713
242	146 00720	243	148 00723	244	149 00727	245	150 00731	229	154 00741
246	155 00743	247	157 00747	248	159 00753	249	160 00757	250	161 00765
251	162 00772	252	163 00776	253	165 01001	254	166 01005	255	169 01012
256	170 01014	257	171 01016	258	173 01022	259	177 01031	260	179 01041
261	180 01046	262	181 01050	263	184 01056	301	186 01061	302	188 01074
303	190 01110	304	191 01113	305	195 01167	306	198 01203	307	199 01207
308	203 01257	309	204 01264	311	205 01267	312	206 01277	313	207 01303
314	208 01307	315	209 01311	316	212 01316	317	213 01322	318	215 01327
319	216 01334	320	221 01346	321	223 01364	322	224 01366	323	225 01371
324	226 01375	325	229 01405	326	230 01411	327	231 01416	328	232 01420
329	233 01424	330	235 01431	331	236 01433	332	239 01444	333	246 01555
334	248 01561	335	249 01564	336	250 01570	337	252 01573	338	253 01575
401	255 01600	402	260 01612	403	263 01637	404	266 01655	405	268 01675
406	269 01702	407	270 01704	408	274 01713	409	275 01715	410	276 01717
411	277 01721	412	281 01760	413	285 01770	414	286 01772	415	289 02014
416	290 02021	417	292 02025	418	293 02031	419	296 02037	420	297 02043
421	300 02055	422	303 02116	423	307 02135	424	310 02150	425	312 02155
427	314 02161	428	315 02166	429	316 02172	430	318 02175	431	319 02211
433	320 02214	434	321 02221	435	323 02224	436	324 02230	437	325 02232
438	326 02234	439	330 02246	440	331 02250	441	332 02254	442	333 02256
443	335 02261	444	336 02267	445	339 02275	446	340 02277	447	341 02302
448	342 02305	449	343 02315	501	345 02320	502	346 02324	503	347 02327
504	348 02340	505	350 02364	506	352 02410	507	353 02415	508	354 02420
509	355 02424	510	356 02426	512	357 02430	513	358 02454	514	361 02465
515	362 02471	516	363 02473	517	366 02501	519	369 02545	520	370 02547
521	371 02553	522	372 02555						

```

DIMENSION SLIST(1000), TLIST(1000), DLIST(1000), ILIST(1000),
*REM(165), VLIST(1)
DIMENSION CXT(11), CYT(11), CZT(11), CDTWT(11)
DIMENSION JUMP(9), T(20), JSUB(20), SYM(20,50), ISUB(20,50), A(20,50),
*B(20,50), D(20,50), TDL(20,50)
COMMON CDVXSP, CDVYSP, CDVZSP, CDPHSC, CDPSSC, CDTHSC, AKX1 , AKX2 ,
1AKX3 , AKX4 , AKY1 , AKY2 , AKY3 , AKY4 , AKZ1 , AKZ2 , AKZ3 ,
2AKZ4 , ASFX , ASFY , ASFZ , CO , COI , C2 , C2I , CA11 ,
3CA12 , CA13 , CA21 , CA22 , CA23 , CA31 , CA32 , CA33 , CAPT ,
4CAPTI , CATXBA, CATXBI, CCAB , CCABI , CCAS , CCASI , CCK1 , CCK2 ,
5CCK3 , CCK4 , CCK5 , CCKF , CCKG , CCPHIB, CCPSIB, CCPSIR, CCR ,
6CCRB , CCRBI , CCRI , CCRS , CCRSI , CCTHB , CCTHR , CCWSTD, CCWTDL ,
7CCZT , CDEL , CDRRD , CDTM , CDTW , CDTWT , CDTWX , CDTX , CDV ,
8CDVF , CDVI , CDVT , CDVXB , CDVXM , CDVXS , CDVXZ , CDVYB , CDVYM ,
9CDVYS , CDVYZ , CDVZB , CDVZM , CDVZS , CDVZZ , CDXD , CDXF , CDYD ,
COMMON CDYFD , CDZD , CDZFD , CFX , CFY , CFZ , CM1 , CM3 ,
1CM4 , CM5 , CM6 , CNPC , CNS , CNVX , CNVY , CNVZ , CNYC ,
2COEFF , COINT , COMGS , CPHIB , CPHIBC , CPSBCP, CPSIB , CPSIBC, CPSIBM ,
3CR1 , CRA , CRLO , CRR , CRRD , CRRG , CRRI , CRRPI , CRS ,
4CSADPI , CSAPG , CSAPI , CSAPR , CSPHIB, CSPSIB, CSPSIR, CSRDP, CSRPG ,
5CSRPI , CSRPR , CSRT , CSRTI , CSTD , CSTDL , CSTHB , CSTHR , CSTZ ,
6CSWSTD, CSWTDL , CT , CTD , CTDAS , CTDV , CTHB , CTHBC , CTHBCP ,
7CTHBM , CTLRP , CTM , CTRI , CTRR , CTTG , CTW , CTX , CUDPHS ,
8CUDPSS, CUDTHS, CWSTD , CWSTDL , CWTPR , CX , CXM , CXRD , CXSD ,
9CXT , CXTD , CXZ , CY , CYM , CYRD , CYSD , CYT , CYTD ,
COMMON CYZ , CZ , CZM , CZRD , CZSD , CZA , CZTD , CZZ ,
1DELAY , DONPRT , DT , DUM1 , DUM2 , DUM3 , DUM4 , DUM5 , DUM6 ,
2DUM7 , DUM8 , DUM9 , DUM10 , DUM11 , DUM12 , DUM13 , DUM14 , DUM15 ,
3DUM16 , DUM17 , DUM18 , FIN , FP , FXP , FXPP , FYP , FYPP ,
4FZP , FZPP , GC , IC , IEXIT , IOLP , IWRITE , K2C , KC ,
5KWRITE , L , LC1 , LC1J , LC2 , LC3 , LC4A , LC4B , LC4C ,
6LC4D , LC4E , LC4F , LC4G , LC5 , LC7 , LC8 , LC10 , LCA ,
7LCS , LCY , LDI00 , LDI10 , LDI11 , LDI13 , LDI20 , LDI21 , LDI22 ,
8LDI25 , LDI26 , LDI31 , LD001 , LD005 , LD011 , LD012 , LD013 , LD062 ,
9LD063 , LF0I , LQT , M , N , PHIB , PINT , PSIB , RDGD ,
COMMON RRDREF , SRAA , SREA , SW , TEST , TFTXV , TFTYV , TFTZV ,
1THETAB , TIME , TPC , TRI , TSC , TVX , TVY , TVZ , TYC ,
2XGRT , XGRTD , XKRDR , YGRT , YGRTD , ZGRT , ZGRTD ,
EQUIVALENCE (DELVX,CDVXSP), (DELVY,CDVYSP), (DELVZ,CDVZSP), (CDPHSC,
*DPHIB), (CDPSSC,DPSIB), (CDTHSC,DTHB), (VLIST,CDVXSP)
ZZ1=CLOCKF(XX)
CALL SELFLD
KT1=5
KT2=9
KT3=6
100 READ INPUT TAPE KT1,1032, (REM(I), I=1,165)
READ INPUT TAPE KT1,1060, NUMRUN, LTOL, NST, NTOL, LSKIP
WRITE OUTPUT TAPE KT2,1061, NUMRUN, LTOL, NST, NTOL, LSKIP
NTR=1
IF ((LTOL) 200,155,200
200 IF ((LSKIP) 201,202,201
201 READ INPUT TAPE KT1,1062, (JUMP(I), I=1,9)
WRITE OUTPUT TAPE KT2,1063, (JUMP(I), I=1,9)
202 L=0
WRITE OUTPUT TAPE KT2,1064

```

```
203 L=L+1
    READ INPUT TAPE KT1,1065,T(L),JS,(SYM(L,K),ISUB(L,K),K=1,JS)
    WRITE OUTPUT TAPE KT2,1066,T(L),(SYM(L,K),ISUB(L,K),K=1,JS)
    JSUB(L)=JS
    IF (NST-L) 155,155,203
155 ZZ=CLOCKF(XX)
    DO 159 I=1,331
159 VLIST(I)=0.
    PTIME=0.
148 READ INPUT TAPE KT1,1000,NDATE1,NDATE2,NDATE3,NRUN1,NRUN2
    I=0
101 I=I+1
    READ INPUT TAPE KT1,1050,SLIST(I),TLIST(I),DLIST(I),ILIST(I)
102 IF ((ILIST(I))=103,103,101
103 J=I
104 WRITE OUTPUT TAPE KT2,1051
    DO 403 I=1,J
    WRITE OUTPUT TAPE KT2,1052,SLIST(I),TLIST(I),DLIST(I),ILIST(I)
403 CONTINUE
    WRITE OUTPUT TAPE KT2,1002,NDATE1,NDATE2,NDATE3,NRUN1,NRUN2
105 I=1
    LS=1
    IF ((LSKIP) 214,107,214
214 IF ((JUMP(NTR)) 107,107,204
204 CALL SKPN (JUMP(NTR),1,6)
107 IF ((TIME-TLIST(I)) 114,108,108
108 K=ILIST(I)
109 VLIST(K)=DLIST(I)
110 I=I+1
    GO TO 107
114 IF ((LD011) 115,122,115
115 LD011=0
    DELVX=0.
    DELVY=0.
    DELVZ=0.
122 IF ((DELVX) 123,124,123
123 LDI31=4095
    GO TO 125
124 LDI31=0
125 IF ((DELVY) 126,127,126
126 LDI25=4095
    GO TO 139
127 LDI25=0
139 IF ((DELVZ) 140,141,140
140 LDI26=4095
    GO TO 128
141 LDI26=0
128 IF ((LD005) 130,129,130
130 SENSE LIGHT 4
    GO TO 150
129 SENSE LIGHT 0
150 FXP=FXPP#DT/ASFX
    FYP=FYP#DT/ASFY
    FZP=FZPP#DT/ASFZ
    IF ((LD062) 152,151,152
151 LDI21=0
```

```

152 LD062=4095
    IF (LQT) 153,131,153
153 CALL QUANT (PHIB ,.036/57.2957795)
    CALL QUANT (THETAB ,.036/57.2957795)
    CALL QUANT (PSIB ,.036/57.2957795)
    CALL QUANT (TRI ,.49.178)
    CALL QUANT (SREA ,.42594791*.1953125E-2)
    CALL QUANT (SRAA ,.42594791*.1953125E-2)
    CALL QUANT (FXP ,.11)
    CALL QUANT (FYP ,.11)
    CALL QUANT (FZP ,.11)
131 CALL GEXECB
    IF (LQT) 154,137,154
154 IF(ABSF(DPHIB)-3./57.2957795) 410,410,411
410 ARG2=.66666667E-1/57.2957795
    GO TO 412
411 ARG2=.66666667E-1*6./57.2957795
412 CALL QUANT (DPHIB ,ARG2)
    IF(ABSF(DPSIB)-3./57.2957795) 413,413,415
413 ARG2=.66666667E-1/57.2957795
    GO TO 416
415 ARG2=.66666667E-1*6./57.2957795
416 CALL QUANT (DPSIB ,ARG2)
    IF(ABSF(DTHB )-3./57.2957795) 417,417,418
417 ARG2=.66666667E-1/57.2957795
    GO TO 419
418 ARG2=.66666667E-1*6./57.2957795
419 CALL QUANT (DTHB ,ARG2)
137 IF (KWRITE) 138,132,138
138 KWRITE=0
    GO TO 133
132 IF (IWRITE) 133,143,133
143 IF (PINT) 144,205,144
144 IF (TIME-(PTIME+DELAY)) 205,145,145
145 PTIME=PTIME+PINT
133 WRITE OUTPUT TAPE KT2,1029,TIME,NDATE1,NDATE2,NDATE3,NRUN1,NRUN2
    WRITE OUTPUT TAPE KT2,1034
    WRITE OUTPUT TAPE KT2,1030, REM( 1),CT ,REM( 2),CA11 ,
1REMI( 3),CA12 ,REM( 4),CA13 ,REM( 5),CDVT ,REM( 6),CWTPR ,
2REMI( 7),CA21 ,REM( 8),CA22 ,REM( 9),CA23 ,REM( 10),CDVI ,
3REMI( 11),CDEL ,REM( 12),CA31 ,REM( 13),CA32 ,REM( 14),CA33 ,
4REMI( 15),CDVE ,REM( 16),CTM ,REM( 17),CSPSIR,REM( 18),CFX ,
5REMI( 19),CX ,REM( 20),CDVXB ,REM( 21),CDTM ,REM( 22),CCPSIR ,
6REMI( 23),CFY ,REM( 24),CY ,REM( 25),CDVYB ,REM( 26),CTDV ,
7REMI( 27),CSTHR ,REM( 28),CFZ ,REM( 29),CZ ,REM( 30),CDVZB ,
8REMI( 31),TSC ,REM( 32),CCTHR ,REM( 33),CDVXS ,REM( 34),CXM ,
9REMI( 35),CDVXM
    WRITE OUTPUT TAPE KT2,1030, REM( 36),CTDAS ,REM( 37),CM1 ,
1REMI( 38),CDVYS ,REM( 39),CYM ,REM( 40),CDVYM ,REM( 41),CRLO ,
2REMI( 42),CM3 ,REM( 43),CDVZS ,REM( 44),CZM ,REM( 45),CDVZM ,
3REMI( 46),CPHIB ,REM( 47),CM4 ,REM( 48),CDV ,REM( 49),CXZ ,
4REMI( 50),CDXD ,REM( 51),CPSIB ,REM( 52),CM5 ,REM( 53),CSTZ ,
5REMI( 54),CYZ ,REM( 55),CDYD ,REM( 56),CTHB ,REM( 57),CM6 ,
6REMI( 58),CTD ,REM( 59),CZZ ,REM( 60),CDZD ,REM( 61),CUDPHS ,
7REMI( 62),COEFF ,REM( 63),CSTD ,REM( 64),CCRI ,REM( 65),CXTD ,
8REMI( 66),CUDPSS,REM( 67),CCK1 ,REM( 68),CSTD1,REM( 69),COI

```

```

9REM( 70),CYTD
  WRITE OUTPUT TAPE KT2,1030,      REM( 71),CUDTHS,REM( 72),CCK2
1REM( 73),CWSTD ,REM( 74),C2I ,REM( 75),CZTD ,REM( 76),CDPHSC,
2REM( 77),CCK3 ,REM( 78),CWSTDL,REM( 79),CCABI ,REM( 80),CXRD
3REM( 81),CDPSSC,REM( 82),CCK4 ,REM( 83),CNS ,REM( 84),CCASI
4REM( 85),CYRD ,REM( 86),CDTHSC,REM( 87),CCK5 ,REM( 88),CTX
5REM( 89),CCRBI ,REM( 90),CZRD ,REM( 91),CPSIBC,REM( 92),CCKF
6REM( 93),CDTX ,REM( 94),CCRSI ,REM( 95),CDXF0 ,REM( 96),CTHBC
7REM( 97),CCKG ,REM( 98),CRA ,REM( 99),CATXBI,REM(100),CDYFD
8REM(101),CPSBCP,REM(102),TEST ,REM(103),CR1 ,REM(104),CAPTI
9REM(105),CDZFD

  WRITE OUTPUT TAPE KT2,1030,      REM(106),CTHBCP,REM(107),FIN
1REM(108),CDRRD ,REM(109),CSRTI ,REM(110),CXSD ,REM(111),CPSIBM
2REM(112),FP ,REM(113),RRDREF,REM(114),CRS ,REM(115),CYSD
3REM(116),CTHBM ,REM(117),SW ,REM(118),CRRD ,REM(119),COMGS
4REM(120),CZSD ,REM(121),CRRI ,REM(122),CRRPI ,REM(123),CRRG
5REM(124),CRR ,REM(125),CDVXZ ,REM(126),CSAPI ,REM(127),CSADPI
6REM(128),CSAPG ,REM(129),CSAPR ,REM(130),CDVYZ ,REM(131),CSRPI
7REM(132),CSRDPi,REM(133),CSRPG ,REM(134),CSRPR ,REM(135),CDVZZ
8REM(136),RDGD ,REM(137),CTR1 ,REM(138),CTR1 ,REM(139),CTLRP
9REM(140),CDTW

  WRITE OUTPUT TAPE KT2,1030,      REM(141),TVX ,REM(142),TVY
1REM(143),TVZ ,REM(144),TYC ,REM(145),TPC ,REM(146),TVX ,REM(147),TVY
  WRITE OUTPUT TAPE KT2,1019,
1REM(143),TVZ ,REM(144),TYC ,REM(145),TPC
  WRITE OUTPUT TAPE KT2,1036,
1REM(148),LC10 ,REM(149),LD100 ,REM(150),IC ,REM(151),LC1J
2REM(152),LC4D ,REM(153),LCA ,REM(154),LDI21 ,REM(155),KC
3REM(156),LC2 ,REM(157),LC7 ,REM(158),LCS ,REM(159),LD005
4REM(160),K2C ,REM(161),LC3 ,REM(162),LC8 ,REM(163),N
5REM(164),M ,REM(165),L

  WRITE OUTPUT TAPE KT2,1031,(CXT(I),CYT(I),CZT(I),CDTWT(I),I=1,11)
  WRITE OUTPUT TAPE KT2,1004,CDVXSP,CDVYSP,CDVZSP
205 IF (LTOL) 206,134,206
206 IF (NST-LS) 134,207,207
207 IF ((TIME-T(LS)) 134,208,208
208 JS=JSUB(LS)
  DO 209 K=1,JS
    IS=ISUB(LS,K)
    A(LS,K)=VLIST(IS)
209 CONTINUE
  LS=LS+1
134 TIME=TIME+DT
  IF ((SENSE SWITCH 6) 142,135
142 PRINT 1053,TIME ,I
135 IF ((ILIST(I)) 210,210,107
210 DO 211 L=1,NST
    JS=JSUB(L)
211 WRITE TAPE KT3,(A(L,K),K=1,JS)
END FILE KT3
136 WRITE OUTPUT TAPE KT2,1001,NRUN1,NRUN2
  PRINT 1003,NRUN1,NRUN2
  ZZ=CLOCKF(XX)
157 IF (NUMRUN=NTR) 213,213,212
212 NTR=NTR+1
  GO TO 155

```

```

213 IF : (LTOL) 215,158,215
215 REWIND KT3
    NTR=0
    DO 216 L=1,NST
        JS=JSUB(L)
    216 READ TAPE KT3,(A(L,K),K=1,JS)
    217 CALL SKPN (1,1,6)
        DO 221 L=1,NST
            JS=JSUB(L)
    221 READ TAPE KT3,(B(L,K),K=1,JS)
        DO 222 L=1,NST
            JS=JSUB(L)
            DO 222 K=1,JS
                D(L,K)=ABSF(A(L,K)-B(L,K))
    222 TOL(L,K)=TOL(L,K)+D(L,K)
    NTR=NTR+1
    WRITE OUTPUT TAPE KT2,1067,NTR
    DO 219 L=1,NST
        JS=JSUB(L)
    219 WRITE OUTPUT TAPE KT2,1068,T(L),(SYM(L,K),D(L,K),K=1,JS)
        IF : (NTOL-NTR) 220,220,217
    220 WRITE OUTPUT TAPE KT2,1069
        DO 218 L=1,NST
            JS=JSUB(L)
    218 WRITE OUTPUT TAPE KT2,1068,T(L),(SYM(L,K),TOL(L,K),K=1,JS)
158 ZZ2=CLOCKF(XX)
    ZZ3=ZZ2-ZZ1
    PRINT 1005,ZZ3
    WRITE OUTPUT TAPE KT2,1005,ZZ3
156 CALL EXIT
1000 FORMAT (11X,I2,1X,I2,1X,I2,10X,A6,A6)
1001 FORMAT (12H END OF RUN ,A6,A6/1H1)
1002 FORMAT (6H DATE ,I2,1H/,I2,1H/,I2,10X,4HRUN ,A6,A6//)
1003 FORMAT (12H END OF RUN ,A6,A6)
1004 FORMAT (1H0,12HIVI READINGS,8X,9HAFT - FWD,13X,5HL - R,14X,
    *7HUP - DN/13X,3E20.8)
1005 FORMAT (1H0,16HTHIS PROGRAM RAN,-2PF9.2,9H MINUTES.)
1019 FORMAT (5(1H ,A6,014,3X))
1029 FORMAT (1H1,7HTIME = ,E15.8,9H SECONDS.,52X,5HDATE ,I2,1H/,I2,1H/,
    *I2,7X,4HRUN ,A6,A6//)
1030 FORMAT (5(1H ,A6,E15.8,2X))
1031 FORMAT (1H0,36H11 VALUES EACH OF X,Y,Z, AND DELTA T//(1H ,4E20.8))
1032 FORMAT (12A6)
1034 FORMAT (1H ,4HSIMULATED COMPUTER OUTPUTS ON THIS PAGE.//)
1036 FORMAT (5(1H ,A6,I6,11X))
1050 FORMAT (A6,2E15.8,I4)
1051 FORMAT (1H1,6HSYMBOL,8X,4HTIME,14X,4HDATA,10X,1HI//)
1052 FORMAT (1H ,A6,2E18.8,I6)
1053 FORMAT (1H ,6HTIME =,E15.8,6H : I =,I4)
1060 FORMAT (5(7X,I3))
1061 FORMAT (1H1,7HNUMRUN=,I3,7H LTOL=,I3,7H NST=,I3,7H NTOL=,I3,
    *7H LSKIP=,I3)
1062 FORMAT (9I3)
1063 FORMAT (1H0,8HJUMP(1)=,I3,2X,8HJUMP(2)=,I3,2X,8HJUMP(3)=,I3,2X,
    *8HJUMP(4)=,I3,2X,8HJUMP(5)=,I3,2X,8HJUMP(6)=,I3,2X,8HJUMP(7)=,I3,
    *2X,8HJUMP(8)=,I3,2X,8HJUMP(9)=,I3)

```

1064 FORMAT (1H0//11H TIME (SEC),6X,22H SYMBOLS AND SUBSCRIPTS)
1065 FORMAT (F9.0,I3,6(1X,A6,I3)/(3X,A6,I3,1X,A6,I3,1X,A6,I3,
*1X,A6,I3,1X,A6,I3))
1066 FORMAT (1H0,F12.0,9(2X,A6,I4)/(15X,A6,I4,2X,A6,I4,2X,A6,
*I4,2X,A6,I4,2X,A6,I4,2X,A6,I4,2X,A6,I4))
1067 FORMAT (1H1,29HTOLERANCES FROM TOLERANCE RUN,I3//5X,11HSAMPLE TIME
*,20X,22H SYMBOLS AND TOLERANCES)
1068 FORMAT (1H0,F16.1,6X,4(3X,A6,E15.8)/(26X,A6,E15.8,3X,A6,E15.8,3X,
*A6,E15.8,3X,A6,E15.8))
1069 FORMAT (1H1,25X,16HFFINAL TOLERANCES//5X,11HSAMPLE TIME,20X,22H SYMBOLS
*OLS AND TOLERANCES)
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0,0)

BENCH7

ENVIRONMENT FOR MATH FLOW 7

FERNEYHOUGH

44

STORAGE NOT USED BY PROGRAM

DEC OCT
12055 27427DEC OCT
32230 76746

STORAGE LOCATIONS FOR VARIABLES APPEARING IN COMMON STATEMENTS

	DEC OCT		DEC OCT		DEC OCT		DEC OCT		DEC OCT		DEC OCT			
AKX1	32555	77453	AKX2	32554	77452	AKX3	32553	77451	AKX4	32552	77450	AKY1	32551	77447
AKY2	32550	77446	AKY3	32549	77445	AKY4	32548	77444	AKZ1	32547	77443	AKZ2	32546	77442
AKZ3	32545	77441	AKZ4	32544	77440	ASFX	32543	77437	ASFY	32542	77436	ASFZ	32541	77435
CO1	32539	77433	CO	32540	77434	C2I	32537	77431	C2	32538	77432	CA11	32536	77430
CA12	32535	77427	CA13	32534	77426	CA21	32533	77425	CA22	32532	77424	CA23	32531	77423
CA31	32530	77422	CA32	32529	77421	CA33	32528	77420	CAPTI	32526	77416	CAPT	32527	77417
CATXBA	32525	77415	CATXBI	32524	77414	CCABI	32522	77412	CCAB	32523	77413	CCASI	32520	77410
CCAS	32521	77411	CCK1	32519	77407	CCK2	32518	77406	CCK3	32517	77405	CCK4	32516	77404
CCK5	32515	77403	CCKF	32514	77402	CCKG	32513	77401	CCPHIB	32512	77400	CCPS1B	32511	77377
CCPSIR	32510	77376	CCRBI	32507	77373	CCR	32508	77374	CCRBI	32506	77372	CCR	32509	77375
CCRSI	32504	77370	CCRS	32505	77371	CCTHB	32503	77367	CCTR	32502	77366	CCWSTD	32501	77365
CCWSDL	32500	77364	CCYT	32499	77363	CDEL	32498	77362	CDPHSC	32558	77456	COPSSC	32557	77455
CDRRD	32497	77361	COTHSC	32556	77454	CDTW	32496	77360	CDTW	32495	77357	CDTWT	32494	77356
CDTXW	32483	77343	CDTX	32482	77342	CDVF	32480	77340	CDVI	32479	77337	CDV	32481	77341
CDVT	32478	77336	CDVXB	32477	77335	CDVXH	32476	77334	CDVXSP	32561	77461	CDVXS	32475	77333
CDVXZ	32474	77332	CDVYB	32473	77331	CDVYM	32472	77330	CDVYSP	32560	77460	CDVYS	32471	77327
CDVYZ	32470	77326	CDVZB	32469	77325	CDVZM	32468	77324	CDVZSP	32559	77457	CDVZS	32467	77323
CDVZZ	32466	77322	CDXD	32465	77321	CDXF3D	32464	77320	CDYD	32463	77317	CDYFD	32462	77316
CDZD	32461	77315	CDZFD	32460	77314	CFX	32459	77313	CFY	32458	77312	CFZ	32457	77311
CM1	32456	77310	CM3	32455	77307	CM4	32454	77306	CM5	32453	77305	CM6	32452	77304
CNPC	32451	77303	CNS	32450	77302	CNVY	32449	77301	CNVY	32448	77300	CNVZ	32447	77277
CNYC	32446	77276	COEFF	32445	77275	COINT	32444	77274	COMGS	32443	77273	CPIIBC	32441	77271
CPHIB	32442	77272	CPSBCP	32440	77270	CPSIBC	32438	77266	CPSIBM	32437	77265	CPSIB	32439	77267
CR1	32436	77264	CRA	32435	77263	CRLO	32434	77262	CRRD	32432	77260	CRRG	32431	77257
CRRI	32430	77256	CRRP1	32429	77255	CRR	32433	77261	CRS	32428	77254	CSADPI	32427	77253
CSAPG	32426	77252	CSAPI	32425	77251	CSAPR	32424	77250	CSPHIB	32423	77247	CSPSIB	32422	77246
CSPSIR	32421	77245	CSRDP1	32420	77244	CSRPG	32419	77243	CSRPI	32418	77242	CSRPR	32417	77241
CSRTI	32415	77237	CSRT	32416	77240	CSTD	32413	77235	CSTD	32414	77236	CSTHB	32412	77234
CSTHR	32411	77233	CSTZ	32410	77232	CSWSTD	32409	77231	CSWSTD	32408	77230	CTDAS	32405	77225
CTD	32406	77226	CTDV	32404	77224	CTHBCP	32401	77221	CTHBC	32402	77222	CTHBM	32400	77220
CTHB	32403	77223	CTLRP	32399	77217	CTM	32398	77216	CTR1	32397	77215	CTR	32396	77214
CT	32407	77221	CTTG	32395	77213	CTW	32394	77212	CTX	32393	77211	CUDPHS	32392	77210
CUDPSS	32391	77207	CUDTHS	32390	77206	CWSTD	32388	77204	CWSTD	32389	77205	CWTTPR	32387	77203
CXM	32385	77201	CXRD	32384	77200	CX	32386	77202	CXSD	32383	77177	CXTD	32371	77163
CXT	32382	77176	CXZ	32370	77162	CYM	32368	77160	CYRD	32367	77157	CY	32369	77161
CYSD	32366	77156	CYTD	32354	77142	CYT	32365	77155	CYZ	32353	77141	CZM	32351	77137
CZRD	32350	77136	CZ	32352	77140	CZSD	32349	77135	CZTD	32337	77121	CZT	32348	77134
CZZ	32336	77120	DELAY	32335	77117	DELVX	32361	77461	DELVY	32560	77460	DELVZ	32559	77457
DONPRT	32334	77116	DPHIB	32558	77456	DPSIB	32557	77455	DTHB	32556	77454	DT	32333	77115
DUM10	32323	77103	DUM11	32322	77102	DUM12	32321	77101	DUM13	32320	77100	DUM14	32319	77077
DUM15	32318	77076	DUM16	32317	77075	DUM17	32316	77074	DUM18	32315	77073	DUM1	32332	77114
DUM2	32331	77113	DUM3	32330	77112	DUM4	32329	77111	DUM5	32328	77110	DUM6	32327	77107
DUM7	32326	77106	DUM8	32325	77105	DUM9	32324	77104	FIN	32314	77072	FP	32313	77071
FXPP	32311	77067	FXP	32312	77070	FYPP	32309	77065	FYP	32310	77066	FZPP	32307	77063
FZP	32308	77064	GC	32306	77062	IC	32305	77061	IEXIT	32304	77060	IDL	32303	77057
IWRITE	32302	77056	K2C	32301	77055	KC	32300	77054	KWRITE	32299	77053	LC10	32283	77033
LC1J	32296	77050	LC1	32297	77051	LC2	32295	77047	LC3	32294	77046	LC4A	32293	77045
LC4B	32292	77044	LC4C	32291	77043	LC4D	32290	77042	LC4E	32289	77041	LC4F	32288	77040

BENCH7 ENVIRONMENT FOR MATH FLOW 7 FERNEYHOUGH 45

LC4G 32287 77037	LC5 32286 77036	LC7 32285 77035	LC8 32284 77034	LCA 32282 77032
LCS 32281 77031	LCY 32280 77030	LD100 32279 77027	LDI10 32278 77026	LDIII 32277 77025
LDI13 32276 77024	LDI20 32275 77023	LDI21 32274 77022	LDI22 32273 77021	LDI25 32272 77020
LDI26 32271 77017	LDI31 32270 77016	LDO01 32269 77015	LDO05 32268 77014	LDO11 32267 77013
LDO12 32266 77012	LDO13 32265 77011	LDO62 32264 77010	LDO63 32263 77007	LFDI 32262 77006
LOT 32261 77005	L 32298 77052	M 32260 77004	N 32259 77003	PHIB 32258 77002
PINT 32257 77001	PSIB 32256 77000	RDGD 32255 76777	RRDREF 32254 76776	SRAA 32253 76775
SEA 32252 76774	SW 32251 76773	TEST 32250 76772	TFTXV 32249 76771	TFTYY 32248 76770
TFTZV 32247 76767	THETAB 32246 76766	TIME 32245 76765	TPC 32244 76764	TRI 32243 76763
TSC 32242 76762	TVX 32241 76761	TVY 32240 76760	TVZ 32239 76757	TYC 32238 76756
VLIST 32251 77461	XGRTD 32236 76754	XGRT 32237 76755	XKRDR 32235 76753	YGRTD 32233 76751
YGRT 32234 76752	ZGRTD 32231 76747	ZGRT 32232 76750		

STORAGE LOCATIONS FOR VARIABLES APPEARING IN DIMENSION AND EQUIVALENCE STATEMENTS

	DEC OCT	DEC OCT	DEC OCT	DEC OCT	DEC OCT
A	5840 13320	B 4840 11350	DLIST 10054 23506	D 3840 07400	I LIST 9054 21536
ISUB	6840 15270	JSUB 7860 17264	JUMP 7889 17321	REM 8054 17566	S LIST 12054 27426
SYM	7840 17240	TLIST 11054 25456	TOL 2840 05430	T 7880 17310	

STORAGE LOCATIONS FOR VARIABLES NOT APPEARING IN COMMON, DIMENSION, OR EQUIVALENCE STATEMENT

ARG2 1840 03460	I 1839 03457	IS 1838 03456	J 1837 03455	JS 1836 03454
K 1835 03453	KT1 1834 03452	KT2 1833 03451	KT3 1832 03450	LSKIP 1831 03447
LS 1830 03446	LTOL 1829 03445	NDATE1 1828 03444	NDATE2 1827 03443	NDATE3 1826 03442
NRUN1 1825 03441	NRUN2 1824 03440	NST 1823 03437	NTOL 1822 03436	NTR 1821 03435
NUMRUN 1820 03434	PTIME 1819 03433	XX 1818 03432	ZZ1 1817 03431	ZZ2 1816 03430
ZZ3 1815 03427	ZZ 1814 03426			

SYMBOLS AND LOCATIONS FOR SOURCE PROGRAM FORMAT STATEMENTS

E FN LOC				
8)VB 1000 03413	8)V9 1001 03405	8)VA 1002 03400	8)VB 1003 03370	8)VC 1004 03364
8)VD 1005 03346	8)VR 1019 03336	8)105 1029 03332	8)106 1030 03314	8)107 1031 03310
8)108 1032 03276	8)10A 1034 03274	8)10C 1036 03263	8)10Q 1050 03257	8)10R 1051 03254
8)10S 1052 03244	8)10T 1053 03240	8)114 1060 03232	8)115 1061 03230	8)116 1062 03213
8)117 1063 03212	8)118 1064 03157	8)119 1065 03146	8)11A 1066 03127	8)11B 1067 03104
8)11C 1068 03064	8)11D 1069 03046			

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

DEC OCT	DEC OCT	DEC OCT	DEC OCT	DEC OCT
1) 1804 03414	2) 1539 03003	3) 1545 03011	4) 32767 77777	6) 1555 03023
C)GO 1806 03416	C)G1 1807 03417	C)G2 1808 03420	C)G3 1809 03421	C)G5 1810 03422
C)G6 1811 03423	C)101 1812 03424	C)202 1813 03425	D)10F 153 00231	D)200 267 00413
D)226 1282 02402	D)424 1266 02362	D)428 1295 02417	D)524 1265 02361	D)600 266 00412
D)700 265 00411	E)9 98 00142	E)F 155 00233	E)J 185 00271	E)R 286 00436
E)T 297 00451	E)11 308 00464	E)14 316 00474	E)17 323 00503	E)19 341 00525
E)18 348 00534	E)1D 406 00626	E)1P 475 00733		

LOCATIONS OF NAMES IN TRANSFER VECTOR

BENCH7 ENVIRONMENT FOR MATH FLOW 7 FERNEYHOUGH

46

	DEC	OCT		DEC	OCT		DEC	OCT		DEC	OCT		DEC	OCT
CLOCK	1 00001		EXIT	17 00021		GEXECB	9 00011		QUANT	8 00010		SELFLD	2 00002	
SKPN	7 00007	(EFT)		13 00015	(FIL)		6 00006	(FPT)		0 00000	(RLR)	16 00020		
(RTN)	4 00004	(RWT)		14 00016	(SPH)		10 00012	(STB)		11 00013	(STH)	5 00005		
(TSB)	15 00017	(TSH)		3 00003	(WLR)		12 00014							

ENTRY POINTS TO SUBROUTINES NOT OUTPUT FROM LIBRARY

CLOCK (RTN)	EXIT (RWT)	GEXECB (SPH)	QUANT (STB)	SELFLD (STH)	SKPN (TSB)	(EFT) (TSH)	(FIL) (MLR)	(FPT)	(RLR)
----------------	---------------	-----------------	----------------	-----------------	---------------	----------------	----------------	-------	-------

EXTERNAL FORMULA NUMBERS WITH CORRESPONDING INTERNAL FORMULA NUMBERS AND OCTAL LOCATIONS

EFN	IFN	LOC											
100	42 00042		200	53 00115		201	54 00117		202	64 00143		203	66 00152
155	81 00235		159	83 00241		148	85 00247		101	88 00272		102	91 00312
103	92 00315		104	93 00317		403	97 00342		105	100 00362		214	103 00374
204	104 00400		107	106 00414		108	107 00421		109	108 00425		110	109 00427
114	111 00434		115	112 00437		122	116 00447		123	117 00452		124	119 00455
125	120 00457		126	121 00461		127	123 00465		139	124 00467		140	125 00471
141	127 00475		128	128 00477		130	129 00501		129	131 00504		150	132 00505
151	136 00526		152	137 00530		153	139 00535		131	148 00621		154	150 00627
410	151 00637		411	153 00643		412	154 00647		413	156 00664		415	158 00670
416	159 00674		417	161 00711		418	163 00715		419	164 00721		137	165 00726
138	166 00730		132	168 00734		143	169 00740		144	170 00742		145	171 00751
133	172 00754		205	196 02335		206	197 02337		207	198 02344		208	199 02351
209	203 02371		134	205 02403		142	207 02410		135	209 02420		210	210 02423
211	212 02432		136	218 02457		157	223 02501		212	224 02506		213	226 02514
215	227 02516		216	231 02534		217	236 02553		221	239 02567		222	248 02626
219	254 02661		220	261 02711		218	264 02724		158	270 02750		156	276 02771

```

SUBROUTINE GEXECB
DIMENSION CXT(11),CYT(11),CZT(11),CDTWT(11)
COMMON CDVXSP,CDVYSP,CDVZSP,CDPHSC,COPSSC,CDTHSC,AKX1,AKX2
1AKX3,AKX4,AKY1,AKY2,AKY3,AKY4,AKZ1,AKZ2,AKZ3
2AKZ4,ASFX,ASFY,ASFZ,CO,COI,C2,C2I,CA11
3CA12,CA13,CA21,CA22,CA23,CA31,CA32,CA33,CAPT
4CAPTI,CATXBA,CATXBI,CCAB,CCABI,CCAS,CCASI,CCK1,CCK2
5CCK3,CCK4,CCK5,CCKF,CCKG,CCPHIB,CCPSIB,CCPSIR,CCR
6CCRB,CCRBI,CCRI,CCRS,CCRSE,CCTHB,CCTR,CCTHR,CCWSTD,CCWTDL
7CCZT,CDEL,CDRRD,CDTM,CDTW,CDTWT,CDTX,CDV
8CDVFT,CDVI,CDVT,CDVXB,CDVXM,CDVXS,CDVXZ,CDVYB,CDVYM
9CDVYS,CDVYZ,CDVZB,CDVZM,CDVZS,CDVZZ,CDXD,CDXF,D,CDYD
COMMON CDYFD,CDZD,CDZFD,CFX,CFY,CFZ,CM1,CM3
1CM4,CM5,CM6,CNPC,CNS,CNVX,CNVY,CNVZ,CNYC
2COEFF,COINT,COMGS,CYPHIB,CYPHIBC,CPSBCP,CPSIB,CPSIBC,CPSIBM
3CR1,CRA,CRL0,CRR,CRRD,CRRG,CRRPI,CRRPI,CRS
4CSADPI,CSAPG,CSAPI,CSAPR,CSPHIB,CSPSIB,CSPSIR,CSRDP,CSRPG
5CSRPI,CSRPR,CSRT,CSRFI,CSTD,CSTDL,CSTHB,CSTHR,CSTZ
6CSWSTD,CSWTDL,CT,CTD,CTDAS,CTDV,CTHB,CTHBC,CTHBCP
7CTHBM,CTRLP,CTM,CTR1,CTRR,CTTG,CTW,CTX,CUDPHS
8CUDPSS,CUDTHS,CWSTD,CWSTDLC,WTTPR,CX,CXM,CXRD,CXSD
9CXT,CXTD,CXZ,CY,CYM,CYRD,CYSD,CYT,CYTD
COMMON CYZ,CZ,CZM,CZRD,CZSD,CZT,CZTD,CZZ
1DELAY,DONPRT,DT,DUM1,DUM2,DUM3,DUM4,DUM5,DUM6
2DUM7,DUM8,DUM9,DUM10,DUM11,DUM12,DUM13,DUM14,DUM15
3DUM16,DUM17,DUM18,FIN,FP,FXP,FXPP,FYP,FYPP
4FZP,FZPP,GC,IC,IEXIT,IOLP,IWRITE,K2C,KC
5KWRITE,L,LC1,LC1J,LC2,LC3,LC4A,LC4B,LC4C
6LC4D,LC4E,LC4F,LC4G,LC5,LC7,LC8,LC10,LC1A
7LCS,LCY,LDI00,LDI10,LDI11,LDI13,LDI20,LDI21,LDI22
8LDI25,LDI26,LDI31,LD001,LD005,LD011,LD012,LD013,LD062
9LD063,LFDI,LQT,M,N,PHIB,PINT,PSIB,RDGD
COMMON RRDREF,SRAA,SREA,SW,TEST,TFTXV,TFTYV,TFTZV
1THETAB,TIME,TPC,TRI,TSC,TVX,TVY,TVZ,TYC
2XGRT,XGRTD,XKRDR,YGRT,YGRTD,ZGRT,ZGRTD
EQUIVALENCE (DELVX,CDVXSP),(DELVY,CDVYSP),(DELVZ,CDVZSP),(CDPHSC,
*DPHIB),(CDPSSC,DPSIB),(CDTHSC,DTHB),(VLIST,CDVXSP)
IF(LCX) 8,101,8
101 LC4A=0
LC4B=0
LC4C=0
LC4D=0
LC4G=0
LCY=0
LCX=4095
8 IF(LCY) 105,102,105
102 LD062=0
LD005=0
CT=0.
LCY=4095
105 CALL GONOGO
103 CT=CT+DT
111 IF(LDI32) 112,1016,112
112 CALL AGE
1016 IF(LDI11) 1025,1020,1025

```

1020 IF ((LDI10) 1021,1023,1021
1023 LC4A=0
LC4B=0
LC4C=0
LC4D=0
LC4G=0
TEST=0.
LCY=0
RETURN
1021 IF ((LDI13) 7,6,7
6 CALL ASCENT (LC4A,LC4B,LC4C,LC4D,LC4E,LC4G,LCY)
RETURN
7 CALL RNDZ
RETURN
1025 IF ((LDI10) 1032,1019,1032
1032 LC4A=0
LC4B=0
LC4C=0
LC4D=0
LC4G=0
LD005=0
RETURN
1019 IF ((LDI13) 5,4,5
4 CALL RNDZ
RETURN
5 CALL REENT (LC4A,LC4B,LC4C,LC4D,LC4E,LC4G,LCY)
RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0)

EXECB7 EXECUTOR FOR MATH FLOW 7 BENCH FERNEYHOUGH

49

STORAGE NOT USED BY PROGRAM

DEC OCT
148 00224

DEC OCT
32230 76746

STORAGE LOCATIONS FOR VARIABLES APPEARING IN COMMON STATEMENTS

AKX1 32555 77453	AKX2 32554 77452	AKX3 32553 77451	AKX4 32552 77450	AKY1 32551 77447
AKY2 32550 77446	AKY3 32549 77445	AKY4 32548 77444	AKZ1 32547 77443	AKZ2 32546 77442
AKZ3 32545 77441	AKZ4 32544 77440	ASFX 32543 77437	ASFY 32542 77436	ASFZ 32541 77435
COI 32539 77433	CO 32540 77434	C21 32537 77431	C2 32538 77432	CA11 32536 77430
CA12 32535 77427	CA13 32534 77426	CA21 32533 77425	CA22 32532 77424	CA23 32531 77423
CA31 32530 77422	CA32 32529 77421	CA33 32528 77420	CAPTI 32526 77416	CAPT 32527 77417
CATXBA 32525 77415	CATXBI 32524 77414	CCABI 32522 77412	CCAB 32523 77413	CCASI 32520 77410
CCAS 32521 77411	CCK1 32519 77407	CCK2 32518 77406	CCK3 32517 77405	CCK4 32516 77404
CCK5 32515 77403	CCKF 32514 77402	CCKG 32513 77401	CCPHIB 32512 77400	CCPSIB 32511 77377
CCPSIR 32510 77376	CCRBI 32507 77373	CCR8 32508 77374	CCRI 32506 77372	CCR 32509 77375
CCR SI 32504 77370	CCRS 32505 77371	CCTHB 32503 77367	CCTR 32502 77366	CCWSTD 32501 77365
CCW TDL 32500 77364	CCZT 32499 77363	CDEL 32498 77362	CDPHSC 32558 77456	CDPSSC 32557 77455
CDRRD 32497 77361	CDTHSC 32556 77454	CDTM 32496 77360	CDTW 32495 77357	CDTHT 32494 77356
CDT WX 32483 77343	COTX 32482 77342	CDV F 32480 77340	CDVI 32479 77337	CDV 32481 77341
CDVT 32478 77336	CDVXB 32477 77335	CDVXM 32476 77334	CDVXSP 32561 77461	CDVXS 32475 77333
CDV XZ 32474 77332	CDVYB 32473 77331	CDVYM 32472 77330	CDVYSP 32560 77460	CDVYS 32471 77327
CDV YZ 32470 77326	CDVZB 32469 77325	CDVZM 32468 77324	CDVZSP 32559 77457	CDVZS 32467 77329
CDV ZZ 32466 77322	CDXD 32465 77321	CDXFD 32464 77320	CDYD 32463 77317	CDYFD 32462 77316
CDZD 32461 77315	CDZFD 32460 77314	CFX 32459 77313	CFY 32458 77312	CFZ 32457 77311
CM1 32456 77310	CM3 32455 77307	CM4 32454 77306	CM5 32453 77305	CM6 32452 77304
CNPC 32451 77303	CNS 32450 77302	CNVX 32449 77301	CNVY 32448 77300	CNVZ 32447 77277
CNYC 32446 77276	COEFF 32445 77275	COINT 32444 77274	COMGS 32443 77273	CPHIBC 32441 77271
CPHIB 32442 77272	CPSBCP 32440 77270	CPSIB 32438 77266	CPSIBM 32437 77265	CPSIB 32439 77267
CR1 32436 77264	CRA 32435 77263	CRLO 32434 77262	CRRD 32432 77260	CRRG 32431 77257
CRRI 32430 77256	CRRPI 32429 77255	CRR 32433 77261	CRS 32428 77254	CSADPI 32427 77253
CSAPG 32426 77252	CSAPI 32425 77251	CSAPR 32424 77250	CSPHIB 32423 77247	CSPSIB 32422 77246
CSPSIR 32421 77245	CSRDP 32420 77244	CSRPG 32419 77243	CSRPI 32418 77242	CSRPR 32417 77241
CSRTI 32415 77237	CSRT 32416 77240	CSTD 32413 77235	CSTD 32414 77236	CSTHB 32412 77234
CSTRH 32411 77233	CSTZ 32410 77232	CSWSTD 32409 77231	CSWTDL 32408 77230	CTDAS 32405 77225
CTD 32406 77226	CTDV 32404 77224	CTHBPC 32401 77221	CTHBC 32402 77222	CTHBM 32400 77220
CTHB 32403 77223	CTLRP 32399 77217	CTM 32398 77216	CTR1 32397 77215	CTR2 32396 77214
CT 32407 77227	CTTG 32395 77213	CTW 32394 77212	CTX 32393 77211	CUDPHS 32392 77210
CUDPSS 32391 77207	CUDTHS 32390 77206	CWSTD 32388 77204	CWSTD 32389 77205	CWTTPR 32387 77203
CXM 32385 77201	CXR D 32384 77200	CX 32386 77202	CXSD 32383 77177	CXTD 32371 77163
CXT 32382 77176	CXZ 32370 77162	CYM 32368 77160	CYRD 32367 77157	CY 32369 77161
CYSO 32366 77156	CYT 32354 77142	CYT 32365 77155	CYZ 32353 77141	CZM 32351 77137
CZRD 32350 77136	CZ 32352 77140	CZSD 32349 77135	CZTD 32337 77121	CZT 32348 77134
CZZ 32336 77120	DELAY 32335 77117	DELVX 32561 77461	DELVY 32560 77460	DELVZ 32559 77457
DONPRT 32334 77116	DPHIB 32558 77456	DPSIB 32557 77455	DTHB 32556 77454	DT 32333 77115
DUM10 32323 77103	DUM11 32322 77102	DUM12 32321 77101	DUM13 32320 77100	DUM14 32319 77077
DUM15 32318 77076	DUM16 32317 77075	DUM17 32316 77074	DUM18 32315 77073	DUM1 32332 77114
DUM2 32331 77113	DUM3 32330 77112	DUM4 32329 77111	DUM5 32328 77110	DUM6 32327 77107
DUM7 32326 77106	DUM8 32325 77105	DUM9 32324 77104	FIN 32314 77072	FP 32313 77071
FXPP 32311 77067	FXP 32312 77070	FYPP 32309 77065	FYP 32310 77066	FZPP 32307 77063
FZP 32308 77064	GC 32306 77062	IC 32305 77061	IEXIT 32304 77060	IOLP 32303 77057
IWRITE 32302 77056	K2C 32301 77055	KC 32300 77054	KWRITE 32299 77053	LC10 32283 77033
LC1J 32296 77050	LC1 32297 77051	LC2 32295 77047	LC3 32294 77046	LC4A 32293 77045
LC4B 32292 77044	LC4C 32291 77043	LC4D 32290 77042	LC4E 32289 77040	LC4F 32288 77040

EXECB7 EXECUTOR FOR MATH FLOW 7 BENCH FERNEYHOUGH

50

LC4G 32287 77037	LC5 32286 77036	LC7 32285 77035	LC8 32284 77034	LCA 32282 77032
LCS 32281 77031	LCY 32280 77030	LDI00 32279 77027	LDI10 32278 77026	LDI11 32277 77025
LDI13 32276 77024	LDI20 32275 77023	LDI21 32274 77022	LDI22 32273 77021	LDI25 32272 77020
LDI26 32271 77017	LDI31 32270 77016	LD001 32269 77015	LD005 32268 77014	LD011 32267 77013
LD012 32266 77012	LD013 32265 77011	LD062 32264 77010	LD063 32263 77007	LDI 32262 77006
LQT 32261 77005	L 32298 77052	M 32260 77004	N 32259 77003	PHIB 32258 77002
PINT 32257 77001	PSIB 32256 77000	RDGD 32255 76777	RRDREF 32254 76776	SRAA 32253 76775
SREA 32252 76774	SW 32251 76773	TEST 32250 76772	TFTXV 32249 76771	TFTYV 32248 76770
TFTZV 32247 76767	THETAB 32246 76766	TIME 32245 76765	TPC 32244 76764	TRI 32243 76763
TSC 32242 76762	TVX 32241 76761	TVY 32240 76760	TVZ 32239 76757	TYC 32238 76756
VLIST 32251 77461	XGRTD 32236 76754	XGRT 32237 76755	XKRDR 32235 76753	YGRTD 32233 76751
YGRT 32234 76752	ZGRTD 32231 76747	ZGRT 32232 76750		

STORAGE LOCATIONS FOR VARIABLES NOT APPEARING IN COMMON, DIMENSION, OR EQUIVALENCE STATEMENT

LCX	DEC	OCT	LDI32	DEC	OCT	DEC	OCT	DEC	OCT
	147	00223		146	00222				

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

21	DEC	OCT	31	DEC	OCT	61	DEC	OCT	DEC	OCT
	137	00211		139	00213		140	00214		

LOCATIONS OF NAMES IN TRANSFER VECTOR

AGE	DEC	OCT	ASCENT	DEC	OCT	GONO GO	DEC	OCT	REENT	DEC	OCT	RNDZ	DEC	OCT
	1	00001		2	00002		0	00000		4	00004		3	00003

ENTRY POINTS TO SUBROUTINES NOT OUTPUT FROM LIBRARY

AGE	ASCENT	GONO GO	REENT	RNDZ
-----	--------	---------	-------	------

EXTERNAL FORMULA NUMBERS WITH CORRESPONDING INTERNAL FORMULA NUMBERS AND OCTAL LOCATIONS

EFN	IFN	LOC	EFN	IFN	LOC	EFN	IFN	LOC	EFN	IFN	LOC
101	10	00022	8	17	00040	102	18	00044	105	22	00054
111	24	00060	112	25	00062	1016	26	00063	1020	27	00067
1021	37	00115	6	38	00121	7	41	00135	1025	44	00142
1019	53	00164	4	54	00170	5	57	00175	1032	45	00144

BINARY CARD NO. KEYS0000
00000

ENTRY KEYS

BINARY CARD NO. KEYS0001

00000	0500	00	0	00014	KEYS	CLA	=043000000
00001	0402	60	4	00001		SUB	1,4
00002	0771	00	0	00022		ARS	18
00003	0621	00	0	00006		STA	LOC1
00004	0760	00	0	00004		ENK	**
00005	-0130	00	0	00000		XCL	**
00006	0771	00	0	00000	LOC1	ARS	**
00007	-0320	00	0	00013		ANA	=01
00010	0767	00	0	00022		ALS	18
00011	0601	60	4	00002		STO	2,4
00012	0020	00	4	00003		TRA	3,4
						END	

LITERALS

00013 000000000001
00014 000043000000

POST PROCESSOR ASSEMBLY DATA

15 IS THE FIRST LOCATION NOT USED BY THIS PROGRAM.

REFERENCES TO DEFINED SYMBOLS

0	KEYS	0
6	LOC1	3

NO ERROR IN ABOVE ASSEMBLY.

SUBROUTINE QUANT (A,B)
C ARGUMENT A IS THE FLOATING POINT VARIABLE TO BE QUANTIZED.
C ARGUMENT B IS THE VALUE OF THE LOW ORDER BIT.
1 IF (A) 2,5,3
2 A=A-B*.5
1 GO TO 4
3 A=A+B*.5
4 A=B*INTF(A/B)
5 RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0)

QUANT

54

STORAGE NOT USED BY PROGRAM

DEC OCT
57 00071
32561 77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

1) DEC OCT 3) DEC OCT 6) DEC OCT DEC OCT DEC OCT
1) 55 00067 3) 48 00060 6) 49 00061

EXTERNAL FORMULA NUMBERS WITH CORRESPONDING INTERNAL FORMULA NUMBERS AND OCTAL LOCATIONS

EFN	IFN	LOC												
1	3	00026	2	4	00031	3	6	00037	4	7	00043	5	8	00054

BINARY CARD NO. DSBENB00

00000	ENTRY	DSB
00002	ENTRY	ENB

BINARY CARD NO. DSBENB01

00000	0564 00 0 00010	DSB	ENB	=00
00001	0020 00 4 00001		TRA	1,4
00002	0520 60 4 00001	ENB	ZET*	1,4
00003	0020 00 0 00006		TRA	*+3
00004	0564 00 0 00011		ENB	=02
00005	0020 00 4 00002		TRA	2,4
00006	0564 00 0 00012		ENB	=02000
00007	0020 00 4 00002		TRA	2,4
			END	

LITERALS

00010	00000000000000
00011	00000000000002
00012	000000002000

POST PROCESSOR ASSEMBLY DATA

13 IS THE FIRST LOCATION NOT USED BY THIS PROGRAM

REFERENCES TO DEFINED SYMBOLS

0	DSB	0
2	ENB	0

NO ERROR IN ABOVE ASSEMBLY.

SUBROUTINE : INSERT (ILIST,DLIST,SLIST)
RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0)

INSERT DUMMY SUBROUTINE. OPERATIONAL PROGRAM USES A GENUINE SUB HERE.

58

STORAGE NOT USED BY PROGRAM

DEC OCT
19 00023 **DEC OCT**
32561 77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

61 DEC OCT 61 DEC OCT 61 DEC OCT 61 DEC OCT 61 DEC OCT

SUBROUTINE GONOGO
RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0)

GONO GO

60

STORAGE NOT USED BY PROGRAM

DEC OCT
19 00023

DEC OCT
32561 77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

6) DEC OCT
13 00015

DEC OCT

DEC OCT

DEC OCT

DEC OCT

SUBROUTINE PAGE
RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0)

AGE

62

STORAGE NOT USED BY PROGRAM

DEC OCT
19 00023

DEC OCT
32561 77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

6) DEC OCT
13 00015

DEC OCT

DEC OCT

DEC OCT

DEC OCT

ASCENT

SUBROUTINE ASCENT (LC4A,LC4B,LC4C,LC4D,LC4E,LC4G,LCY)
LC4A=0
LC4B=4095
LC4C=0
LC4D=0
LC4E=0
LC4G=0
LCY=0
RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0)

ASCENT

64

STORAGE NOT USED BY PROGRAM

DEC OCT
49 00061

DEC OCT
32561 77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

DEC OCT
21 41 00051

DEC OCT
61 43 00053

DEC OCT

DEC OCT

DEC OCT

TDPRED

```
SUBROUTINE TDPRED (LC4A,LC4B,LC4C,LC4D,LC4E,LC4G,LCY)
LC4A=0
LC4B=0
LC4C=0
LC4D=0
LC4E=4095
LC4G=0
LCY =0
RETURN
END(1,1,0,0,0,1,1,0,0,0,0,0,0)
```

TOPRED

66

STORAGE NOT USED BY PROGRAM

DEC OCT
49 00061DEC OCT
32561 77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

2) DEC OCT
41 000516) DEC OCT
43 00053

DEC OCT

DEC OCT

DEC OCT

REENT

SUBROUTINE REENT (LC4A,LC4B,LC4C,LC4D,LC4E,LC4G,LCY)
LC4A=0
LC4B=0
LC4C=0
LC4D=0
LC4E=0
LC4G=4095
LCY=0
RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0)

REENT

68

STORAGE NOT USED BY PROGRAM

DEC OCT
49 00061

DEC OCT
32561 77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

2) DEC OCT
41 00051

61 DEC OCT
43 00053

DEC OCT

DEC OCT

DEC OCT

ALIGNP

64

```
SUBROUTINE ALIGNP(CFX,CFY,CFZ,FXP,FYP,FZP,AKX1,AKX2,AKX3,AKX4,AKY1
1,AKY2,AKY3,AKY4,AKZ1,AKZ2,AKZ3,AKZ4,DTSC)
  FXP= FXP -DTSC*AKX4
  FYP= FYP -DTSC*AKY4
  FZP= FZP -DTSC*AKZ4
  CFX = AKX1*FXP + AKX2*FYP + AKX3* FZP
  CFY = AKY1*FXP + AKY2*FYP + AKY3*FZP
  CFZ = AKZ1*FXP + AKZ2*FYP + AKZ3*FZP
  FXP=0.
  FYP=0.
  FZP=0.
  RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0)
```

ALIGNP

70

STORAGE NOT USED BY PROGRAM

DEC OCT
132 00204

DEC OCT
32561 77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

11 DEC OCT
129 00201

31 DEC OCT
122 00172

61 DEC OCT
123 00173

DEC OCT

DEC OCT

WAIT5

//

SUBROUTINE WAIT5
RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0)

WAITS

72

STORAGE NOT USED BY PROGRAM

DEC OCT
19 00023

DEC OCT
32561 77461



LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

61 DEC OCT
13 00015

DEC OCT

DEC OCT

DEC OCT

DEC OCT

SUBROUTINE GANG (CTHB,CPHIB,CPSIB,THETAB,PHIB,PSIB,CUDTHS,CUDPSS,
*CUDPHS,CTHBC,CPSIBC)
CTHB=THE TAB
CPSIB=PSIB
CPHIB=PHIB
101 IF (1.57079633-CPSIB) 102,99,99
102 IF (CPSIB-4.71238898) 103,99,99
103 CPSIB=3.14159265-CPSIB
104 IF (CPSIB) 105,106,106
105 CPSIB=CPSIB+6.28318530
106 IF (3.14159265-CTHB) 108,107,107
107 CTHB=CTHB+3.14159265
GO TO 109
108 CTHB=CTHB-3.14159265
109 IF (3.14159265-CPHIB) 111,110,110
110 CPHIB=CPHIB+3.14159265
GO TO 99
111 CPHIB=CPHIB-3.14159265
99 CUDPHS=CPHIB
CUDTHS=CTHB-CTHBC
CUDPSS=CPSIB-CPSIBC
50 IF (ABSF(CUDPHS)-3.14159265) 60,51,51
51 IF (CUDPHS) 52,53,53
52 CUDPHS=CUDPHS+6.28318530
GO TO 60
53 CUDPHS=CUDPHS-6.28318530
60 IF (ABSF(CUDPSS)-3.14159265) 70,61,61
61 IF (CUDPSS) 62,63,63
62 CUDPSS=CUDPSS+6.28318530
GO TO 70
63 CUDPSS=CUDPSS-6.28318530
70 IF (ABSF(CUDTHS)-3.14159265) 74,71,71
71 IF (CUDTHS) 72,73,73
72 CUDTHS=CUDTHS+6.28318530
GO TO 74
73 CUDTHS=CUDTHS-6.28318530
74 RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0)

GANG GIMBAL ANGLE SUBROUTINE FOR FLIP CORRECTION

62

74

STORAGE NOT USED BY PROGRAM

DEC	OCT
186	00272
32561	77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

3)	DEC	OCT	6)	DEC	OCT	DEC	OCT	DEC	OCT
	176	00260		180	00264				

EXTERNAL FORMULA NUMBERS WITH CORRESPONDING INTERNAL FORMULA NUMBERS AND OCTAL LOCATIONS

EFN	IFN	LOC									
101	6	00113	102	7	00117	103	8	00123	104	9	00126
106	11	00134	107	12	00141	108	14	00145	109	15	00150
111	18	00161	99	19	00164	50	22	00174	51	23	00202
53	26	00211	60	27	00214	61	28	00222	62	29	00225
70	32	00234	71	33	00242	72	34	00245	73	36	00251
									74	37	00254

ROUTINE TO GENERATE A SELF-LOADING TAPE ON A7

75

BINARY CARD NO. SELFLD00 00000	ENTRY	SELFLD		
BINARY CARD NO. SELFLD01				
00000 0634 00 1 00031	SELFLD	SXA	XRI,1	SAVE INDEX REGISTERS FOR RETURN TO CALLING PROGRAM
00001 0634 00 2 00032		SXA	XR2,2	
00002 0634 00 4 00033		SXA	XR4,4	
00003 0500 00 0 00135		CLA	SLNI	SAVE STATUS OF SENSE LIGHT ONE
00004 -0760 00 0 00141		SLT	1	
00005 0500 00 0 00137		CLA	NOP	
00006 0601 00 0 00030		STO	SLNIP	
00007 0500 00 0 00136		CLA	SLN	SAVE STATUS OF SENSE LIGHT ONE
00010 -0760 00 0 00144		SLT	4	
00011 0500 00 0 00137		CLA	NOP	
00012 0601 00 0 00027		STO	SLNNOP	
00013 0774 00 1 00005	WRITAG	AXT	5,1	
00014 0772 00 0 01207	WRITE	REWA	7	
00015 0776 00 0 01227		SDHA	7	
00016 0766 00 0 01227		WTBA	7	
00017 0540 00 0 00140		RCHA	WTBIOC	
00020 0060 00 0 00020		TCOA	*	
00021 0022 00 0 00051		TRCA	TRCHK	WRITE TAPE REDUNDANCY CHECK ERROR ROUTINE
00022 0770 00 0 01207		WEFA	7	
00023 -0772 00 0 01207		RUNA	7	
BINARY CARD NO. SELFLD02				
00024 0074 00 4 00254		TSX	CPY90,4	PRINT ON-LINE
00025 0 77767 2 00242		HTR	PROP,2,-9	TAPE HAS BEEN PROPERLY WRITTEN
00026 0020 00 0 00027		TRA	SLNNOP	RETURN TO CALLING PROGRAM
00027 0761 00 0 00000	SLNNOP	NOP		RESTORE SENSE LIGHT FOUR
00030 0761 00 0 00000	SLNIP	NOP		RESTORE SENSE LIGHT ONE
00031 0774 00 1 00000	XRI	AXT	**,1	RETURN TO CALLING PROGRAM
00032 0774 00 2 00000	XR2	AXT	**,2	
00033 0774 00 4 00000	XR4	AXT	**,4	
00034 0020 00 4 00001		TRA	1,4	
00035 0 77775 0 00003	LOADER	I0CD	3,,,-3	
00036 0060 00 0 00001		TCOA	1	
00037 0061 00 0 00002		TCOB	2	
00040 0020 00 0 00041		TRA	LOADR1	
00041 0760 00 0 00163	LOADR1	SWT	3	MONITOR - OR - NON MONITOR
00042 0020 00 0 00045		TRA	**+3	NON MONITOR
00043 -0022 00 0 00066		TRCB	TCHECK	MONITOR CHANNEL B CHECK
00044 0020 00 0 00047		TRA	ON	
00045 0022 00 0 00066		TRCA	TCHECK	CHANNEL A CHECK
00046 0020 00 0 00047		TRA	ON	
00047 0074 00 4 00127	ON	TSX	REWIND,4	REWIND B7 OR A1
BINARY CARD NO. SELFLD03				
00050 0020 00 0 00027		TRA	SLNNOP	RETURN TO CALLING PROGRAM
00051 2 00001 1 00014	TRCHK	TIX	WRITE,1,1	WRITE TAPE REDUNDANCY CHECK ERROR ROUTINE
00052 0074 00 4 00254		TSX	CPY90,4	PRINT ON-LINE
00053 0 77767 0 00143		HTR	TRCHK1,,,-9	5 ATTEMPTS TO WRITE A7 HAVE FAILED
00054 0074 00 4 00254		TSX	CPY90,4	
00055 0 77767 0 00154		HTR	TRCHK2,,,-9	MOUNT ANOTHER TAPE - HIT START OR

ROUTINE TO GENERATE A SELF-LOADING TAPE ON A7

76

00056	0074 00 4 00254	TSX	CPY90,4	
00057	0 77767 2 00165	HTR	TRCHK3,2,-9	DEPRESS MQ 6 TO OMIT AND CONTINUE
00060	0420 00 0 00000	HPR		
00061	0760 00 0 00004	ENK		
00062	0131 00 0 00000	XCA		
00063	-0320 00 0 00253	ANA	MASK6	
00064	-0100 00 0 00027	TNZ	SLNNOP	RETURN TO CALLING PROGRAM
00065	0020 00 0 00013	TRA	WRITAG	TRY AGAIN
00066	-0760 00 0 00141	TCHECK	SLT	TEST FIRST TRY INDICATOR
00067	0020 00 0 00071	TRA	1	
00070	0020 00 0 00105	TRA	#+2	
00071	0074 00 4 00127	TSX	TPERRS	
00072	0760 00 0 00141	SLN	REWIND,4	
00073	0760 00 0 00163	RELOAD	1	TURN ON FIRST TRY INDICATOR
		SWT	3	

BINARY CARD NO. SELFLD04

00074	0020 00 0 00101	TRA	TAPEA1	
00075	0762 00 0 02227	RTBB	7	LOAD FROM B7 - MONITOR
00076	-0540 00 0 00142	RCHB	LTBI0C	
00077	-0544 00 0 00035	LCHB	LOADER	
00100	0020 00 0 00001	TRA	1	
00101	0762 00 0 01221	TAPEA1	RTBA	LOAD FROM A1 - NON MONITOR
00102	0540 00 0 00142	RCHA	LTBI0C	
00103	0544 00 0 00035	LCHA	LOADER	
00104	0020 00 0 00001	TRA	1	
00105	0074 00 4 00127	TPERR5	TSX	REWIND,4
00106	0074 00 4 00254	TSX	CPY90,4	PRINT ON-LINE
00107	0 77767 0 00176	HTR	ONBAD,,,-9	TAPE LOADING REDUNDANCY ERROR
00110	0760 00 0 00163	SWT	3	
00111	0020 00 0 00124	TRA	TPERR6	
00112	0074 00 4 00254	TSX	CPY90,4	
00113	0 77767 0 00207	HTR	ONBAD1,,,-9	TO RETRY HIT START - TO ACCEPT PUT MQ 6
00114	0074 00 4 00254	TSX	CPY90,4	
00115	0 77767 2 00220	HTR	ONBAD2,2,,,-9	DOWN - HIT START
00116	0420 00 0 00000	HPR		
00117	0760 00 0 00004	ENK		

BINARY CARD NO. SELFLD05

00120	0131 00 0 00000	XCA		
00121	-0320 00 0 00253	ANA	MASK6	
00122	-0100 00 0 00027	TNZ	SLNNOP	RETURN TO CALLING PROGRAM
00123	0020 00 0 00073	TRA	RELOAD	TRY AGAIN
00124	0074 00 4 00254	TPERR6	TSX	CPY90,4
00125	0 77767 0 00231	HTR	ONBAD3,,,-9	TO ACCEPT HIT START OR CLEAR AND LOAD TAPE
00126	0 00000 0 00027	HTR	SLNNOP	RETURN TO CALLING PROGRAM
00127	0760 00 0 00163	REWIND	SWT	REWIND B7 OR A1 SUBROUTINE
00130	0020 00 0 00133	TRA	1,+3	
00131	0772 00 0 02207	REWB	7	
00132	0020 00 0 00134	TRA	1,+2	
00133	0772 00 0 01201	REWA	1	
00134	0020 00 4 00001	TRA	1,+4	
00135	0760 00 0 00141	SLN1	SLN	1
00136	0760 00 0 00144	SLN	SLN	4
00137	0761 00 0 00000	NOP	NOP	
00140	-0 00004 0 00035	WTBI0C	IOCP	LOADER,,4
00141	0 77774 0 00006	I0CO		5,,,-9

ROUTINE TO GENERATE A SELF-LOADING TAPE ON A7

77

00142 -1 00003 0 00000 LTBI0C IOCT 0+3
00143 056021636325 TRCHK1 BCI 9,5 ATTEMPTS TO WRITE A7 HAVE FAILED

BINARY CARD NO. SELFLD06

00144 444763626063
00145 466066513163
00146 256021076030
00147 216525602621
00150 314325246060
00151 606060606060
00152 606060606060
00153 606060606060
00154 444664456360 TRCHK2 BCI 9,MOUNT ANOTHER TAPE - HIT START OR
00155 214546633025
00156 516063214725
00157 604060303163
00160 606263215163
00161 604651606060
00162 606060606060
00163 606060606060
00164 606060606060
00165 242547512562 TRCHK3 BCI 9,DEPRESS MQ 6 TO OMIT AND CONTINUE
00166 626044506006
00167 606346604644

BINARY CARD NO. SELFLD07

00170 316360214524
00171 602346456331
00172 456425606060
00173 606060606060
00174 606060606060
00175 606060606060
00176 632147256043 ONBAD BCI 9,TAPE LOADING REDUNDANCY ERROR
00177 462124314527
00200 605125246445
00201 242145237060
00202 255151465160
00203 606060606060
00204 606060606060
00205 606060606060
00206 606060606060
00207 634660512563 ONBAD1 BCI 9,TO RETRY HIT START - TO ACCEPT PUT MQ 6
00210 517060303163
00211 606263215163
00212 604060634660
00213 212323254763

BINARY CARD NO. SELFLD08

00214 604764636044
00215 5060060606060
00216 606060606060
00217 606060606060
00220 244664456040 ONBAD2 BCI 9,DOWN - HIT START
00221 603031636062
00222 632151636060
00223 606060606060

ROUTINE TO GENERATE A SELF-LOADING TAPE ON A7

00224 606060606060
00225 606060606060
00226 606060606060
00227 606060606060
00230 606060606060
00231 634660212323
00232 254763603031
00233 636062632151
00234 636046516023
00235 432521516021
00236 452460434621
00237 246063214725

BINARY CARD NO. SELFLD09

00240 606060606060
00241 606060606060
00242 632147256021
00243 076030216260
00244 475146472551
00245 254370602225
00246 254560665131
00247 636325456060
00250 606060606060
00251 606060606060
00252 606060606060
00253 +004000000000

ONBAD3 BCI

9,TO ACCEPT HIT START OR CLEAR AND LOAD TAPE

PROP BCI

9,TAPE A7 HAS PROPERLY BEEN WRITTEN

MASK6 OCT

004000000000

78

ROUTINE TO GENERATE A SELF-LOADING TAPE ON A7

© 1964 COMMUNICATIONS & COMPUTER CORPORATION CLEVELAND, OHIO 44115

ROUTINE TO GENERATE A SELF-LOADING TAPE ON A7

76

SUBROUTINE CPY90, TO PRINT ON LINE

TSX CPY90,4
HTR A,,X
(RETURN) A=LOCA. 1ST WORD
 X= NO. OF WORDS

RESTORE THE PRINTER AFTER A LINE OF PRINT PUT A Z IN TAG OF TSX+1.

00254	-0634	00	1	00331	CPY90	SXD	OP2A,1
00255	-0634	00	2	00350		SXD	OP4A,2
00256	-0634	00	4	00360		SXD	OP6C,4
00257	0500	00	4	00001		CLA	1,4
00260	0621	00	0	00306		STA	BEGIN3
00261	0625	00	0	00426		STT	OP14
00262	-0734	00	2	00000		PDX	,2
00263	3	77763	2	00267		TXH	BEGIN4,2,-13

BINARY CARD NO. SELFLD10

	TXI	*+1,2,12
	SXD	OV72,2
	LAC	BEGIN5,2
BEGIN4	SXD	BEGIN2,2
BEGIN5	AXT	12,1
	STZ	OP50+12,1
	STZ	OP50+27,1
	TXI	*-2,1,1
	STZ	BLKTST
	AXT	36,1
	AXC	1,2
	SXD	OP3A,2
	TXI	BEGIN3,2,1
BEGIN1	LXD	OP3A,2
BEGIN2	TXL	OP16,2,0
	TXI	*+1,2,-1
	SXD	OP3A,2
	TXI	*+1,2,1
BEGIN3	LDQ	0,2
	AXT	6,4

5687

BINARY CARD NO. SELFLD11

OPO	SXD	OP1B,4	
	AXT	0,2	
	AXT	0,4	
	CAL	BT4	
	ARS	36,1	
	SLW	VARONE	
	SXD	OP2B,1	
	LXD	BLKTST,1	
	PXD	,0	
	LGL	3	
	CAS	SIXC	
	TXI	OP3,4,-2	IN 70S
	TXI	OP1,4,-2	IN 60S
	CAS	FOURC	
	TXI	OP3,4,-1	IN 50S
	TXI	OP6,4,-1	IN 40S

ROUTINE TO GENERATE A SELF-LOADING TAPE ON AT

80

	00330	0340 00 0 00452	CAS	TWOC		5687
TD	00331	-3 00000 0 00335	OP2A	TXL	OP3	5687
TD	00332	-3 00000 0 00353	OP2B	TXL	OP6	5687
	00333	1 00001 4 00334		TXI	++1,4,1	5687
		BINARY CARD NO. SELFLD12				
	00334	0100 00 0 00401	TZE	OP7		5687
	00335	-0754 00 0 00000	OP3	PXD	,0	5687
	00336	-0763 00 0 00003		LGL	3	5687
	00337	0737 00 2 00000		PAC	,2	5687
	00340	0340 00 0 00451		CAS	ONEC	5687
	00341	0020 00 0 00344		TRA	++3	5687
TD	00342	-3 00000 0 00351	OP3A	TXL	OP5	5687
TD	00343	-3 00000 0 00351		TXL	OP5	5687
	00344	-0500 00 0 00447		CAL	VARONE	5687
	00345	-0602 00 1 00474		ORS	OP50+10,1	5687
	00346	-0602 60 1 00457	OP4	DRS*	OP30,1	5687
	00347	-0602 60 1 00460		DRS*	OP40,1	5687
TD	00350	-3 00000 0 00364	OP4A	TXL	OP1A	5687
	00351	-0500 00 0 00447	OP5	CAL	VARONE	5687
	00352	1 77770 2 00346		TXI	OP4,2,-8	5687
	00353	-0754 00 0 00000	OP6	PXD	,0	5687
	00354	-0763 00 0 00003		LGL	3	5687
	00355	-0100 00 0 00376		TNZ	OP2	5687
	00356	-0500 00 0 00447	OP6A	CAL	VARONE	5687
	00357	-0602 60 1 00460	OP6B	ORS*	OP40,1	5687
		BINARY CARD NO. SELFLD13				
TD	00360	-3 00000 0 00364	OP6C	TXL	OP1A	5687
	00361	-0754 00 0 00000	OP1	PXD	,0	5687
	00362	-0763 00 0 00003		LGL	3	5687
	00363	-0100 00 0 00376		TNZ	OP2	5687
	00364	-0534 00 1 00332	OP1A	LXD	OP28,1	5687
	00365	1 77771 1 00366		TXI	++1,1,-1	5687
	00366	-0534 00 4 00372		LXD	OP1B,4	5687
	00367	2 00001 4 00310		TIX	OP0,4,1	5687
	00370	3 00001*1 00301		TXH	BEGIN1,1,1	5687
	00371	0520 00 0 00446		ZET	BLKST	5687
TD	00372	-3 00000 0 00405	OP1B	TXL	OP16	5687
	00373	-0774 00 1 00017		AXC	15,1	5687
	00374	-0634 00 1 00446		SXD	BLKST,1	5687
	00375	1 00063 1 00301		TXI	BEGIN1,1,51	5687
	00376	0737 00 2 00000	OP2	PAC	,2	5687
	00377	-0500 00 0 00447		CAL	VARONE	5687
TD	00400	-3 00000 0 00346		TXL	OP4	5687
	00401	-0754 00 0 00000	OP7	PXD	,0	5687
	00402	-0763 00 0 00003		LGL	3	5687
	00403	-0100 00 0 00376		TNZ	OP2	5687
		BINARY CARD NO. SELFLD14				
	00404	1 77775 4 00356		TXI	OP6A,4,-3	5687
	00405	0774 00 4 00000	OP16	AXT	,4	5687
	00406	0774 00 2 0030		AXT	24,2	5687
	00407	050G 00 4 00475	OP17	CLA	OP50+11,4	5687
	00410	0601 00 2 00545		STO	CPYBLK+24,2	5687
	00411	0500 00 4 00514		CLA	OP50+26,4	5687

ROUTINE TO GENERATE A SELF-LOADING TAPE ON A7

81

00412	0601 00 2 00546	STO	CPYBLK+25,2	5687
00413	-2 00002 2 00415	TNX	OP18,2,2	5687
00414	1 00001 4 00407	TXI	OP17,4,1	5687
00415	0060 00 0 00415	OP18	TCOA	*
00416	0766 00 0 01361	WPDA		5687
00417	-0520 00 0 00456	NZT	OV72A	5687
00420	0020 00 0 00423	TRA	*+3	5687
00421	0600 00 0 00456	STZ	OV72A	5687
00422	0760 00 0 01371	SPRA	9	5687
00423	0540 00 0 00445	RCHA	OP20	5687
00424	0060 00 0 00424	TCOA	*	5687
00425	-0520 00 0 00455	NZT	OV72	5687
00426	0020 00 0 00440	OP14	TRA	OP13,**
00427	-0534 00 2 00455	LXD	OV72,2	5687
 BINARY CARD NO. SELFLD15				
00430	-0634 00 2 00456	SXD	OV72A,2	5687
00431	0534 00 1 00306	LXA	BEGIN3,1	5687
00432	1 00014 1 00433	TXI	*+1,1,12	5687
00433	0634 00 1 00306	SXA	BEGIN3,1	5687
00434	0600 00 0 00455	STZ	OV72	5687
00435	0020 00 0 00267	TRA	BEGIN4	5687
00436	0766 00 0 01361	WPDA		5687
00437	0760 00 0 01361	SPRA	1	5687
00440	-0534 00 1 00331	OP13	LXD	OP2A,1
00441	-0534 00 2 00350	LXD	OP4A,2	5687
00442	-0534 00 4 00360	LXD	OP6C,4	5687
00443	0600 00 0 00443	TCOA	*	5687
00444	0020 00 4 00002	TRA	2,4	5687
00445	0 00030 0 00515	OP20	I OCD	CPYBLK,,24
00446	0 00000 0 00000	BLKTST	HTR	0
00447	0 00000 0 00000	VARONE	HTR	0
00450	-0000000000000	BT4	OCT	400000000000
00451	+000000000001	ONEC	DEC	1
00452	+000000000002	TWOC	DEC	2
00453	+000000000004	FOURC	DEC	4
 BINARY CARD NO. SELFLD16				
00454	+000000000006	SIXC	DEC	6
00455	0 00000 0 00000	OV72	HTR	0
00456	0 00000 0 00000	OV72A	HTR	0
00457	0 00000 2 00464	OP30	HTR	OP50+2,2
00460	0 00000 4 00462	OP40	HTR	OP50,4
00461	0 00000 0 00000	HTR	0	5687
00462		OP50	BSS	12
 BINARY CARD NO. SELFLD17				
00476	0 00000 2 00503	HTR	OP50+17,2	5687
00477	0 00000 4 00501	HTR	OP50+15,4	5687
00500	0 00000 0 00000	HTR	0	5687
00501		BSS	12	5687
00515		CPYBLK	BSS	24
			END	5687

U.A

ROUTINE TO GENERATE A SELF-LOADING TAPE ON A7
POST PROCESSOR ASSEMBLY DATA

545 IS THE FIRST LOCATION NOT USED BY THIS PROGRAM

REFERENCES TO DEFINED SYMBOLS

47	ON	44,	46
450	BT4	313	
137	NOP	5,	11
310	OP0	367	
361	OP1	324	
376	OP2	355,	363,
335	OP3	323,	326,
346	OP4	352,	400
351	OP5	342,	343
353	OP6	327,	332
401	OP7	334	
136	SLN	7	
31	XR1	0	
32	XR2	1	
33	XR4	2	
451	ONEC	340	
440	OP13	426	
426	OP14	261	
405	OP16	302,	372
407	OP17	414	
415	OP18	413	
364	OP1A	350,	360
372	OP1B	310,	366
445	OP20	423	
331	OP2A	254,	440
332	OP2B	316,	364
457	OP30	346	
342	OP3A	277,	301,
460	OP40	347,	357
350	OP4A	255,	441
462	OP50	271,	272,
		345,	407,
		411,	457,
		460,	476,
		477	
356	OP6A	404	
357	OP6B		
360	OP6C	256,	442
455	OV72	265,	425,
242	PROP	427,	434
454	SIXC	322	
135	SLN1	3	
452	TWOC	330	
254	CPY90	24,	52,
		54,	56,
		106,	112,
		114,	124
453	FOURC	325	
253	MASK6	63,	121
176	ONBAD	107	
456	OV72A	417,	421,
30	SLN1P	430	
51	TRCHK	6	
14	WRITE	21	
301	BEGIN1	51	
302	BEGIN2	370,	375
306	BEGIN3	267	
		300,	431,
		433	
267	BEGIN4	263,	435

82

ROUTINE TO GENERATE A SELF-LOADING TAPE ON A7
POST PROCESSOR ASSEMBLY DATA

270	BEGINS	266
446	BLKTST	274, 317, 371, 374
515	CPYBLK	410, 412, 445
35	LOADER	77, 103, 140
41	LOADR1	40
142	LTBIOC	76, 102
207	ONBAD1	113
220	ONBAD2	115
231	ONBAD3	125
73	RELOAD	123
127	REWIND	47, 71, 105
0	SELFLD	0
27	SLNNOP	12, 26, 50, 64, 122, 126
101	TAPEA1	74
66	TCHECK	43, 45
105	TPERR5	70
124	TPERR6	111
143	TRCHK1	53
154	TRCHK2	55
165	TRCHK3	57
447	VARONE	315, 344, 351, 356, 377
13	WRITAG	65
140	WTBIOC	17

NO ERROR IN ABOVE ASSEMBLY.

SUBROUTINE STATE (W)

OT

SUBROUTINE STATE (W)

CSTATE IBM-OWEGO, SINGLE-PRECISION COWELLS METHOD, (3) SCARBOROUGH

C

C 14 ARGUMENTS ARE REQUIRED FOR THIS SUBROUTINE.
 C THEY ARE AS FOLLOWS,

C ARG1=X POSITION COMPONENT
 C ARG2=Y POSITION COMPONENT
 C ARG3=Z POSITION COMPONENT
 C ARG4=RADIUS MAGNITUDE
 C ARG5=X VELOCITY COMPONENT
 C ARG6=Y VELOCITY COMPONENT
 C ARG7=Z VELOCITY COMPONENT
 C ARG8=VELOCITY MAGNITUDE
 C ARG9=EARTH OBLATENESS CONSTANT, RJ
 C ARG10=TIME STEP SIZE
 C ARG11=X THRUST ACCELERATION
 C ARG12=Y THRUST ACCELERATION
 C ARG13=Z THRUST ACCELERATION
 C ARG14=NOT USED

C ALL ARGUMENTS EXCEPT VELOCITY MAGNITUDE AND ARG14 MUST BE
 C INITIALLY SUPPLIED

C

DIMENSION W(14),R(14)
 DO 1 I=1,14
 1 R(I)=W(I)
 DO 10 I=1,3
 2 G=-.1407654E17/R(4)**3
 Q3=R(9)*(2.0925874E7/R(4))**2
 Q4=5.*(R(3)/R(4))**2
 Q1=1.+Q3*(1.-Q4)
 XDD=+G*R(1)*Q1+R(11)
 YDD=+G*R(2)*Q1+R(12)
 ZDD=+G*R(3)*(1.+Q3*(3.-Q4))+R(13)
 GO TO 4,5,6,I
 4 XP=R(1)
 YP=R(2)
 ZP=R(3)
 XK1=XDD
 YK1=YDD
 ZK1=ZDD
 T1=R(10)/2.
 T2=R(10)**2/8.
 R(1)=XP+T1*R(5)+T2*XDD
 R(2)=YP+T1*R(6)+T2*YDD
 R(3)=ZP+T1*R(7)+T2*ZDD
 R(4)=SQRTF(R(1)**2+R(2)**2+R(3)**2)
 GO TO 10
 5 T1=T2*4.
 R(1)=XP+R(10)*R(5)+T1*XDD
 R(2)=YP+R(10)*R(6)+T1*YDD
 R(3)=ZP+R(10)*R(7)+T1*ZDD
 R(4)=SQRTF(R(1)**2+R(2)**2+R(3)**2)
 XK2=XDD
 YK2=YDD
 ZK2=ZDD
 GO TO 10

SUBROUTINE STATE (W)

OO

```
6   T1=R(10)/6.  
R(1)=XP+R(10)*(R(5)+T1*(XK1+2.*XK2))  
R(2)=YP+R(10)*(R(6)+T1*(YK1+2.*YK2))  
R(3)=ZP+R(10)*(R(7)+T1*(ZK1+2.*ZK2))  
R(4)=SQRTF(R(1)**2+R(2)**2+R(3)**2)  
R(5)=R(5)+T1*(XK1+4.*XK2+XDD)  
R(6)=R(6)+T1*(YK1+4.*YK2+YDD)  
R(7)=R(7)+T1*(ZK1+4.*ZK2+ZDD)  
R(8)=SQRTF(R(5)**2+R(6)**2+R(7)**2)  
10  CONTINUE  
DO 20 I=1,14  
20  W(I)=R(I)  
RETURN  
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0)
```

SUBROUTINE STATE (W)

86

STORAGE NOT USED BY PROGRAM

DEC	OCT	DEC	OCT
348	00534	32561	77461

STORAGE LOCATIONS FOR VARIABLES APPEARING IN DIMENSION AND EQUIVALENCE STATEMENTS

R	DEC	OCT	DEC	OCT	DEC	OCT	DEC	OCT
	347	00533						

STORAGE LOCATIONS FOR VARIABLES NOT APPEARING IN COMMON, DIMENSION, OR EQUIVALENCE STATEMENT

G	DEC	OCT	Q1	DEC	OCT	Q3	DEC	OCT	Q4	DEC	OCT	T1	DEC	OCT
T2	333	00515	332	00514	331	00513	330	00512	329	00511				
Z2	328	00510	XDD	327	00507	XK1	326	00506	XK2	325	00505	XP	324	00504
YDD	323	00503	YK1	322	00502	YK2	321	00501	YP	320	00500	ZDD	319	00477
ZK1	318	00476	ZK2	317	00475	ZP	316	00474						

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

IJ	DEC	OCT	21	DEC	OCT	31	DEC	OCT	61	DEC	OCT	91	DEC	OCT
CIGO	312	00470	E14	293	00445	E14	296	00450	E16	305	00461		311	00467
	315	00473		80	00120		187	00273						

LOCATIONS OF NAMES IN TRANSFER VECTOR

SQRT	DEC	OCT		DEC	OCT		DEC	OCT		DEC	OCT
	0	00000									

ENTRY POINTS TO SUBROUTINES NOT OUTPUT FROM LIBRARY

SQRT

EXTERNAL FORMULA NUMBERS WITH CORRESPONDING INTERNAL FORMULA NUMBERS AND OCTAL LOCATIONS

EFN	IFN	LOC									
1	5	00017	3	6	00023	2	7	00024	4	15	00121
6	37	00274	10	46	00432	20	48	00435	5	28	00213

MODIFIED EULER INTEGRATION SUBROUTINE. ECKSTROM - IBM OWEKO.

BINARY CARD NO. MEDP3000

00000	ENTRY	MAR
00046	ENTRY	DEV
00122	ENTRY	PRT

BINARY CARD NO. MEDP3001

00000 0600 00 0 00133	MAR	STZ	COUNT
00001 0500 60 4 00002		CLA*	2,4
00002 0601 00 0 00127		STO	DT
00003 0500 60 4 00001		CLA*	1,4
00004 0771 00 0 00022		ARS	18
00005 0601 00 0 00130		STO	N
00006 0500 00 4 00003		CLA	3,4
00007 0400 00 0 00130		ADD	N
00010 0621 00 0 00053		STA	X1
00011 0621 00 0 00061		STA	X2
00012 0621 00 0 00062		STA	X3
00013 0621 00 0 00075		STA	X4
00014 0621 00 0 00101		STA	X5
00015 0621 00 0 00102		STA	X6
00016 0400 00 0 00130		ADD	N
00017 0621 00 0 00055		STA	XD1
00020 0621 00 0 00071		STA	XD2
00021 0621 00 0 00057		STA	XD3
00022 0400 00 0 00130		ADD	N
00023 0621 00 0 00054		STA	XP1

BINARY CARD NO. MEDP3002

00024 0621 00 0 00074		STA	XP2
00025 0400 00 0 00130		ADD	N
00026 0621 00 0 00056		STA	XDP1
00027 0621 00 0 00070		STA	XDP2
00030 0400 00 0 00130		ADD	N
00031 0621 00 0 00100		STA	XL1
00032 0621 00 0 00103		STA	XL2
00033 0621 00 0 00036		STA	XL3
00034 0634 00 1 00040		SXA	*+4,1
00035 0534 00 1 00130		LXA	N,1
00036 0600 00 1 00036	XL3	STZ	*,1
00037 2 00001 1 00036		TIX	*-1,1,1
00040 0774 00 1 00040		AXT	*,1
00041 0634 00 4 00047		SXA	S4,4
00042 0500 00 0 00131		CLA	D1
00043 0601 60 4 00006		STO*	6,4
00044 0600 00 0 00134		STZ	IND
00045 0020 00 4 00007		TRA	7,4
00046 0634 00 1 00106	DEV	SXA	EXIT,1
00047 0774 00 4 00047	S4	AXT	*,4

BINARY CARD NO. MEDP3003

00050 0534 00 1 00130		LXA	N,1
00051 0520 00 0 00134		ZET	IND
00052 0020 00 0 00070		TRA	XDP2
00053 0500 00 1 00053	X1	CLA	*,1

= I
= 0, V+N

MODIFIED EULER INTEGRATION SUBROUTINE. ECKSTROM - IBM OWEKO.

00054	0601 00 1 00054	XPI	STO	*,,1	V+3N
00055	0500 00 1 00055	XD1	CLA	*,,1	V+2N
00056	0601 00 1 00056	XDPI	STO	*,,1	V+4N
00057	0560 00 1 00057	XD3	LDQ	*,,1	V+2N
00060	0260 00 0 00127		FMP	DT	
00061	0300 00 1 00061	X2	FAD	*,,1	V+N
00062	0601 00 1 00062	X3	STO	*,,1	V+N
00063	2 00001 1 00053		TIX	X1,,1,,1	
00064	0500 00 0 00131		CLA	D1	
00065	0601 00 0 00134		STO	IND	
00066	0534 00 1 00106		LXA	EXIT,,1	
00067	0020 00 0 00115		TRA	LD	
00070	0500 00 1 00070	XDP2	CLA	*,,1	V+4N
00071	0300 00 1 00071	XD2	FAD	*,,1	V+2N
00072	0241 00 0 00135		FDP	TWO	
00073	0260 00 0 00127		FMP	DT	

BINARY CARD NO. MEDP3004

00074	0300 00 1 00074	XP2	FAD	*,,1	V+3N
00075	0601 00 1 00075	X4	STO	*,,1	V+N
00076	-0600 00 0 00136		STQ TEMP		
00077	0500 00 0 00136		CLA TEMP		
00100	0300 00 1 00100	XL1	FAD	*,,1	
00101	0300 00 1 00101	X5	FAD	*,,1	
00102	0601 00 1 00102	X6	STO	*,,1	
00103	-0600 00 1 00103	XL2	STQ	*,,1	
00104	2 00001 1 00070		TIX	XDP2,,1,,1	
00105	0600 00 0 00134		STZ	IND	
00106	0774 00 1 00106	EXIT	AXT	*,,1	
00107	0500 00 0 00133		CLA	COUNT	
00110	0400 00 0 00131		ADD	D1	
00111	0601 00 0 00133		STO	COUNT	
00112	0402 60 4 00005		SUB*	5,,4	
00113	0100 00 0 00120		TZE	*+5	
00114	0120 00 0 00120		TPL	*+4	
00115	0500 00 0 00131	LD	CLA	D1	
00116	0601 60 4 00006		STO*	6,,4	
00117	0020 00 4 00007		TRA	7,,4	

BINARY CARD NO. MEDP3005

00120	0500 00 0 00132		CLA	D2	
00121	0020 00 0 00116		TRA	*--3	
00122	0600 00 0 00133	PRT	STZ	COUNT	
00123	0534 00 4 00047		LXA	S4,,4	
00124	0500 60 4 00002		CLA*	2,,4	
00125	0601 00 0 00127		STO	DT	
00126	0020 00 0 00115		TRA	LD	
00127	0 00000 0 00000	DT	PZE		
00130	0 00000 0 00000	N	PZE		
00131	0 00001 0 00000	D1	PZE	,,1	
00132	0 00002 0 00000	D2	PZE	,,2	
00133	0 00000 0 00000	COUNT	PZE		
00134	0 00000 0 00000	IND	PZE		
00135	+2024000000000	TWO	DEC	2,	
00136	0 00000 0 00000	TEMP	PZE		
			END		

MODIFIED EULER INTEGRATION SUBROUTINE. ECKSTROM - IBM OWEKO.
POST PROCESSOR ASSEMBLY DATA

137 IS THE FIRST LOCATION NOT USED BY THIS PROGRAM

REFERENCES TO DEFINED SYMBOLS

130	N	5,	7,	16,	22,	25,	30,	35,	50
131	D1	42,	64,	110,	115				
132	D2	120							
127	DT	2,	60,	73,	125				
115	LD	67,	126						
47	S4	41,	123						
53	X1	10,	63						
61	X2	11							
62	X3	12							
75	X4	13							
101	X5	14							
102	X6	15							
46	DEV	0							
134	IND	44,	51,	65,	105				
0	MAR	0							
122	PRT	0							
135	TWO	72							
55	XD1	17							
71	XD2	20							
57	XD3	21							
100	XL1	31							
103	XL2	32							
36	XL3	33							
54	XP1	23							
74	XP2	24							
106	EXIT	46,	66						
136	TEMP	76,	77						
56	XDP1	26							
70	XDP2	27,	52,	104					
133	COUNT	0,	107,	111,	122				

NO ERROR IN ABOVE ASSEMBLY.

LIBE

90

REAL TIME INTERRUPT SIMULATION. CH B COMMAND TRAP. CONSTABLE.

BINARY CARD NO. TCTRL000
00002

ENTRY CTRL1

TRANSFER VECTOR

BINARY CARD NO. TCTRL001

00000	746325623460	(TES)	
00001	272567252360	GEXEC	
00002	0634 00 4 00131	CTRL1 SXA	IXB4,4
00003	0634 00 2 00132	SXA	IXB2,2
00004	0634 00 1 00133	SXA	IXB1,1
00005	0522 60 0 00000	XEC*	\$ (TES)
00006	0760 00 0 00004	ENK	
00007	0131 00 0 00000	XCA	
00010	-0320 00 0 00645	ANA	=077777
00011	0767 00 0 00022	ALS	18
00012	0402 00 0 00647	SUB	=7.38+17
00013	0120 00 0 00016	TPL	*+3
00014	0500 00 0 00646	CLA	=01000000
00015	0020 00 0 00024	TRA	*+7
00016	0131 00 0 00000	XCA	
00017	0200 00 0 00652	MPY	=10.B+4
00020	0767 00 0 00004	ALS	4
00021	0340 00 0 00650	CAS	=0077777000000
00022	0500 00 0 00650	CLA	=0077777000000
00023	0761 00 0 00000	NOP	

T SCALED +35

MS DESIRED SCALED +17

NO. OF WORDS SCALED +21
NO. OF WORDS SCALED +17

BINARY CARD NO. TCTRL002

00024	0622 00 0 00145	STD	CW1
00025	0766 00 0 02226	WTBB	6
00026	-0540 00 0 00145	RCHB	CW1
00027	0564 00 0 00643	ENB	*02
00030	0520 00 0 00155	ZET	INIT
00031	0020 00 0 00033	TRA	*+2
00032	0020 00 0 00043	TRA	*+9
00033	0774 00 1 00316	AXT	206,1
00034	0500 00 1 00474	CLA	SAVE1,1
00035	0601 00 1 00000	STO	0,1
00036	2 00001 1 00034	TIX	=-2,1,1
00037	0774 00 1 00145	AXT	101,1
00040	0500 00 1 00641	CLA	SAVE2,1
00041	0601 00 1 00145	STO	101,1
00042	2 00001 1 00040	TIX	=-2,1,1
00043	0500 00 0 00147	CLA	LOCA
00044	0601 00 0 00015	STO	13
00045	0520 00 0 00154	ZET	DIND
00046	0020 00 0 00050	TRA	*+2
00047	0020 00 0 00052	TRA	*+3

SET UP IOCT COMMAND

BINARY CARD NO. TCTRL003

00050	0500 00 0 00644	CLA	=077
00051	0221 00 0 00642	DVP	=01
00052	0520 00 0 00153	ZET	OFIND

LIBE

00053	0020	00	0	00063	TRA	*+8
00054	0500	00	0	00151	CLA	SJ2
00055	0560	00	0	00152	LDQ	SJ3
00056	0763	00	0	00002	LLS	2
00057	0560	00	0	00150	LDQ	SJ1
00060	0520	00	0	00153	ZET	OFIND
00061	0020	00	0	00066	TRA	*+5
00062	0140	00	0	00066	TOV	*+4
00063	0500	00	0	00651	CLA	=0200000000000
00064	0763	00	0	00001	LLS	1
00065	0020	00	0	00054	TRA	*-9
00066	0774	00	4	00000	IXA4	AXT 0,4
00067	0774	00	2	00000	IXA2	AXT 0,2
00070	0774	00	1	00000	IXA1	AXT 0,1
00071	0021	00	0	00001	CENT	TTR \$GEXEC
00072	0634	00	4	00066	TENT	SXA IXA4,4
00073	0634	00	2	00067	SXA	IXA2,2

BINARY CARD NO. TCTRL004

00074	0634	00	1	00070	SXA	IXA1,1
00075	-0022	00	0	00076	TRCB	*+1
00076	0564	00	0	00641	ENB	=0
00077	0600	00	0	00154	STZ	DIND
00100	0600	00	0	00153	STZ	OFIND
00101	-0600	00	0	00150	STQ	SJ1
00102	0765	00	0	00002	LRS	2
00103	0601	00	0	00151	STO	SJ2
00104	-0600	00	0	00152	STQ	SJ3
00105	-0140	00	0	00110	TNO	*+3
00106	0500	00	0	00645	CLA	=077777
00107	0601	00	0	00153	STO	OFIND
00110	0760	00	0	00012	DCT	
00111	0020	00	0	00113	TRA	*+2
00112	0020	00	0	00115	TRA	*+3
00113	0500	00	0	00645	CLA	=077777
00114	0601	00	0	00154	STO	DIND
00115	0500	00	0	00014	CLA	12
00116	0621	00	0	00071	STA	CENT
00117	0774	00	1	00316	AXT	206,1

BINARY CARD NO. TCTRL005

00120	0500	00	1	00000	CLA	0,1
00121	0601	00	1	00474	STO	SAVE1,1
00122	2	00001	1	00120	TIX	*-2,1,1
00123	0774	00	1	00145	AXT	101,1
00124	0500	00	1	00145	CLA	101,1
00125	0601	00	1	00641	STO	SAVE2,1
00126	2	00001	1	00124	TIX	*-2,1,1
00127	0500	00	0	00645	CLA	=077777
00130	0601	00	0	00155	STO	INIT
00131	0774	00	4	00000	IXB4	AXT 0,4
00132	0774	00	2	00000	IXB2	AXT 0,2
00133	0774	00	1	00000	IXB1	AXT 0,1
00134	-0760	00	0	02000	ETTB	
00135	0020	00	0	00137	TRA	*+2
00136	0020	00	4	00001	TRA	1,4

LIBE

00137	0772	00	0	02206	REWB	6
00140	0061	00	0	00140	TCOB	*
00141	0766	00	0	02226	WTBB	6
00142	-0540	00	0	00146	RCHB	CW2
00143	0061	00	0	00143	TCOB	*

BINARY CARD NO. TCTRL006

00144	0020	00	4	00001	TRA	1,4	
00145	-1	00000	0	40000	CW1	IOCT	16384,0,0
00146	0	00012	0	40000	CW2	IOCD	16384,0,10
00147	0021	00	0	00072	LOCA	TTR	TENT
00150	0	00000	0	00000	SJ1	PZE	0
00151	0	00000	0	00000	SJ2	PZE	0
00152	0	00000	0	00000	SJ3	PZE	0
00153	0	00000	0	00000	OFIND	PZE	0
00154	0	00000	0	00000	DIND	PZE	0
00155	0	00000	0	00000	INIT	PZE	0
00474					SAVE1	BES	206
00641					SAVE2	BES	101
					END		

LITERALS

BINARY CARD NO. TCTRL007

00641	000000000000
00642	000000000001
00643	000000000002
00644	0000000000077
00645	000000077777
00646	000001000000
00647	000007231463
00650	077777000000
00651	200000000000
00652	240000000000

LIBE

POST PROCESSOR ASSEMBLY DATA

653 IS THE FIRST LOCATION NOT USED BY THIS PROGRAM

REFERENCES TO DEFINED SYMBOLS

145	CW1	24,	26
146	CW2	142	
150	SJ1	57,	101
151	SJ2	54,	103
152	SJ3	55,	104
71	CENT	116	
154	DIND	45,	77, 114
155	INIT	30,	130
70	IXA1	74	
67	IXA2	73	
66	IXA4	72	
133	IXB1	4	
132	IXB2	3	
131	IXB4	2	
147	LOCA	43	
72	TENT	147	
2	CTRL1	0	
1	GEXEC	71	
153	OFIND	52,	60, 100, 107
474	SAVE1	34,	121
641	SAVE2	40,	125
0	(TES)	5	

NO ERROR IN ABOVE ASSEMBLY.

94

BINARY CARD NO. KEYCN000
00000

ENTRY KEYCN

BINARY CARD NO. KEYCN001

00000 0760 00 0 00004
00001 -0600 60 4 00001
00002 0020 00 4 00002

KEYCN ENK **
STQ* 1,4
TRA 2,4
END

POST PROCESSOR ASSEMBLY DATA

3 IS THE FIRST LOCATION NOT USED BY THIS PROGRAM.

REFERENCES TO DEFINED SYMBOLS

0 KEYCN 0

NO ERROR IN ABOVE ASSEMBLY.

ERRANG - ERROR ANGLE SUBROUTINE

```
SUBROUTINE ERRANG (CUDPHS,CUDPSS,CUDTHS,CDPHSC,CDPSSC,CDTHSC)
1 IF(ABSF(CUDPHS)-20./57.2957795) 3, 3, 4
3 CDPHSC=CUDPHS
   GO TO 7
4 IF (CUDPHS) 5, 6, 6
5 CDPHSC=-20./57.2957795
   GO TO 7
6 CDPHSC=20./57.2957795
7 IF (ABSF(CUDPSS)-20./57.2957795) 8, 8, 9
8 CDPSSC=CUDPSS
   GO TO 12
9 IF (CUDPSS) 10, 11, 11
10 CDPSSC=-20./57.2957795
   GO TO 12
11 CDPSSC=20./57.2957795
12 IF (ABSF(CUDTHS)-20./57.2957795) 13, 14, 14
13 CDTHSC=CUDTHS
   GO TO 2
14 IF (CUDTHS) 15, 16, 16
15 CDTHSC=-20./57.2957795
   GO TO 2
16 CDTHSC=20./57.2957795
2 RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0)
```

ERRANG ERROR ANGLE SUBROUTINE

97

STORAGE NOT USED BY PROGRAM

DEC OCT
116 00164DEC OCT
32561 77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

1) DEC OCT
114 001623) DEC OCT
106 001526) DEC OCT
108 00154

DEC OCT

DEC OCT

EXTERNAL FORMULA NUMBERS WITH CORRESPONDING INTERNAL FORMULA NUMBERS AND OCTAL LOCATIONS

EFN	IFN	LOC												
1	3	00041	3	4	00051	4	6	00054	5	7	00057	6	9	00065
7	10	00070	8	11	00100	9	13	00103	10	14	00106	11	16	00114
12	17	00117	13	18	00127	14	20	00132	15	21	00135	16	23	00143
2	24	00146												

BINARY CARD NO. HDA70000

00000

ENTRY HDA7

BINARY CARD NO. HDA70001

00000	0776	00	0	01227	HDA7	SDN	663
00001	0020	00	4	00001	TRA	1,4	
END							

POST PROCESSOR ASSEMBLY DATA

2 IS THE FIRST LOCATION NOT USED BY THIS PROGRAM

REFERENCES TO DEFINED SYMBOLS

0 HDA7 0

NO ERROR IN ABOVE ASSEMBLY.

100

BINARY CARD NO. HDA90000

00000

ENTRY HDA9

BINARY CARD NO. HDA90001

00000 0776 00 0 01231

HDA9 SDN 665

00001 0020 00 4 00001

TRA 1,4

END

POST PROCESSOR ASSEMBLY DATA

2 IS THE FIRST LOCATION NOT USED BY THIS PROGRAM

REFERENCES TO DEFINED SYMBOLS

0 HDA9 0

NO ERROR IN ABOVE ASSEMBLY.

102

BINARY CARD NO. LDB60000
00000

ENTRY : LDB6

BINARY CARD NO. LDB60001

00000	0776	00	0	02206	LDB6	SDN	1158
00001	0020	00	4	00001	TRA		1,4
END							

POST PROCESSOR ASSEMBLY DATA

2 IS THE FIRST LOCATION NOT USED BY THIS PROGRAM.

REFERENCES TO DEFINED SYMBOLS

0 LDB6 0

NO ERROR IN ABOVE ASSEMBLY.

ISZS

SUBROUTINE IVISZS(LDI22,LC5,CSTZ,CT,LD011,LD012,LD013,CDVXZ,CDVYZ,
1CDVZZ,LDI25,LDI26,LDI31,LC1,LC1J)
301 IF (LDI22) 2,302,2
302 IF (LC5) 308,323,308
323 CSTZ=CT+23.
303 LD012=0
LD013=4095
LD011=4095
304 LD012=4095
LD011=4095
305 LD013=0
LD011=4095
306 LC5=4095
307 CDVXZ=0.
CDVYZ=0.
CDVZZ=0.
GO TO 2
308 IF (LDI25) 345,309,345
309 IF (LDI26) 345,310,345
310 IF (LDI31) 345,346,345
345 IF ((CSTZ-CT) 346,2,2
346 LC1=0
LC5=0
347 LC1J=-4095
2 RETURN
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0)

ISZS

105

STORAGE NOT USED BY PROGRAM

DEC OCT
115 00163

DEC OCT
32561 77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

2) DEC OCT
105 00151

3) DEC OCT
107 00153

6) DEC OCT
109 00155

DEC OCT

DEC OCT

EXTERNAL FORMULA NUMBERS WITH CORRESPONDING INTERNAL FORMULA NUMBERS AND OCTAL LOCATIONS

EFN	IFN	LOC
301	3	00057
305	11	00104
310	20	00131

EFN	IFN	LOC
302	4	00063
306	13	00110
345	21	00133

EFN	IFN	LOC
323	5	00067
307	14	00112
346	22	00137

EFN	IFN	LOC
303	6	00072
308	18	00121
347	24	00143

EFN	IFN	LOC
304	9	00100
309	19	00125
2	25	00145

IDS

```
SUBROUTINE IVIDS (CDVXS,CDVXB,CDVXZ,CDVYS,CDVYB,CDVYZ,CDVZS,CDVZB,  
1CDVZZ,LDI22,LC1J,LDO12,LDO13,CDV,CDVXSP,CDVYSP,CDVZSP)  
326 CDVXS=CDVXB-CDVXZ  
CDVYS=CDVYB-CDVYZ  
CDVZS=CDVZB-CDVZZ  
327 IF (LDI22) 344,328,344  
328 IF (LC1J) 336,334,330  
330 LC1J=-4095  
331 LDO12=4095  
LDO13=4095  
332 IF (CDVZS) 11,13,12  
11 CDVZS=CDVZS-.5  
GO TO 13  
12 CDVZS=CDVZS+.5  
13 CDV = INTF(CDVZS)  
CDVZSP=CDVZSP+CDV  
333 CDVZZ=CDVZZ+CDV  
GO TO 344  
334 LC1J=4095  
335 LDO12=0  
LDO13=4095  
339 IF (CDVYS) 14,16,15  
14 CDVYS=CDVYS-.5  
GO TO 16  
15 CDVYS=CDVYS+.5  
16 CDV = INTF(CDVYS)  
CDVYSP=CDVYSP+CDV  
340 CDVYZ=CDVYZ+CDV  
GO TO 344  
336 LC1J=0  
337 LDO12=4095  
LDO13=0  
341 IF (CDVXS) 17,19,18  
17 CDVXS=CDVXS-.5  
GO TO 19  
18 CDVXS=CDVXS+.5  
19 CDV = INTF(CDVXS)  
CDVXSP=CDVXSP+CDV  
342 CDVXZ=CDVXZ+CDV  
344 RETURN  
END(1,1,0,0,0,0,1,1,0,0,0,0,0,0,0,0)
```

IDS

107

STORAGE NOT USED BY PROGRAM

DEC	OCT
195	00303
32561	77461

LOCATIONS FOR OTHER SYMBOLS NOT APPEARING IN SOURCE PROGRAM

2)	DEC	OCT	3)	DEC	OCT	6)	DEC	OCT	DEC	OCT	DEC	OCT
	186	00272		188	00274		189	00275				

EXTERNAL FORMULA NUMBERS WITH CORRESPONDING INTERNAL FORMULA NUMBERS AND OCTAL LOCATIONS

EFN	IFN	LOC												
326	3	00125	327	6	00136	328	7	00142	330	8	00146	331	9	00150
332	11	00154	11	12	00157	12	14	00163	13	15	00166	333	17	00175
334	19	00201	335	20	00203	339	22	00207	14	23	00212	15	25	00216
16	26	00221	340	28	00230	336	30	00234	337	31	00236	341	33	00242
17	34	00245	18	36	00251	19	37	00254	342	39	00263	344	40	00266

ARGUMENT 1 IS THE NUMBER OF FILES TO BE SKIPPED GREATER THAN ZERO

* ARGUMENT 2 IS THE CHANNEL SELECTED
* CHANNEL A = 1
* CHANNEL B = 2
* ARGUMENT 3 IS THE TAPE DRIVE SETTING

BINARY CARD NO. SKIPN000
00000

ENTRY SKPN

BINARY CARD NO. SKIPN001

00000	0634	00	1	00020	SKPN	SXA	RTN,1
00001	0634	00	2	00021		SXA	RTN+1,2
00002	0500	60	4	00001		CLA*	1,4
00003	-0734	00	1	00000		PDX	0,1
00004	0500	60	4	00002		CLA*	2,4
00005	-0734	00	2	00000		PDX	0,2
00006	0500	00	2	00025		CLA	CH+2,2
00007	0400	60	4	00003		ADD*	3,4
00010	0771	00	0	00022		ARS	18
00011	0621	00	0	00012		STA	A
00012	0762	00	0	00000	A	RDS	**
00013	0522	00	2	00027		XEC	CH+4,2
00014	0522	00	2	00031		XEC	CH+6,2
00015	0522	00	2	00033		XEC	CH+8,2
00016	0020	00	0	00012		TRA	A
00017	2	00001	1	00012		TIX	A,1,1
00020	0774	00	1	00000	RTN	AXT	0,1
00021	0774	00	2	00000		AXT	0,2
00022	0020	00	4	00004		TRA	4,4
00023	+001200000000				CH	OCT	2200000000

BINARY CARD NO. SKIPN002

00024	+001200000000				OCT	1200000000	
00025	-0540	00	0	00033	RCHB	CW1	
00026	0540	00	0	00033	RCHA	CW1	
00027	0061	00	0	00014	TCOB	A+2	
00030	0060	00	0	00014	TCOA	A+2	
00031	-0030	00	0	00017	TEFB	RTN-1	
00032	0030	00	0	00017	TEFA	RTN-1	
00033	2	00000	0	00000	CWI	IOPR	0,0,0
00034	0	00000	0	00000		IOCD	0,0,0
						END	

ARGUMENT 1 IS THE NUMBER OF FILES TO BE SKIPPED GREATER THAN ZERO

* ARGUMENT 2 IS THE CHANNEL SELECTED
* CHANNEL A = 1
* CHANNEL B = 2
* ARGUMENT 3 IS THE TAPE DRIVE SETTING

BINARY CARD NO. SKIPN000
00000

ENTRY SKPN

BINARY CARD NO. SKIPN001

00000	0634	00	1	00020	SKPN	SXA	RTN,1
00001	0634	00	2	00021		SXA	RTN+1,2
00002	0500	60	4	00001		CLA*	1,4
00003	-0734	00	1	00000		PDX	0,1
00004	0500	60	4	00002		CLA*	2,4
00005	-0734	00	2	00000		PDX	0,2
00006	0500	00	2	00025		CLA	CH+2,2
00007	0400	60	4	00003		ADD*	3,4
00010	0771	00	0	00022		ARS	18
00011	0621	00	0	00012		STA	A
00012	0762	00	0	00000	A	RDS	**
00013	0522	00	2	00027		XEC	CH+4,2
00014	0522	00	2	00031		XEC	CH+6,2
00015	0522	00	2	00033		XEC	CH+8,2
00016	0020	00	0	00012		TRA	A
00017	2	00001	1	00012		TIX	A,1,1
00020	0774	00	1	00000	RTN	AXT	0,1
00021	0774	00	2	00000		AXT	0,2
00022	0020	00	4	00004		TRA	4,4
00023	+002200000000				CH	OCT	2200000000

BINARY CARD NO. SKIPN002

00024	+001200000000		OCT	1200000000			
00025	-0540	00	0	00033		RCHB	CW1
00026	0540	00	0	00033		RCHA	CW1
00027	0061	00	0	00014		TCOB	A+2
00030	0060	00	0	00014		TCOA	A+2
00031	-0030	00	0	00017		TEFB	RTN-1
00032	0030	00	0	00017		TEFA	RTN-1
00033	2	00000	0	00000	CW1	IOPR	0,0,0
00034	0	00000	0	00000		IOCD	0,0,0
						END	

ARGUMENT 1 IS THE NUMBER OF FILES TO BE SKIPPED GREATER THAN ZERO
POST PROCESSOR ASSEMBLY DATA

35 IS THE FIRST LOCATION NOT USED BY THIS PROGRAM

REFERENCES TO DEFINED SYMBOLS

12	A	11,	16,	17,	27,	30
23	CH	6,	13,	14,	15	
33	CW1	25,	26			
20	RTN	0,	1,	31,	32	
0	SKPN	0				

NO ERROR IN ABOVE ASSEMBLY.

APPENDIX B

Sample on-line and off-line output.

ON-LINE OUTPUT

1356.0	211413.3	-88135.2	-560.0	0.	0.	0.	4095	0
1357.0	211239.8	-88135.5	-561.4	13.	0.	0.	4095	0
1358.0	211064.3	-88136.2	-561.6	12.	0.	0.	4095	0
1359.0	210888.8	-88137.2	-562.6	12.	0.	0.	4095	0
1360.0	210712.1	-88138.5	-563.2	11.	0.	0.	4095	0
1361.0	210535.3	-88139.5	-564.4	10.	0.	0.	4095	0
1362.0	210356.2	-88141.5	-565.1	9.	0.	0.	4095	0
1363.0	210177.1	-88143.5	-566.0	8.	0.	0.	4095	0
1364.0	209998.4	-88146.2	-566.9	7.	0.	0.	4095	0
1365.0	209816.7	-88148.5	-567.5	6.	0.	0.	4095	0
1366.0	209635.4	-88151.0	-568.4	5.	0.	0.	4095	0
1367.0	209452.7	-88154.0	-568.8	5.	0.	0.	4095	0
1368.0	209269.7	-88157.5	-569.8	4.	0.	0.	4095	0
1369.0	209086.1	-88161.0	-570.4	3.	0.	0.	4095	0
1370.0	208900.8	-88164.5	-571.3	2.	0.	0.	4095	0
1371.0	208715.9	-88168.5	-571.8	1.	0.	0.	4095	0
1430.0	19 683.9	-88291.0	-613.4	0.	0.	0.	4095	0
1530.0	179001.1	-87891.7	-674.4	0.	0.	0.	4095	4095
1630.0	160501.0	-86739.5	-729.6	0.	0.	0.	4095	4095
1730.0	142357.1	-84847.7	-775.1	0.	0.	0.	4095	0
1830.0	124736.8	-82247.5	-807.9	0.	0.	0.	4095	0
1930.0	107804.6	-78967.7	-829.5	0.	0.	0.	4095	0
2030.0	91717.6	-75055.0	-840.6	0.	0.	0.	4095	4095
2076.0	84640.2	-73057.7	-841.7	0.	0.	1.	4095	4095
2130.0	76599.5	-70578.5	-838.2	0.	0.	0.	4095	0
2230.0	62577.4	-65592.0	-823.9	0.	0.	0.	4095	4095
2330.0	49777.6	-60148.7	-796.6	0.	0.	0.	4095	4095
2430.0	38294.3	-54321.5	-756.9	0.	0.	0.	4095	0
2530.0	28210.0	-48190.0	-706.6	0.	0.	0.	4095	0
2630.0	19586.0	-41837.0	-645.4	0.	0.	0.	4095	0
2730.0	12456.6	-35347.2	-573.7	0.	0.	0.	4095	4095
2799.0	8424.6	-30835.2	-519.4	0.	0.	1.	4095	4095
2830.0	6837.6	-28810.5	-493.9	0.	0.	0.	4095	0
2930.0	2706.5	-22313.0	-406.2	0.	0.	0.	4095	0

TIME (SECONDS)	RELATIVE POSITION (FT)			RELATIVE VELOCITY (FPS)			RADAR RANGE (FT)	RANGE RATE (FPS)	LD100
	TRAILING	VERTICAL	OUT-OF-PLANE	TRAILING	VERTICAL	OUT-PLANE			
3030.0	75.4	-15935.5	-314.5	-18.95	62.91	0.96	15938.2	-63.07	4095
3130.0	-1098.5	-9762.5	-217.4	-4.62	60.46	1.01	9826.1	-59.66	4095
3230.0	-874.1	-3873.2	-115.1	9.03	57.20	1.04	3970.9	-57.92	4095
3282.0	-225.7	-949.7	-60.1	15.80	55.19	1.05	977.1	-57.48	4095
3283.0	-210.0	-894.5	-59.0	15.93	55.15	1.05	919.9	-57.18	4095
3284.0	-194.4	-839.5	-57.6	16.06	55.11	1.05	862.5	-57.39	4095
3285.0	-177.4	-784.2	-56.9	16.19	55.07	1.05	805.4	-57.13	4095
3286.0	-161.8	-729.2	-56.0	16.31	55.03	1.05	748.0	-57.37	4095
3287.0	-144.8	-674.0	-54.6	16.44	54.99	1.05	690.8	-57.27	4095
3288.0	-127.9	-618.7	-53.9	16.57	54.95	1.05	633.7	-57.03	4095
3289.0	-112.2	-564.2	-52.7	16.70	54.91	1.05	576.8	-56.91	4095
3290.0	-95.2	-509.2	-51.9	16.82	54.87	1.05	519.8	-57.03	4095
3291.0	-78.3	-454.2	-50.5	16.95	54.83	1.05	462.9	-56.89	4095
3292.0	-61.3	-399.5	-49.6	17.08	54.79	1.05	406.4	-56.47	4095
3293.0	-44.4	-344.5	-48.6	17.20	54.75	1.05	350.2	-56.21	4095
3294.0	-27.4	-290.2	-47.7	17.33	54.70	1.05	294.5	-55.74	4095
3295.0	-9.1	-235.2	-47.0	17.46	54.66	1.05	239.5	-54.93	0
3296.0	9.0	-181.0	-45.9	17.58					

OFF - LINE OUTPUT : SHEET 1

TIME	FROM PROBLEM START	0.17299999E 04	DATE 11/ 8/65	RUN 7M5-MVS-5.1
GEMINI	POSITION - INERTIAL - TARGET IN GEMINI FRAME	-0.21500326E 08 0.17217291E 06	-0.36073972E 07 -0.91762207E 03	0.13602526E 06 -0.88263404E 05
TARGET	VELOCITY - INERTIAL	0.37482695E 04	-0.21964563E 05	0.12298762E 05
	VECTOR MAGNITUDE	0.21801280E 08		
	POSITION - INERTIAL	-0.21562400E 08	-0.37700363E 07	0.22046330E 06
	VELOCITY - INERTIAL	0.39480667E 04	-0.21860373E 05	0.12261964E 05
S/C IN TARG. CYLINDRICAL	VECTOR MAGNITUDE	0.21890611E 08		
	X-Y-Z POSITION	0.17197191E 06	-0.89331999E 05	-0.87350976E 03
	X-Y-Z VELOCITY	-0.18165307E 03	0.15176138E 02	-0.26491699E 01
MATRIX	INERTIAL - SPACECRAFT	0.14561331E-00 -0.86342735E 00 0.48301446E-00	0.74281510E-01 -0.47729865E-00 -0.87560099E 00	0.98655365E 00 0.16337482E-00 -0.53614577E-02
MATRIX	TARGET - INERTIAL	-0.15557608E-00 0.86154426E 00 -0.48325722E-00	-0.98500673E 00 -0.17222161E-00 0.10071137E-01	-0.74550607E-01 0.47757845E-00 0.87542047E 00
MATRIX	INERTIAL - NAVIGATION	0.14784122E-00 -0.86292014E 00 0.48323054E-00	0.98619548E 00 0.16546750E-00 -0.62394798E-02	-0.74574780E-01 0.47748224E-00 0.87547091E 00
MATRIX	SPACECRAFT - NAVIGATION	0.10000038E 01 -0.26465580E-03 0.22830591E-02	-0.22797333E-02 -0.25803135E-03 0.10000014E 01	-0.26519224E-03 -0.10000043E 01 -0.25724678E-03
RADAR	RANGE - AZIMUTH %R# - ELEVATION %A# RATE - SINE R - SINE A	0.19347981E 06 -0.16779101E 03	0.47427416E-02 0.16617562E-01	0.58094794E 01 -0.36700781E-00
GIMBAL ANGLES	THETA - PSI - PHI	0.22797436E-02	0.26519108E-03	0.62829279E 01
INTEGRATING ACCELEROMETER OUTPUTS	- BEFORE COMP - AFTER COMP	0. 0.	0. 0.	-0. -0.
DELTA V	METER READINGS	0.	0.	0.
THRUSTER	ACCELERATION	0.	0.	0.
DELTA V	TOTAL APPLIED	0.29239997E 02	0.	0.
ERROR ANGLES		0.23271056E-02	0.	0.
TURNING RATES		PITCH -0.11635528E-02	YAW -0.	ROLL -0.
ORBITAL PARAMETERS	MU - OMEGA - IOTA	0.12911297E-01	0.32965243E 01	0.50438696E 00

OFF-LINE OUTPL : SHEET 2

TIME # 0.17299999E 04 SECONDS.
SIMULATED COMPUTER OUTPUTS ON THIS PAGE.

DATE 11/ 8/65

RUN 7M5-MVS-5.1

CT	0.17299999E 04	CA11	0.99999683E 00	CA12	-0.25132741E-02	CA13	-0.	CDVT	0.56932953E 02
CWTPR	0.33161255E 01	CA21	-0.93626756E-11	CA22	-0.37252785E-08	CA23	-0.99999999E 00	CDVI	0.29742391E 02
CDFL	0.95993108E 00	CA31	0.25132741E-02	CA32	0.99999683E 00	CA33	-0.37252902E-08	CDVF	0.27190562E 02
CTM	0.12599999E 04	CPSPSR	0.55925804E-04	CFX	0.	CX	0.25875769E 06	CDVXB	0.49796902E-00
CDTM	0.82555399E 03	CCPSIR	0.99999999E 00	CFY	0.	CY	-0.89824490E 05	CDVYB	0.80325780E-01
CDTV	0.12427079E 04	CSTHR	0.20269533E-02	CFZ	0.	CZ	0.48029104E 03	CDVZB	0.93393707E-02
TSC	0.10399999E 04	CCTHR	0.99999794E 00	CDVXS	0.49796902E-00	CXM	0.25875769E 06	CDVXM	-0.41508873E-00
CTDAS	0.17299999E 04	CM1	0.99999794E 00	CDVYS	0.80325780E-01	CYM	-0.89824490E 05	CDVYM	-0.19550854E-00
CRIO	0.	CM3	0.91171844E 00	CDVZS	0.50933937E 00	CZM	0.48029104E 03	CDVZM	0.20973882E-00
CPHIB	0.62831853E 01	CM4	-0.18290102E-02	CDV	0.	CXZ	0.35970651E 06	CDXD	0.26155093E 02
CPSIB	0.	CM5	-0.41081146E-00	CSTZ	0.17529999E 04	CYZ	-0.88809620E 05	CDYD	0.11745510E 02
CTHR	0.25132741E-02	CM6	0.41563545E-02	CTD	0.20000000E 03	CZZ	-0.24712544E 04	CDZD	-0.79097392E 01
CUDPHS	0.59604645E-07	COEFF	-0.18606968E-02	CSTD	0.12000000E 04	CCR1	0.	CXTD	-0.15663639E 03
CUDPSS	0.	CCK1	-0.12788025E-02	CSTD	0.65000000E 03	COI	0.	CYTD	-0.20640697E 01
CUDTHS	0.25132741E-02	CCK2	0.13132936E-02	CWSTD	0.23314618E-00	C2I	0.	CZTD	0.47834462E 01
CDPHSC	0.	CCK3	-0.10181683E-02	CWSTD	0.75772510E 00	CCABI	0.	CXRD	-0.18283807E 03
CDPSSC	0.	CCK4	-0.20427573E-02	CNS	0.70000000E 01	CCASI	0.	CYRD	-0.13873315E 02
CDTHSC	0.23271056E-02	CCK5	0.12321033E-02	CTX	0.34000000E 03	CCRBI	0.	CZRD	-0.31752948E 01
CPSIBC	0.	CCKF	-0.88551982E-03	CDTX	0.20000000E 02	CCRSI	0.	CDXFD	0.26584303E 02
CTHBC	0.	CCKG	0.16961742E-02	CRA	0.	CATXBI	0.	CDYFD	0.47122745E 01
CPSBCP	0.62811790E 01	TEST	0.	CR1	0.21889127E 06	CAPTI	0.	CDZFD	0.32242788E 01
CTHBOP	0.42712694E-00	FIN	0.	CDRRD	0.99990000E 04	CSRTI	0.	CXSD	0.18308564E 03
CPSIBM	0.62813593E 01	FP	0.	RRDREF	0.33392908E 03	CRS	0.21797321E 08	CYSD	0.82218567E 02
CTHBM	0.42712772E-00	SW	0.	CRD	0.99990000E 04	COMGS	0.11658516E-02	CZSD	-0.55368175E 02
CRRI	0.21141621E 06	CRRI	0.21771100E 06	CRRG	0.21771100E 06	CRR	0.21889127E 06	CDVXZ	0.
CSAPI	-0.42225709E-00	CSADPI	-0.35190618E-00	CSAPG	-0.40428741E-00	CSAPR	0.20269533E-02	CDVYZ	0.
CSRPT	0.26960970E-02	CSRDP	0.14142802E-01	CSRPG	0.26960970E-02	CSRPR	-0.55925804E-04	CDVZZ	0.
RDGD	0.40950000E 04	CTR	0.13000000E 03	CTR1	0.15800000E 04	CTLRP	0.15800000E 04	CDTW	-0.35555398E 03
TVX	0.	TVY	0.	TVZ	0.	TYC	0.	TPC	0.
TVX	0000000000000	TVY	0000000000000	TVZ	0000000000000	TYC	0000000000000	TPC	0000000000000
LC1	0	LC4C	0	LC10	0	LD100	0	IC	4
LC1J	-4095	LC4D	4095	LCA	0	LD121	4095	KC	4
LC2	4095	LC7	4095	LCS	0	LD005	0	K2C	0
LC3	4095	LC8	4095	N	-1	M	0	L	0

11 VALUES EACH OF X,Y,Z, AND DELTA T

0.29777842E 06	-0.89328323E 05	-0.70728532E 03	-0.
0.31331852E 06	-0.89204617E 05	-0.11501496E 04	-0.
0.32879878E 06	-0.89072406E 05	-0.16303751E 04	-0.
0.34431585E 06	-0.88786081E 05	-0.19252704E 04	-0.
0.19956721E 06	-0.90832833E 05	-0.40035439E 03	-0.
0.20327564E 06	-0.91005729E 05	-0.40665068E 03	-0.
0.20694850E 06	-0.91116174E 05	-0.41285703E 03	-0.
0.21073224E 06	-0.91072698E 05	-0.27515465E 03	-0.
0.21446788E 06	-0.91116033E 05	-0.27928787E 03	-0.
0.21810985E 06	-0.91233986E 05	-0.13508210E 03	-0.
0.22186159E 06	-0.91194405E 05	-0.13705246E 03	-0.

TIME #SEC#	TRAILING %FT#	VERTICAL %FT#	OUT-OF-PLANE	X-METER	Y-METER	Z-METER	LD121	LRDFD1
1730.0	171971.9	-89332.0	-873.5	0.	0.	0.	4095	0